

## INSPECTION

### 1. INSPECT REAR SPEED SENSOR

(a) Check the speed sensor. If any of the following occurs, replace the speed sensor with a new one.

- The surface of the speed sensor is cracked, dented, or chipped off.
- The connector or wire harness is scratched, cracked, or damaged.
- The speed sensor has been dropped.

BC

## INSTALLATION

### HINT:

- Use the same procedures for the LH side and RH side.
- The procedures listed below are for the LH side.

### 1. INSTALL REAR SPEED SENSOR LH

#### NOTICE:

To prevent interference with other parts, do not twist the sensor wire's painted line areas when installing it.

(a) Install the sensor (labeled A) with the bolt (labeled B).



**Torque: 8.5 N\*m (87 kgf\*cm, 75 in.\*lbf)**

#### NOTICE:

- Keep the sensor tip and sensor installation hole free from foreign matter.
- To prevent interference with the bearing rotor, do not rotate the sensor body when inserting the sensor body or after inserting the sensor body.

(b) Install the sensor clamp (labeled C) with the nut (labeled D).

**Torque: 5.0 N\*m (51 kgf\*cm, 44 in.\*lbf)**



(c) Install the sensor clamps (labeled E) with the 2 nuts (labeled F).

**Torque: 5.0 N\*m (51 kgf\*cm, 44 in.\*lbf)**

#### NOTICE:

Do not twist the sensor wire when installing the clamps.


(d) Install the sensor clamp (labeled G) with the bolt (labeled H).

**Torque: 8.5 N\*m (87 kgf\*cm, 75 in.\*lbf)**

#### NOTICE:

Do not twist the sensor wire when installing the clamp.


BC



(e) Insert the connector and grommet to the inside of the vehicle through the passage hole in the wheel house.

**NOTICE:**


**Make sure the grommet's band clamp remains on the outside of the vehicle.**



(f) Hold the grommet and pull it from the inside of the vehicle to the outside of the vehicle. Then fix it in place so that it is not tilted.

**NOTICE:**

- When pulling out the grommet, do not grip the sensor wire.
- Fix the grommet in place within the range shown in the illustration.



(g) Connect the speed sensor connector.

**2. INSTALL DECK TRIM SIDE PANEL ASSEMBLY LH**

(a) Install the deck trim side panel LH (see page [IR-49](#)).

**HINT:**

Refer to the procedures from the installation of the deck trim side panel LH up until the installation of the rear door scuff plate LH.

**3. INSTALL REAR WHEEL**

**Torque: 103 N\*m (1,050 kgf\*cm, 76 ft.\*lbf)**

---

4. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL
5. CHECK SPEED SENSOR SIGNAL
  - (a) Check the speed sensor signal (see page [BC-28](#)).

BC