



## DOOR LOCK CONTROL (LHD)

FROM POWER SOURCE SYSTEM (SEE PAGE 130)




The current 18-plane add from DB-LCK goes to TERMINAL\_BD118 and then to each board\_ECU, and from BOARD\_A to



## DOOR LOCK CONTROL (LHD)

FROM POWER SOURCE SYSTEM (SEE PAGE 130)



**SYSTEM OUTLINE**

The current is always sent from DR LCK fuse to TERMINAL BDL of multiplex network body ECU, and from DOME fuse to TERMINAL BDM of multiplex network master SW. When ignition SW is turned on, the current is sent from ECU-IG fuse to TERMINAL SIG of the multiplex network body ECU.

**1. MANUAL LOCK OPERATION**

When the door lock control SW (Multiplex network master SW) is turned to LOCK position, the lock signal from TERMINAL TX of multiplex network master SW is input to TERMINAL MPX of multiplex network body ECU to operate ECU. The current is sent from TERMINAL LOCK of ECU to each motor and the motor locks the doors by the current sent from TERMINAL ULCK of ECU to GROUND.

**2. MANUAL UNLOCK OPERATION**

When the door lock control SW (Multiplex network master SW) is turned to UNLOCK position, the unlock signal from TERMINAL TX of multiplex network master SW is input to TERMINAL MPX of multiplex network body ECU to operate ECU. The current is sent from TERMINAL ULCK of ECU to each motor and the motor unlocks the doors by the current sent from TERMINAL LOCK of ECU to GROUND.

**SERVICE HINTS****M2 (B) MULTIPLEX NETWORK BODY ECU**

14-GROUND : Approx. 12 volts with the ignition SW at **ON** position

24-GROUND : Always continuity

12-GROUND : Always approx. 12 volts

23-GROUND : Approx. 12 volts for **0.2** seconds with following operations

\* Door lock control SW unlocked

\* Door lock control SW locked with ignition key cylinder and driver's door open  
(Ignition key reminder function)

\* Door lock knob locked with ignition key in cylinder and driver's door open

22-GROUND : Approx. 12 volts for **0.2** seconds with following operations

\* Door lock control SW locked

(B) 5-GROUND : Always continuity

**D11, D12 DOOR COURTESY SW FRONT LH, RH**

1-GROUND : Closed with each of the door open

**S9, S10 SLIDE DOOR COURTESY SW LH, RH**

1-GROUND : Closed with each of the door open

**U1 UNLOCK WARNING SW**

1-2 : Closed with the ignition key in the cylinder

**O : PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
B4	98 (LHD)	J22	98 (LHD)	S11	A 99 (LHD)
B5	98 (LHD)	J25	98 (LHD)	S12	B 99 (LHD)
D4	96 (LHD)	J29	98 (LHD)	S13	A 99 (LHD)
D11	98 (LHD)	M1 A	97 (LHD)	S14	B 99 (LHD)
D12	98 (LHD)	M2 B	97 (LHD)	S17	99 (LHD)
D13	98 (LHD)	M3	98 (LHD)	S18	99 (LHD)
D18	98 (LHD)	S9	99 (LHD)	U1	97 (LHD)
J3	97 (LHD)	S10	99 (LHD)		

# DOOR LOCK CONTROL (LHD)

## □ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	81	Engine Room Main Wire and Engine Room J/B (Left of the Air Cleaner)
3A		
3B		
3D		
3E		
4B		
4C		
4F		
5A		
5B		
5C		
5F	84 (LHD)	Engine Room Main Wire and Passenger Side J/B (Cowl Side of the Front Passenger's Seat)
5I	84 (LHD)	Floor Wire and Passenger Side J/B (Cowl Side of the Front Passenger's Seat)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	108 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
ID1	108 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
IF1	108 (LHD)	Instrument Panel Wire and Cowl No.3 Wire (Right of the Center Airbag Sensor Assembly)
II1	110 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Surrounding of the Passenger Side J/B)
IK2	110 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BE1	112 (LHD)	Back Door No.1 Wire and Floor No.2 Wire (Rear of the Left Side of the Roof Panel)
BG1	112 (LHD)	Back Door No.1 Wire and Back Door No.2 Wire (Left of License Plate)

## ▽ : GROUND POINTS


Code	See Page	Ground Points Location
EA	106 (LHD)	Front Fender Front Apron RH
IB	108 (LHD)	Upper Part of Front Body Pillar RH
BF	112 (LHD)	Center of the Back Door


## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	110 (LHD)	Instrument Panel Wire	I10	110 (LHD)	Instrument Panel Wire
		A 112	(DHL) 98	92	(DHL) 98 110
		B 512	(DHL) 98	83	(DHL) 98 510
		A 612	(DHL) 98	85	(DHL) 98 610
		B 418	(DHL) 98	110	(DHL) 98 410
		712	(DHL) 98	84	(DHL) 98 710
		612	(DHL) 98	81	(DHL) 98 610
		10	(DHL) 98	92	(DHL) 98 840
			(DHL) 98	912	(DHL) 98 610

# DOOR LOCK CONTROL (RHD)


FROM POWER SOURCE SYSTEM (SEE PAGE 130)





## DOOR LOCK CONTROL (RHD)

FROM POWER SOURCE SYSTEM (SEE PAGE 130)



**SYSTEM OUTLINE**

The current is always sent from DR LCK fuse to TERMINAL BDL of multiplex network body ECU, and from DOME fuse to TERMINAL BDM of multiplex network master SW. When ignition SW is turned on, the current is sent from ECU-IG fuse to TERMINAL SIG of the multiplex network body ECU.

**1. MANUAL LOCK OPERATION**

When the door lock control SW (Multiplex network master SW) is turned to LOCK position, the lock signal from TERMINAL TX of multiplex network master SW is input to TERMINAL MPX of multiplex network body ECU to operate ECU. The current is sent from TERMINAL LOCK of ECU to each motor and the motor locks the doors by the current sent from TERMINAL ULCK of ECU to GROUND.

**2. MANUAL UNLOCK OPERATION**

When the door lock control SW (Multiplex network master SW) is turned to UNLOCK position, the unlock signal from TERMINAL TX of multiplex network master SW is input to TERMINAL MPX of multiplex network body ECU to operate ECU. The current is sent from TERMINAL ULCK of ECU to each motor and the motor unlocks the doors by the current sent from TERMINAL LOCK of ECU to GROUND.

**SERVICE HINTS****M2 (B) MULTIPLEX NETWORK BODY ECU**

14-GROUND : Approx. 12 volts with the ignition SW at **ON** position

24-GROUND : Always continuity

12-GROUND : Always approx. 12 volts

23-GROUND : Approx. 12 volts for **0.2** seconds with following operations

\* Door lock control SW unlocked

\* Door lock control SW locked with ignition key cylinder and driver's door open  
(Ignition key reminder function)

\* Door lock knob locked with ignition key in cylinder and driver's door open

22-GROUND : Approx. 12 volts for **0.2** seconds with following operations

\* Door lock control SW locked

(B) 5-GROUND : Always continuity

**D11, D12 DOOR COURTESY SW FRONT LH, RH**

1-GROUND : Closed with each of the door open

**S9, S10 SLIDE DOOR COURTESY SW LH, RH**

1-GROUND : Closed with each of the door open

**U1 UNLOCK WARNING SW**

1-2 : Closed with the ignition key in the cylinder

**O : PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
B4	104 (RHD)	J3	103 (RHD)	S9	105 (RHD)
B5	104 (RHD)	J14	A	S10	105 (RHD)
D4	102 (RHD)	J15	B	S11	A
D11	104 (RHD)	J22	104 (RHD)	S12	B
D12	104 (RHD)	J25	104 (RHD)	S13	A
D14	B	J29	104 (RHD)	S14	B
D15	A	M1	A	S17	105 (RHD)
D16	A	M2	B	S18	105 (RHD)
D17	B	M3	104 (RHD)	U1	103 (RHD)

# DOOR LOCK CONTROL (RHD)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	81	Engine Room Main Wire and Engine Room J/B (Left of the Air Cleaner)
3B		
3D	88 (RHD)	Instrument Panel Wire and Center J/B (Right of the Combination Meter)
3E		
4B	82	Instrument Panel Wire and Driver Side J/B (Cowl Side of the Driver's Seat)
4C		
4F	83	Engine Room Main Wire and Driver Side J/B (Cowl Side of the Driver's Seat)
5A		
5B	86 (RHD)	Instrument Panel Wire and Passenger Side J/B (Cowl Side of the Front Passenger's Seat)
5C		
5F	86 (RHD)	Engine Room Main Wire and Passenger Side J/B (Cowl Side of the Front Passenger's Seat)
5I	86 (RHD)	Floor No.2 Wire and Passenger Side J/B (Cowl Side of the Front Passenger's Seat)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	116 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Upper Part of Front Body Pillar RH)
IC2	116 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IF1	116 (RHD)	Instrument Panel Wire and Cowl No.3 Wire (Left of the Center Airbag Sensor Assembly)
IK1	118 (RHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IK2		
IL2	118 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
BE1	120 (RHD)	Back Door No.1 Wire and Floor No.2 Wire (Rear of the Left Side of the Roof Panel)
BG1	120 (RHD)	Back Door No.1 Wire and Back Door No.2 Wire (Left of License Plate)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
ED	114 (RHD)	Front Fender Front Apron LH
IB	116 (RHD)	Upper Part of Front Body Pillar RH
BF	120 (RHD)	Center of the Back Door

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I4	118 (RHD)	Instrument Panel Wire	I9	118 (RHD)	Instrument Panel Wire

(CHR) 201	98	(CHR) 201	6L	(CHR) 201	4B
(CHR) 201	918	(CHR) 201	A	(CHR) 201	8B
(CHR) 201	A	(CHR) 201	B	(CHR) 201	3C
(CHR) 201	B	(CHR) 201	SSL	(CHR) 201	11G
(CHR) 201	A	(CHR) 201	SSL	(CHR) 201	31G
(CHR) 201	B	(CHR) 201	SSL	(CHR) 201	81G
(CHR) 201	118	(CHR) 201	BL	(CHR) 201	8
(CHR) 201	818	(CHR) 201	A	(CHR) 201	81G
(CHR) 201	818	(CHR) 201	B	(CHR) 201	A
(CHR) 201	818	(CHR) 201	EM	(CHR) 201	B