




TRC, VSC 和轮胎压力警告系统

From Power Source System (See Page 92)




S 2
Skid Control ECU with Actuator






TRC, VSC 和轮胎压力警告系统


From Power Source System (See Page 92)






TRC, VSC 和轮胎压力警告系统

From Power Source System (See Page 92)



From Power Source System (See Page 92)



System Outline

1. ABS Operation

If the brake pedal is depressed suddenly, the ABS controls the hydraulic pressure of the wheel cylinders for all the four wheels to automatically avoid wheel locking and ensure the directional and steering stability of the vehicle. If the brake pedal is depressed suddenly, the skid control ECU with actuator controls the solenoids in the actuators using the signals from the sensors to move the brake fluid to the reservoir in order to release the braking pressure applied to the wheel cylinder. If the skid control ECU with actuator detects that the fluid pressure in the wheel cylinder is insufficient, the ECU controls the solenoids in the actuators to increase the braking pressure.

2. Traction Control Operation

The traction control system controls the engine torque, the hydraulic pressure of the driving wheel cylinders, slipping of the wheels which may occur at start or acceleration of the vehicle, to ensure an optimal driving power and vehicle stability corresponding to the road conditions.

3. VSC Operation

Unexpected road conditions, vehicle speed, emergency situation, and any other external factors may cause large under- or over-steering of the vehicle. If this occurs, the VSC system automatically controls the engine power and wheel brakes to reduce the under- or over-steering.

To reduce large over-steering :

If the VSC system determines that the over-steering is large, it activates the brakes for the outer turning wheels depending on the degree of the over-steering to produce the moment toward the outside of the vehicle and reduce the over-steering.

To reduce large under-steering :

If the VSC system determines that the under-steering is large, it controls the engine power and activates the rear wheel brakes to reduce the under-steering.

Traction control SW

The traction control SW is used to stop the VSC function. After the engine is started, the VSC system is stopped (turned off) and the TRC OFF indicator light lights up. When the traction control SW is pressed again, the VSC system enters the stand-by mode. If the engine is stopped and restarted, the VSC system enters the stand-by mode regardless of the traction control SW.

4. Mutual System Control

To efficiently operate the VSC system at its optimal level, the VSC system and other control systems are mutually controlled while the VSC system is being operated.

Engine throttle control

The engine power does not interfere with the VSC brake control by controlling the opening of the throttle and reducing the engine output.

VSC system operation indication

The slip indicator light flashes and the buzzer sounds intermittently to warn the driver that the current road is slippery, while the VSC system is being operated.

5. Fail Safe Function

If an error occurs in the skid control ECU with actuator, sensor signals, and/or actuators, the skid control ECU with actuator inhibits the brake actuator control and inputs the error signal to the engine ECU. According to the error signal, the brake actuator turns off the solenoid and the engine ECU rejects any electronically controlled throttle open request from the VSC system. As a result, the vehicle functions regardless of the BA, TRC and VSC systems.

Service Hints

S2 Skid Control ECU with Actuator

46-Ground : Approx. 12 volts with the ignition SW at ON position (Ignition SW type) or with the power SW at IG ON position (Power SW type)

31-Ground : Always approx. 12 volts

1, 32-Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page	
A11	66	J5	A	64	P6	68
A18	66	J6	B	64	S2	65
B3	62	J7		64	S4	65
B5	66	J8	A	68	S5	65
C8	62	J9	B	68	S13	69
C15	66	J10	A	58, 68	S14	69
D2	67	J11	B	58, 68	S27	73
E2	A	J12	C	58, 68	S28	73
E3	B	J13	D	58, 68	T1	65
E4	C	J14	E	58, 68	T10	69
E5	D	J15	F	58, 68	T11	69
E6	E	J16	A	60, 68	T12	69
G1	67	J31	G	58, 68	V3	69
H12	67	J32	D	60, 68	W1	65
J1	A	J33	E	60, 68	Y1	69
J2	B	N1	64			

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)
3	31	Engine Room R/B No.3 (Near the Front Left Suspension Tower)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	23	Engine Room Main Wire and Engine Room J/B No.1 (Near the Front Right Suspension Tower)
4C		
4D		
4E		
4G	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4I		
4J		
4K		
5D		
5G		
5H		
5I	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5J		
5K		
5M		
DA	33	Instrument Panel Wire and Driver Side J/B (Cowl Side Left)
DD		
DK	34	Engine Room Main Wire and Driver Side J/B (Cowl Side Left)
DL		
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PD		
PK	40	Engine Room Main Wire and Front Passenger's Side J/B (Cowl Side Right)
PL		


TRC, VSC 和轮胎压力警告系统

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EB1	76	Engine Room Main Wire and Engine Wire (Inside of the ECU Box)
EC1	76	Skid Control Sensor Wire and Engine Room Main Wire (Engine Compartment Right)
ED1	76	Skid Control Sensor Wire and Engine Room Main Wire (Engine Compartment Left)
IB2	78	Engine Room Main Wire and Floor No.2 Wire (Left Cowl Side Panel)
ID2	78	Instrument Panel Wire and Engine Room Main Wire (Left Kick Panel)
IJ1	80	Engine Room Main Wire and Floor Wire (Right Kick Panel)
BG1	84	Skid Control Sensor Rear LH Wire and Floor No.2 Wire (Wheel House Rear LH)
BH1	84	Skid Control Sensor Wire and Floor Wire (Wheel House Rear RH)

: Ground Points

Code	See Page	Ground Points Location
EE	76	Rear Side of the Front Left Fender Apron
EF		
EI	76	Left Side of Cylinder Head
IK	78	Cowl Side Panel LH
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH



— Service Hints —

C14 (A) Clock (w/ Navigation System)

- (A) 4-Ground : Approx. 12 volts with the ignition SW at ON or ACC position (Ignition SW type) or with the power SW at IG ON or ACC ON position (Power SW type)
- (A) 8-Ground : Always approx. 12 volts
- (A) 7-Ground : Always continuity

C14 (B) Clock (w/o Navigation System)

- (B) 4-Ground : Approx. 12 volts with the ignition SW at ON or ACC position (Ignition SW type) or with the power SW at IG ON or ACC ON position (Power SW type)
- (B) 1-Ground : Always approx. 12 volts
- (B) 2-Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C14	A 66	G1	67	R3	C 68
	B 66	M5	68		
F14	67	R1 A	68		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B No.1 (Near the Front Right Suspension Tower)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
4C	44	Instrument Panel Wire and Center J/B RH (Right Side of the Instrument Panel Reinforcement)
4E		
4I		
4K		
5D	48	Instrument Panel Wire and Center J/B LH (Right Side of the Instrument Panel Reinforcement)
5G		
PA	39	Instrument Panel Wire and Front Passenger's Side J/B (Cowl Side Right)
PD		

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
II2	80	Instrument Panel Wire and Engine Room Main Wire (Right Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
IL	78	Left Side of Shift Lever
IN	78	Cowl Side Panel RH