


DTC	36	Steering Sensor Circuit
------------	-----------	--------------------------------

CIRCUIT DESCRIPTION


DTC No.	DTC Detecting Condition	Trouble Area
36	When steering angle is less than 36°, or any signal is not input at all.	<ul style="list-style-type: none"> •Battery •Steering sensor •Open or short circuit in between absorber control ECU and steering sensor •Absorber control ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check voltage between terminals SS1 and SS2 of absorber control ECU connector and body ground.



PREPARATION:

- (a) Remove the No.1 lower panel (See page BO-82).
- (b) Turn the ignition switch ON.

CHECK:

Measure the voltage between terminals SS1 and SS2 of the absorber control ECU connector and the body ground when the steering wheel is turned slowly.

OK:


Changes between 1 V and approx. 3.5 V



Proceed to next circuit inspection shown on problem symptoms table (See page DI-224).

NG

2 Check voltage between terminals 1 and 2 of steering sensor connector.



PREPARATION:

- (a) Remove the steering wheel lower No.2 and No.3 covers, steering wheel pad, steering wheel column upper and lower covers (See page SR-11).
- (b) Disconnect the steering sensor connector.
- (c) Turn the ignition switch ON.

CHECK:

Measure the voltage between terminals 1 and 2 of the steering sensor connector.

OK:


Voltage: 10 – 14 V



Check and repair harness and connectors between battery and steering sensor.

OK

3 Check steering sensor.

**PREPARATION:**

Apply battery positive voltage in between terminals 1 and 2.

CHECK:

Measure the resistance between terminal 2 and terminals 7 and 8 of the steering sensor connector when the rotating part of the steering sensor is turned slowly.

OK:

Changes between 0 Ω and $\infty \Omega$

NG

Replace steering sensor.

OK

4 Check harness and connectors between absorber control ECU and steering sensor (See page [IN-31](#)).

NG

Repair or replace harness or connector.

OK

Check and replace absorber control ECU.