


<b>DTC</b>	<b>B1412/12</b>	<b>Ambient Temperature Sensor Circuit</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION

This sensor detects the ambient temperature and sends the appropriate signals to the A/C control assembly.

DTC No.	Detection Item	Trouble Area
B1412/12	Open or short in ambient temperature sensor circuit.	<ul style="list-style-type: none"> <li>● Ambient temperature sensor.</li> <li>● Harness or connector between ambient temperature sensor and A/C control assembly.</li> <li>● A/C control assembly.</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### HINT:

In case of using the hand-held tester, start the inspection step 1 and in case of not using the hand-held tester, start from step 2.


**1 Check ambient temp. sensor using hand-held tester.**

### PREPARATION:

Connect the hand-held tester to the DLC3.


### CHECK:

Check the ambient temp. sensor using DATA LIST.



**NG**

**2 Check voltage between terminals TAM and SG of A/C control assembly connector.**



### PREPARATION:

- Remove A/C control assembly with connectors still connected (See page [BO-79](#)).
- Turn ignition switch ON.

### CHECK:

Check voltage between terminals TAM and SG of A/C control assembly connector at each temperature .

### OK:


#### **Voltage**

**at 25 °C (77 °F) : 1.35 – 1.75 V**

**at 40 °C (104 °F) : 0.85 – 1.25 V**


### HINT:

As the temperature increases, the voltage decreases.



**OK**

**Proceed to the next circuit inspection shown on matrix chart (See page [DI-711](#)). However, if DTC B1412/12 is displayed, check and replace A/C control assembly.**

**3 Check ambient temperature sensor.****PREPARATION:**

Disconnect ambient temperature sensor connector.

**CHECK:**

Check resistance between terminals 1 and 2 of ambient temperature sensor connector at each temperature.

**OK:****Resistance**

at 25 °C (77 °F) : 1.6 – 1.8 kΩ

at 40 °C (104 °F) : 0.5 – 0.7 kΩ

**HINT:**

As the temperature increases, the resistance decreases.

**NG****Replace ambient temperature sensor.****OK****4 Check harness and connector between A/C control assembly and ambient temperature sensor (See page [IN-31](#)).****NG****Repair or replace harness or connector.****OK****Check and replace A/C control assembly.**