

## **SYMPTOM DIAGNOSIS**

**DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH  
ALL DOOR**

**ALL DOOR : Description**

INFOID:000000004929796

All doors do not lock/unlock using door lock and unlock switch.

**ALL DOOR : Diagnosis Procedure**

INFOID:000000004929797

### **1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT**

Check power supply and ground circuit.

Refer to [DLK-64, "BCM \(BODY CONTROL MODULE\) : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### **2.CHECK DOOR LOCK AND UNLOCK SWITCH**

Check door lock and unlock switch.

- Driver side: Refer to [DLK-67, "DRIVER SIDE : Component Function Check".](#)
- Passenger side: Refer to [DLK-69, "PASSENGER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### **3.CHECK DOOR SWITCH**

Check door switch.

Refer to [DLK-65, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

### **4.CHECK KEY SLOT**

Check key slot.

Refer to [DLK-96, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

### **5.CHECK DOOR LOCK ACTUATOR**

Check door lock actuator.

Refer to [DLK-71, "DRIVER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

### **6.CONFIRM THE OPERATION**

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident".](#)

NO >> GO TO 1.

**DRIVER SIDE**

# DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## DRIVER SIDE : Description

INFOID:000000004929798

A

Driver side door does not lock/unlock using door lock and unlock switch.

## DRIVER SIDE : Diagnosis Procedure

INFOID:000000004929799

B

### 1. CHECK DRIVER SIDE DOOR LOCK ACTUATOR

Check driver side door lock actuator.

Refer to [DLK-71. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

C

### 2. CONFIRM THE OPERATION

Confirm the operation again.

E

Is the result normal?

F

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

G

NO >> GO TO 1.

## PASSENGER SIDE

## PASSENGER SIDE : Description

INFOID:000000004929800

H

Passenger side door does not lock/unlock using door lock and unlock switch.

## PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004929801

I

### 1. CHECK DOOR LOCK ACTUATOR

J

Check passenger side door lock actuator.

Refer to [DLK-72. "PASSENGER SIDE : Component Function Check"](#).

K

Is the inspection result normal?

L

YES >> GO TO 2.

M

NO >> Repair or replace the malfunctioning parts.

### 2. CONFIRM THE OPERATION

N

Confirm the operation again.

O

Is the result normal?

P

YES >> Check intermittent incident. Refer to [GI-40. "Intermittent Incident"](#).

DLK

NO >> GO TO 1.

# DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

<SYMPTOM DIAGNOSIS>

[WITH SUPER LOCK]

## DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

### Description

INFOID:0000000004929802

All doors do not lock/unlock using Intelligent Key.

### Diagnosis Procedure

INFOID:0000000004929803

#### 1.CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Go to [DLK-266, "ALL DOOR : Diagnosis Procedure"](#).

#### 2.CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver.

Refer to [DLK-78, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-94, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5.CHECK KEY SLOT

Check key slot.

Refer to [DLK-96, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

#### 6.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

# DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

[WITH SUPER LOCK]

< SYMPTOM DIAGNOSIS >

## DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH FRONT DOOR

### FRONT DOOR : Description

INFOID:000000004929804

All doors do not lock/unlock using front side door request switch.

### FRONT DOOR : Diagnosis Procedure

INFOID:000000004929805

#### 1. CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Refer to [DLK-268, "Description"](#).

#### 2. CHECK "LOCK/UNLOCK BY I-KEY" SETTING IN "WORK SUPPORT"

Check "LOCK/UNLOCK BY I-KEY" in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "LOCK/UNLOCK BY I-KEY" in "WORK SUPPORT".

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

## DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000004929806

All doors do not lock/unlock using driver side door request switch.

### DRIVER SIDE : Diagnosis Procedure

INFOID:000000004929807

#### 1. CHECK DRIVER SIDE DOOR REQUEST SWITCH

Check driver side door request switch.

Refer to [DLK-83, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (driver side).

Refer to [DLK-89, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check Intermittent Incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

## PASSENGER SIDE

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

[WITH SUPER LOCK]

< SYMPTOM DIAGNOSIS >

PASSENGER SIDE : Description

INFOID:000000004929808

All doors do not lock/unlock using passenger side door request switch.

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004929809

## 1. CHECK PASSENGER SIDE DOOR REQUEST SWITCH

Check passenger side door request switch.

Refer to [DLK-83, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

## 2. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (passenger side).

Refer to [DLK-89, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

## 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check Intermittent Incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

< SYMPTOM DIAGNOSIS >

**SUPER LOCK DOES NOT OPERATE**  
**ALL DOOR**

ALL DOOR : Diagnosis Procedure

INFOID:000000004929810

### 1. CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Refer to [DLK-268, "Diagnosis Procedure"](#).

### 2. CHECK DRIVER SIDE SUPER LOCK ACTUATOR

Check driver side super lock actuator.

Refer to [DLK-73, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

**DRIVER SIDE**

DRIVER SIDE : Diagnosis Procedure

INFOID:000000004929811

### 1. CHECK DRIVER SIDE SUPER LOCK ACTUATOR

Check driver side super lock actuator.

Refer to [DLK-73, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

**PASSENGER SIDE**

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000004929812

### 1. CHECK PASSENGER SIDE SUPER LOCK ACTUATOR

Check passenger side super lock actuator.

Refer to [DLK-74, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

## **SUPER LOCK DOES NOT OPERATE**

**< SYMPTOM DIAGNOSIS >**

**[WITH SUPER LOCK]**

**NO      >> GO TO 1.**

# ANTI-HIJACK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## ANTI-HIJACK FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000004963035

#### 1. CHECK "DOOR LOCK-UNLOCK SET" SETTING IN "WORK SUPPORT"

Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".

Refer to [DLK-52, "DOOR LOCK : CONSULT-III Function \(BCM - DOOR LOCK\)".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "DOOR LOCK-UNLOCK SET" in "WORK SUPPORT".

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident".](#)

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# TRUNK LID DOES NOT OPEN WITH TRUNK LID OPENER SWITCH

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## TRUNK LID DOES NOT OPEN WITH TRUNK LID OPENER SWITCH

### Description

INFOID:000000004929821

#### NOTE:

Check trunk lid opener switch operation in the trunk lid open condition. Refer to .

### Diagnosis Procedure

INFOID:000000004929822

#### 1. CHECK TRUNK LID OPENER SWITCH

Check trunk lid opener switch.

Refer to [DLK-81, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK TRUNK LID OPENER ACTUATOR

Check trunk lid opener actuator.

Refer to [DLK-85, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK TRUNK LID OPENER CANCEL SWITCH

Check trunk lid opener cancel switch.

Refer to [DLK-87, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

&lt; SYMPTOM DIAGNOSIS &gt;

## TRUNK LID DOES NOT OPEN WITH INTELLIGENT KEY

### Description

INFOID:0000000004929823

**NOTE:**

Check Intelligent Key remote operation with trunk lid open condition. Refer to .

### Diagnosis Procedure

INFOID:0000000004929824

#### 1. CHECK TRUNK LID OPEN FUNCTION

Check trunk lid open function with trunk lid opener switch.

Does trunk lid open with trunk lid opener switch?

YES &gt;&gt; GO TO 2.

NO >> Refer to [DLK-274, "Diagnosis Procedure"](#).

#### 2. CHECK "TRUNK OPEN DELAY" SETTING IN "WORK SUPPORT"

Check "TRUNK OPEN DELAY" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)"](#).Is the inspection result normal?

YES &gt;&gt; GO TO 3.

NO &gt;&gt; Set "TRUNK OPEN DELAY" setting in "WORK SUPPORT".

#### 3. CHECK TRUNK LID OPEN FUNCTION 2

Check trunk lid open function with Intelligent Key.

Does trunk lid open with Intelligent Key?

YES &gt;&gt; GO TO 5.

NO &gt;&gt; GO TO 4.

#### 4. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-94, "Component Function Check"](#).Is the inspection result normal?

YES &gt;&gt; GO TO 5.

NO &gt;&gt; Repair or replace the malfunctioning parts.

#### 5. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO &gt;&gt; GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

## TRUNK LID DOES NOT OPEN WITH TRUNK LID OPENER REQUEST SWITCH

### Description

INFOID:000000004929825

#### NOTE:

Check trunk lid opener request switch operation in the trunk lid open condition. Refer to

### Diagnosis Procedure

INFOID:000000004929826

#### 1. CHECK TRUNK LID OPEN FUNCTION

Check trunk lid open function with Intelligent Key.

##### Does trunk lid open with Intelligent Key?

YES >> GO TO 2.

NO >> Refer to [DLK-268, "Diagnosis Procedure"](#).

#### 2. CHECK TRUNK LID OPENER REQUEST SWITCH

Check trunk lid opener request switch.

Refer to [DLK-85, "Component Function Check"](#).

##### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK INSIDE KEY ANTENNA (TRUNK ROOM)

Check inside key antenna (trunk room).

Refer to [DLK-62, "DTC Logic"](#).

##### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK OUTSIDE KEY ANTENNA (REAR BUMPER)

Check outside key antenna (rear bumper).

Refer to [DLK-89, "Component Function Check"](#).

##### Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5. CONFIRM THE OPERATION

Confirm the operation again.

##### Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

# HAZARD REMINDER OPERATION DOES NOT OPERATE

[WITH SUPER LOCK]

< SYMPTOM DIAGNOSIS >

## HAZARD REMINDER OPERATION DOES NOT OPERATE

### Description

INFOID:0000000004929827

#### NOTE:

Before performing the diagnosis, check the operation condition. Refer to

### Diagnosis Procedure

INFOID:0000000004929828

#### 1. CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

Check the "HAZARD ANSWER BACK" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set the "HAZARD ANSWER BACK" setting in "WORK SUPPORT".

#### 2. CHECK HAZARD WARNING LAMP

Check hazard warning lamp.

Refer to [DLK-102, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident".](#)

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

< SYMPTOM DIAGNOSIS >

## KEY REMINDER FUNCTION DOES NOT OPERATE INTELLIGENT KEY SYSTEM

### INTELLIGENT KEY SYSTEM : Diagnosis Procedure

INFOID:000000004992870

#### 1. CHECK "ANTI KEY LOCK IN FUNCTI" SETTING IN "WORK SUPPORT"

Check "ANTI KEY LOCK IN FUNCTI" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "ANTI KEY LOCK IN FUNCTI" setting in "WORK SUPPORT".

#### 2. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-65, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK TRUNK ROOM LAMP SWITCH

Check trunk room lamp switch.

Refer to [DLK-438, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-58, "DTC Logic".](#)
- Console: Refer to [DLK-60, "DTC Logic".](#)
- Trunk room: Refer to [DLK-62, "DTC Logic".](#)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5. CHECK UNLOCK SENSOR

Check unlock sensor.

Refer to [DLK-440, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

#### 6. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident".](#)

NO >> GO TO 1.

## POWER DOOR LOCK SYSTEM

### POWER DOOR LOCK SYSTEM : Diagnosis Procedure

INFOID:000000004992872

#### 1. CHECK KEY SLOT

Check key slot.

Refer to [DLK-96, "Component Function Check".](#)

Is the inspection result normal?

# KEY REMINDER FUNCTION DOES NOT OPERATE

[WITH SUPER LOCK]

< SYMPTOM DIAGNOSIS >

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

A

## 2. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

B

YES >> GO TO 3.

C

NO >> Repair or replace the malfunctioning parts.

## 3. CONFIRM THE OPERATION

Confirm the operation again.

D

Is the result normal?

E

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

F

NO >> GO TO 1.

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

AA

BB

CC

DD

EE

FF

GG

HH

II

JJ

KK

LL

MM

NN

OO

PP

QQ

RR

SS

TT

UU

VV

WW

XX

YY

ZZ

AA

## KEY WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000004929832

#### 1. CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK KEY SLOT

Check key slot.

Refer to [DLK-96, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5. CHECK KEY SLOT INDICATOR

Check key slot illumination.

Refer to [DLK-98, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

#### 6. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

# OFF POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## OFF POSITION WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000004929834

#### 1. CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check BCM for DTC? Refer to [DLK-229, "FOR EUROPE : DTC Index"](#).

#### 2. CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# P POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## P POSITION WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000004929836

#### 1. CHECK DETENTION SWITCH

Check BCM for DTC?

Refer to [DLK-229, "FOR EUROPE : DTC Index"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to the following items.

- [DLK-58, "DTC Logic"](#) (instrument center)
- [DLK-60, "DTC Logic"](#) (console)
- [DLK-62, "DTC Logic"](#) (trunk room)

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

#### 6. CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

#### 7. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

## ACC WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000004929838

#### 1. CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check DTC for BCM. Refer to [DLK-229, "FOR EUROPE : DTC Index"](#).

#### 2. CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK COMBINATION METER DISPLAY FUNCTION

Check combination meter display function.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

TAKE AWAY WARNING DOES NOT OPERATE  
DOOR IS OPEN

DOOR IS OPEN : Description

INFOID:000000004929839

When door opens, take away warning does not operate.

DOOR IS OPEN : Diagnosis Procedure

INFOID:000000004929840

## 1. CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check DTC for BCM. Refer to [DLK-229, "FOR EUROPE : DTC Index"](#).

## 2. CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

## 3. CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

## 4. CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

## 5. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

## 6. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to the following items.

- [DLK-58, "DTC Logic"](#) (instrument center)
- [DLK-60, "DTC Logic"](#) (console)
- [DLK-62, "DTC Logic"](#) (trunk room)

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

## 7. CHECK KEY SLOT INDICATOR

Check key slot illumination.

Refer to [DLK-98, "Component Function Check"](#).

Is the inspection result normal?

# TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

YES >> GO TO 8.

NO >> Repair or replace the malfunctioning parts.

## 8.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

## ANY DOOR OPEN TO ALL DOORS CLOSED

### ANY DOOR OPEN TO ALL DOORS CLOSED : Description

INFOID:000000004929841

When key is outside of vehicle, and door opens and then closes, take away warning does not operate.

### ANY DOOR OPEN TO ALL DOORS CLOSED : Diagnosis Procedure

INFOID:000000004929842

#### 1.CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to the following items.

- [DLK-58, "DTC Logic"](#) (instrument center)
- [DLK-60, "DTC Logic"](#) (console)
- [DLK-62, "DTC Logic"](#) (trunk room)

DLK

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CHECK KEY SLOT INDICATOR

Check key slot indicator.

Refer to [DLK-98, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

## PUSH-BUTTON IGNITION SWITCH OPERATION

### PUSH-BUTTON IGNITION SWITCH OPERATION : Description

INFOID:000000004929843

When Intelligent Key is inside vehicle and not detected, take away warning does not sound due to push-button ignition switch operation.

# TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

PUSH-BUTTON IGNITION SWITCH OPERATION : Diagnosis Procedure

INFOID:000000004929844

## 1. CHECK POWER POSITION

Check if ignition switch position is changing or not.

Does ignition switch position change?

YES >> GO TO 2.

NO >> Check DTC for BCM. Refer to [DLK-229, "FOR EUROPE : DTC Index"](#).

## 2. CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [SEC-61, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

## 3. CHECK BUZZER (COMBINATION METER)

Check buzzer (combination meter).

Refer to [DLK-101, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

## 4. CHECK KEY SLOT INDICATOR

Check key slot indicator.

Refer to [DLK-98, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

## 5. CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

## 6. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to the following items.

- [DLK-58, "DTC Logic"](#) (instrument center)
- [DLK-60, "DTC Logic"](#) (console)
- [DLK-62, "DTC Logic"](#) (trunk room)

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

## 7. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

## INTELLIGENT KEY IS REMOVED FROM KEY SLOT

INTELLIGENT KEY IS REMOVED FROM KEY SLOT : Description

INFOID:000000004929845

When Intelligent Key is removed from key slot, key slot does not blink.

# TAKE AWAY WARNING DOES NOT OPERATE

[WITH SUPER LOCK]

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY IS REMOVED FROM KEY SLOT : Diagnosis Procedure

INFOID:000000004929846

## 1. CHECK KEY SLOT

Check key slot.

Refer to [DLK-96, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

## 2. CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

## 3. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to the following items.

- [DLK-58, "DTC Logic" \(instrument center\)](#)
- [DLK-60, "DTC Logic" \(console\)](#)
- [DLK-62, "DTC Logic" \(trunk room\)](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

## 4. CHECK KEY SLOT INDICATOR

Check key slot indicator.

Refer to [DLK-98, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

## 5. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

< SYMPTOM DIAGNOSIS >

# INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

## Diagnosis Procedure

INFOID:0000000004929848

### 1. CHECK "LO- BATT OF KEY FOB WARN" SETTING IN "WORK SUPPORT"

Check the "LO- BATT OF KEY FOB WARN" setting in "WORK SUPPORT".

Refer to [DLK-53, "INTELLIGENT KEY : CONSULT-III Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set the "LO- BATT OF KEY FOB WARN" setting in "WORK SUPPORT".

### 2. CHECK INTELLIGENT KEY BATTERY

Check Intelligent Key battery.

Refer to [DLK-94, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3. CHECK COMBINATION METER DISPLAY

Check combination meter display.

Refer to [DLK-100, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

### 4. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to the following items.

- [DLK-58, "DTC Logic" \(instrument center\)](#)
- [DLK-60, "DTC Logic" \(console\)](#)
- [DLK-62, "DTC Logic" \(trunk room\)](#)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

### 5. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident".](#)

NO >> GO TO 1.

# DOOR LOCK OPERATION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## DOOR LOCK OPERATION WARNING DOES NOT OPERATE WITH DOOR REQUEST SWITCH

### WITH DOOR REQUEST SWITCH : Description

INFOID:000000004929849

Door lock operation warning does not activate using door request switch.

### WITH DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000004929850

#### 1. CHECK DOOR LOCK FUNCTION

Check door lock function using door request switch.

Does door lock/unlock with door request switch?

YES >> GO TO 2.

NO-1 >> Go to [DLK-269, "DRIVER SIDE : Description"](#) (driver side).

NO-2 >> Go to [DLK-270, "PASSENGER SIDE : Description"](#) (passenger side).

#### 2. CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch.

Refer to [DLK-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

Refer to the following items.

- [DLK-58, "DTC Logic"](#) (instrument center)
- [DLK-60, "DTC Logic"](#) (console)
- [DLK-62, "DTC Logic"](#) (trunk room)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

### WITH INTELLIGENT KEY

#### WITH INTELLIGENT KEY : Description

INFOID:000000004929851

Door lock operation warning does not activate using Intelligent Key.

#### WITH INTELLIGENT KEY : Diagnosis Procedure

INFOID:000000004929852

#### 1. CHECK DOOR LOCK OPERATION WARNING FUNCTION

Check door lock operation warning activate using door request switch.

Does door lock operation warning activate with door request switch?

YES >> GO TO 2.

# DOOR LOCK OPERATION WARNING DOES NOT OPERATE

[WITH SUPER LOCK]

< SYMPTOM DIAGNOSIS >

NO >> Refer to [DLK-289, "WITH DOOR REQUEST SWITCH : Diagnosis Procedure".](#)

## 2. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-94, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

## 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident".](#)

NO >> GO TO 1.

## KEY ID WARNING DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000004929854

#### 1. CHECK INTELLIGENT KEY

Check Intelligent Key.

Refer to [DLK-94, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK COMBINATION METER DISPLAY FUNCTION

Check combination meter display function.

Refer to [DLK-100, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

# FUEL LID LOCK ACTUATOR DOES NOT OPERATE

<SYMPTOM DIAGNOSIS>

[WITH SUPER LOCK]

## FUEL LID LOCK ACTUATOR DOES NOT OPERATE

### Diagnosis Procedure

INFOID:0000000004929855

#### 1.CHECK FUEL LID LOCK ACTUATOR CIRCUIT

Check fuel lid opener actuator circuit.

Refer to [DLK-75, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-40, "Intermittent Incident"](#).

NO >> GO TO 1.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## SQUEAK AND RATTLE TROUBLE DIAGNOSES

### Work Flow

INFOID:0000000004929856



### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of the customer's comments; refer to [DLK-297, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by a test drive with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumble bee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DLK

### DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

## [WITH SUPER LOCK]

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
- 2) Tap or push/pull around the area where the noise appears to be coming from.
- 3) Rev the engine.
- 4) Use a floor jack to recreate vehicle "twist".
- 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
- 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.

- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
- If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Engine Ear or mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - Removing the components in the area that is suspected to be the cause of the noise.  
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
  - Tapping or pushing/pulling the component that is suspected to be the cause of the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - Feeling for a vibration by hand by touching the component(s) that are suspected to be the cause of the noise.
  - Placing a piece of paper between components that are suspected to be the cause of the noise.
  - Looking for loose components and contact marks.  
Refer to [DLK-295, "Inspection Procedure"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - Separate components by repositioning or loosening and retightening the component, if possible.
  - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. These insulators are available through the authorized Nissan Parts Department.

### CAUTION:

**Never use excessive force as many components are constructed of plastic and may be damaged.**

### NOTE:

- URETHANE PADS  
Insulates connectors, harness, etc.
- INSULATOR (Foam blocks)  
Insulates components from contact. Can be used to fill space behind a panel.
- INSULATOR (Light foam block)
- FELT CLOTHTAPE  
Used to insulate where movement does not occur. Ideal for instrument panel applications.  
The following materials, not available through NISSAN Parts Department, can also be used to repair squeaks and rattles.
- UHMW(TEFLON) TAPE  
Insulates where slight movement is present. Ideal for instrument panel applications.
- SILICONE GREASE  
Used in place of UHMW tape that is be visible or does not fit.  
Note: Will only last a few months.
- SILICONE SPRAY  
Used when grease cannot be applied.
- DUCT TAPE  
Used to eliminate movement.

## CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## Inspection Procedure

INFOID:000000004929857

Refer to Table of Contents for specific component removal and installation information.

### INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

#### CAUTION:

**Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.**

### CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

### DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. The areas can usually be insulated with felt cloth tape or insulator foam blocks to repair the noise.

### TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for the following:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. Trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## SEATS

When isolating seat noise it is important to note the position the seat is in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. Rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

## UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## Diagnostic Worksheet

INFOID:000000004929858



### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.

A

B

C

D

E

F

G

H

I

J

DLK





L

M

N

O

P



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8740E

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH SUPER LOCK]

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

---

---

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

<input type="checkbox"/> anytime	<input type="checkbox"/> after sitting out in the rain
<input type="checkbox"/> 1st time in the morning	<input type="checkbox"/> when it is raining or wet
<input type="checkbox"/> only when it is cold outside	<input type="checkbox"/> dry or dusty conditions
<input type="checkbox"/> only when it is hot outside	<input type="checkbox"/> other:

### III. WHEN DRIVING:

<input type="checkbox"/> through driveways	<input type="checkbox"/> squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> over rough roads	<input type="checkbox"/> creak (like walking on an old wooden floor)
<input type="checkbox"/> over speed bumps	<input type="checkbox"/> rattle (like shaking a baby rattle)
<input type="checkbox"/> only about _____ mph	<input type="checkbox"/> knock (like a knock at the door)
<input type="checkbox"/> on acceleration	<input type="checkbox"/> tick (like a clock second hand)
<input type="checkbox"/> coming to a stop	<input type="checkbox"/> thump (heavy, muffled knock noise)
<input type="checkbox"/> on turns: left, right or either (circle)	<input type="checkbox"/> buzz (like a bumble bee)
<input type="checkbox"/> with passengers or cargo	
<input type="checkbox"/> other: _____	
<input type="checkbox"/> after driving _____ miles or _____ minutes	

### IV. WHAT TYPE OF NOISE

<input type="checkbox"/> squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> creak (like walking on an old wooden floor)
<input type="checkbox"/> rattle (like shaking a baby rattle)
<input type="checkbox"/> knock (like a knock at the door)
<input type="checkbox"/> tick (like a clock second hand)
<input type="checkbox"/> thump (heavy, muffled knock noise)
<input type="checkbox"/> buzz (like a bumble bee)

### TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

---

---

---

YES	NO	Initials of person performing
-----	----	-------------------------------

Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: \_\_\_\_\_ Customer Name: \_\_\_\_\_  
W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

PIIB8742E