

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

FOR EUROPE

FOR EUROPE : Reference Value

INFOID:000000004991292

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper volume dial is in a dial position 1 - 7	Wiper volume dial position
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
RR FOG SW NOTE: At models without rear fog lamp this item is not monitored.	Rear fog lamp switch OFF	Off
	Rear fog lamp switch ON	On
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
DOOR SW-RL	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	Off
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL UN-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
H/L WASH SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	Trunk lid opener cancel switch OFF	Off
	Trunk lid opener cancel switch ON	On
TR/BD OPEN SW	Trunk lid opener switch OFF	Off
	While the trunk lid opener switch is turned ON	On
TRNK/HAT MNTR	Trunk lid closed	Off
	Trunk lid opened	On
SEN CANCEL SW	Sensor cancel switch is not pressed	Off
	Sensor cancel switch is pressed	On
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off
	LOCK button of the Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed	On
RKE-TR/BD	TRUNK OPEN button of the Intelligent Key is not pressed	Off
	TRUNK OPEN button of the Intelligent Key is pressed	On
RKE-PANIC	NOTE: The item is indicated, but not monitored.	Off
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	NOTE: The item is indicated, but not monitored.	0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Trunk lid opener request switch is not pressed	Off
	Trunk lid opener request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Shift lever in P position	Off
	Shift lever in any position other than P	On
SFT PN/N SW	Shift lever in any position other than P and N	Off
	Shift lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Shift lever in any position other than P	Off
	Shift lever in P position	On
SFT PN -IPDM	Shift lever in any position other than P and N	Off
	Shift lever in P or N position	On
SFT P -MET	Shift lever in any position other than P	Off
	Shift lever in P position	On
SFT N -MET	Shift lever in any position other than N	Off
	Shift lever in N position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off
	Steering lock system are not the LOCK condition or the changing condition from LOCK to UNLOCK	On
VEH SPEED 1	While driving	Equivalent to speed-ometer reading
VEH SPEED 2	While driving	Equivalent to speed-ometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off
	The Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT




PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	—				
1 (GR)* ¹ (W)* ²	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (R)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	12 V
3 (W)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	12 V
4 (R)* ¹ (O)* ²	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)	12 V
5 (L)	Ground	Super lock	Output	Super lock ac- tuator	Actuator is activated 0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON 0 V
					OFF 12 V
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated) 12 V
					Other than LOCK (Actuator is not activated) 0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated) 12 V
					Other than UNLOCK (Actuator is not activated) 0 V
10 (G)* ¹ (P)* ²	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated) 12 V
					Other than UNLOCK (Actuator is not activated) 0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (P)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF 0 V
					ON NOTE: When the illumination bright- ening/dimming level is in the neutral position.
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated) Battery voltage
					ACC 0 V



JSNIA0010GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
17 (W)	Ground	Turn signal RH (Front and side)	Output	Turn signal switch OFF Turn signal switch RH
				0 V  PKID0926E 6.5 V
18 (O)	Ground	Turn signal LH (Front and side)	Output	Turn signal switch OFF Turn signal switch LH
				0 V  PKID0926E 6.5 V
19 (V)* ¹ (GR)* ²	Ground	Room lamp timer control	Output	Interior room lamp OFF ON
				12 V 0 V
20 (SB)* ¹ (V)* ²	Ground	Turn signal RH (Rear)	Output	Turn signal switch OFF Turn signal switch RH
				0 V  PKID0926E 6.5 V
23 (G)	Ground	Trunk lid open	Output	Trunk lid OPEN (Trunk lid opener actuator is activated) Other than OPEN (Trunk lid opener actuator is not activated)
				12 V 0 V
24 (R)	Ground	Rear fog lamp	Output	Rear fog lamp OFF ON
				0 V 12 V
25 (V)* ¹ (SB)* ²	Ground	Turn signal LH (Rear)	Output	Ignition switch ON Turn signal switch OFF Turn signal switch LH
				0 V  PKID0926E 6.5 V

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 PWC
 L
 M
 N
 O
 P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
30 (O) ^{*1} (L) ^{*2}	Ground	Trunk room lamp	Output	ON
				OFF
34 (P)	Ground	Trunk room antenna (-)	Output	When Intelligent Key is in the passenger compart- ment
				When Intelligent Key is not in the passenger compart- ment
35 (L)	Ground	Trunk room antenna (+)	Output	When Intelligent Key is in the passenger compart- ment
				When Intelligent Key is not in the passenger compart- ment




JMKIA0062GB



JMKIA0063GB



JMKIA0062GB



JMKIA0063GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
38 (R)* ¹ (G)* ²	Ground	Rear bumper antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the trunk lid opener request switch is operated with ignition switch OFF
39 (BR)* ¹ (R)* ²	Ground	Rear bumper antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the trunk lid opener request switch is operated with ignition switch OFF
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	OFF or ACC
				ON
50 (R)* ¹ (BR)* ²	Ground	Trunk room lamp switch	Input	OFF (Trunk lid is closed)
				ON (Trunk lid is opened)
52 (SB)	Ground	Starter relay control	Output	When shift lever is in P or N position
				When shift lever is not in P or N position

A

B

C

D

E

F

G

H

J

PWC


L

M


N

O


P




JMKIA0062GB




JMKIA0063GB



JMKIA0062GB




JMKIA0063GB




JPMIA0011GB


11.8 V



0 V



12 V




0 V

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
61 (W)	Ground	Trunk lid opener re- quest switch	Input	ON (Pressed)
				OFF (Not pressed)
64 (O) ^{*1} (GR) ^{*2}	Ground	Intelligent Key warn- ing buzzer (Engine room)	Output	Sounding
				Not sounding
67 (G) ^{*1} (O) ^{*2}	Ground	Trunk lid opener switch	Input	Pressed
				Not pressed
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	When Intelligent Key is in the passenger compart- ment
				When Intelligent Key is not in the passenger compart- ment




JPMIA0016GB

1.0 V




JPMIA0011GB

11.8 V







JMKIA0062GB



JMKIA0063GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				 (V) 15 10 5 0 1 s JMKIA0062GB
74 (SB)	Ground	Passenger door an- tenna (-)	Output When the pas- senger door re- quest switch is operated with ignition switch OFF	When Intelligent Key is not in the passenger compart- ment
				 (V) 15 10 5 0 1 s JMKIA0063GB
75 (BR)	Ground	Passenger door an- tenna (+)	Output When the pas- senger door re- quest switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area
				 (V) 15 10 5 0 1 s JMKIA0062GB
				When Intelligent Key is not in the antenna detection area
				 (V) 15 10 5 0 1 s JMKIA0063GB

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment
				Ignition switch OFF
				When Intelligent Key is not in the passenger compartment




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB







JMKIA0062GB



JMKIA0063GB

BCM (BODY CONTROL MODULE)



< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	<p>When Intelligent Key is in the passenger compartment</p>  <p>JMKIA0062GB</p>
80 (GR)	Ground	NATS antenna amp.	Input/ Output	<p>Ignition switch OFF</p> <p>When Intelligent Key is not in the passenger compartment</p>  <p>JMKIA0063GB</p>
81 (L)* ¹ (W)* ²	Ground	NATS antenna amp.	Input/ Output	<p>Ignition switch is pressed while inserting the Intelligent Key into the key slot.</p> <p>Just after pressing ignition switch. Pointer of tester should move.</p>
82 (R)* ¹ (SB)* ²	Ground	Ignition relay [Fuse block (J/B)] control	Output	<p>OFF or ACC</p> <p>ON</p>
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	<p>During waiting</p>  <p>JMKIA0064GB</p>
84 (GR)	Ground	Dimmer signal	Output	<p>When operating either button on the Intelligent Key</p>  <p>JMKIA0065GB</p>

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P
PWC






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	+	-		
Signal name	Input/ Output			
85 (V)	Ground	Alarm link	Vehicle securi- ty system	Disarmed phase
				Pre-armed phase or armed phase
86 (BR)	Ground	Dongle link	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.
				Just after pressing ignition switch. Pointer of tester should move.
87 (BR)	Ground	Combination switch INPUT 5	Combination switch	All switches OFF (Wiper volume dial 4)
				 1.4 V
				 1.3 V
				Any of the conditions be- low with all switches OFF • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 6 • Wiper volume dial 7
				 1.3 V



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P	
	Signal name	Input/ Output				
+	-					
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper volume dial 4)	 1.4 V JPMIA0041GB
					Lighting switch HI (Wiper volume dial 4)	 1.3 V JPMIA0036GB
					Lighting switch 2ND (Wiper volume dial 4)	 1.3 V JPMIA0037GB
					Any of the conditions below with all switches OFF • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 3	 1.3 V JPMIA0040GB
89 (BR)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ig- nation switch (Push switch)	Pressed	0 V
					Not pressed	12 V
90 (P)	Ground	CAN-L	Input/ Output		—	—
91 (L)	Ground	CAN-H	Input/ Output		—	—
92 (LG)	Ground	Key slot illumination	Output	Key slot illumin- ation	OFF	12 V
					Blinking	 6.5 V JPMIA0015GB
					ON	0 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	+	-				
93 (V)	Ground	ON indicator lamp	Output	Ignition switch		
					OFF (LOCK indicator is not illuminated)	Battery voltage
					ON	0 V
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
96 (SB)	Ground	A/T shift selector (Detention switch) power supply	Output		—	12 V
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	12 V
98 (R) ^{*1} (P) ^{*2}	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	12 V
					UNLOCK status	0 V
99 (G)	Ground	Shift lever P position switch	Input	Shift lever	P position	0 V
					Any position other than P	12 V
100 (W)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> <small>1.0 V</small>
101 (V) ^{*1} (W) ^{*2}	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> <small>1.0 V</small>
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		12 V
106 (P) ^{*1} (V) ^{*2}	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J L M N O P PWC
	Signal name	Input/ Output			
+	-				
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper volume dial 4)	All switches OFF	 1.4 V JPMIA0041GB
				Turn signal switch LH	 1.3 V JPMIA0037GB
				Turn signal switch RH	 1.3 V JPMIA0036GB
				Front wiper switch LO	 1.3 V JPMIA0038GB
				Front washer switch ON	 1.3 V JPMIA0039GB






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (R)	Ground	Combination switch INPUT 4	Input	 All switches OFF (Wiper volume dial 4)  Lighting switch AUTO (Wiper volume dial 4)  Lighting switch 1ST (Wiper volume dial 4)  Any of the conditions below with all switches OFF • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6
				JPMIA0041GB 1.4 V
				JPMIA0038GB 1.3 V
				JPMIA0036GB 1.3 V
				JPMIA0039GB 1.3 V



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J L M N O P
	Signal name	Input/ Output			
109 (Y)	Ground	Combination switch INPUT 2	Combination switch (Wiper volume dial 4)	All switches OFF	 1.4 V JPMIA0041GB
				Lighting switch PASS	 1.3 V JPMIA0037GB
				Lighting switch 2ND	 1.3 V JPMIA0036GB
				Front wiper switch INT/ AUTO	 1.3 V JPMIA0038GB
				Front wiper switch HI	 1.3 V JPMIA0040GB
110 (G)	Ground	Hazard switch	Hazard switch	ON	0 V
				OFF	 1.1 V JPMIA0012GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
111 (Y)	Ground	Steering lock unit communication	Input/ Output	LOCK status
				LOCK or UNLOCK
				(V)  JMKA0066GB
				For 15 seconds after UN-LOCK 12 V
112 (GR)	Ground	Light and rain sensor serial link	Input/ Output	15 seconds or later after UNLOCK 0 V
				Ignition switch ON
				(V)  JPMIA0156GB 8.7 V
				—
116 (SB)	Ground	Stop lamp switch 1	Input	Battery voltage
117 (G)	Ground	Sensor cancel switch	Input	Sensor cancel switch
				OFF (Not pressed) 1.1 V
118 (P)* ¹ (BR)* ²	Ground	Stop lamp switch 2	Input	OFF (Brake pedal is not depressed) 0 V
				ON (Brake pedal is depressed)
				Battery voltage
				—
119 (SB)	Ground	Driver side door lock assembly (Unlock sensor)	Input	Driver door
				LOCK status (Unlock sensor switch OFF) 1.1 V
				UNLOCK status (Unlock switch sensor ON) 0 V

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
121 (R)	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot
				12 V
				0 V
123 (BR) ^{*1} (W) ^{*2}	Ground	IGN feedback	Input	OFF or ACC
				0 V
				Battery voltage
124 (LG)	Ground	Passenger door switch	Input	OFF (Door close)
				 11.8 V
				0 V
128 (P) ^{*1} (GR) ^{*2}	Ground	Door lock and unlock switch LOCK	Input	NEUTRAL position
				 11.8 V
				0 V
129 (O)	Ground	Trunk lid opener cancel switch	Input	CANCEL
				 1.1 V
				0 V
131 (BR)	Ground	Door lock and unlock switch UNLOCK	Input	NEUTRAL position
				 11.8 V
				0 V

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
133 (W) ^{*1} (L) ^{*2}	Ground	Push-button ignition switch illumination	Output	ON (Tail lamps OFF)
				NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.
				 JPMIA0159GB
134 (GR) ^{*1} (R) ^{*2}	Ground	LOCK indicator lamp	Output	ON (Tail lamps ON)
				OFF
137 (L)	Ground	Receiver ground	Input	Ignition switch ON
140 (BR)	Ground	Shift lever P/N position	Input	OFF
				Battery voltage
				0 V
141 (G)	Ground	Security indicator	Output	ON
				 JPMIA0014GB
				11.3 V
142 (O)	Ground	Combination switch OUTPUT 5	Output	OFF
				Battery voltage
				0 V
				All switches OFF
				Lighting switch 1ST
	Ground	Combination switch (Wiper volume dial 4)	Output	Lighting switch HI
				Lighting switch 2ND
				Turn signal switch RH
				 JPMIA0031GB
				10.7 V
143 (P)	Ground	Combination switch OUTPUT 1	Output	All switches OFF (Wiper volume dial 4)
				Front wiper switch HI (Wiper volume dial 4)
				Any of the conditions below with all switches OFF
				<ul style="list-style-type: none"> • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 3 • Wiper volume dial 6 • Wiper volume dial 7
	Ground	Combination switch OUTPUT 1	Output	 JPMIA0032GB
				10.7 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P	
	Signal name	Input/ Output				
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper volume dial 4)	0 V
					Front washer switch ON (Wiper volume dial 4)	
					Any of the conditions below with all switches OFF • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6	 JPMIA0033GB 10.7 V
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper volume dial 4)	All switches OFF	0 V
					Front wiper switch INT/ AUTO	
					Front wiper switch LO	
					Lighting switch AUTO	
					Rear fog lamp switch ON	 JPMIA0034GB 10.7 V
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper volume dial 4)	All switches OFF	0 V
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	 JPMIA0035GB 10.7 V
150 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	 JPMIA0011GB 11.8 V
					ON (Door open)	0 V
151 (G)	Ground	Rear window defogger relay control	Output	Rear window defogger	Active	0 V
					Not activated	Battery voltage


- *1: LHD models
- *2: RHD models

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


FOR EUROPE : Wiring Diagram - BCM (LHD models) -

INFOID:0000000004991293



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWA4568GB

PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


LR : With light & rain sensor



JCMWA4569GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMW4570GB

PWC

L

M

N

O


P

R

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMW4571GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (LHD MODELS)

Connector No.	M116
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4	1	GR	BAT (F.L.) (LHD models)
5	L	OUTPUT 3	2	R	POWER WINDOW POWER SUPPLY BAT
7	Y	INPUT 3	3	W	POWER WINDOW POWER SUPPLY (RAMP)
8	O	OUTPUT 5	4		
9	Y	INPUT 2	5		
10	R	INPUT 4	6		
11	LG	INPUT 1	7		
12	P	OUTPUT 1	8		
13	BR	INPUT 5	9		
14	G	OUTPUT 2	10		

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS15DFW-CS



Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG7-NH



Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	BAT (F.L.) (LHD models)	4	R	INTERIOR ROOM LAMP POWER SUPPLY (LHD models)
2	R	POWER WINDOW POWER SUPPLY BAT	5	L	SUPER LOCK OUTPUT
3	W	POWER WINDOW POWER SUPPLY (RAMP)	7	Y	STEP LAMP
4			8	V	ALL DOOR FUEL LID LOCK OUTPUT
5			9	G	DRIVER DOOR FUEL LID LOCK OUTPUT
6			10	G	PASSENGER DOOR UNLOCK OUTPUT (LHD models)
7			11	R	BA1 (FUSE)
8			13	B	GND
9			14	P	PUSH+BUTTON IGNITION SW/HL GND
10			15	Y	ACC IND
11			17	W	TURN SIGNAL RH (FRONT SIDE) OUTPUT

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
20	GR	TURN SIGNAL RH (FRONT SIDE) OUTPUT	34	P	TRUNK ROOM ANT-
21	SB	TRUNK LID OPEN OUTPUT	35	L	TRUNK ROOM ANT-
22	G	REAR FOG OUTPUT	36	R	REAR BUMPER ANT (LHD models)
23	R	TURN SIGNAL L/H (FRONT SIDE) OUTPUT	39	BR	REAR BUMPER ANT- (LHD models)
24			47	Y	IGN RELAY (PDM L/R) CONTROL
25	V	TRUNK ROOM LAMP OUTPUT (LHD models)	50	R	TRUNK ROOM LAMP SW (LHD models)
30	O	TRUNK ROOM LAMP OUTPUT (LHD models)	52	SB	STARTER RELAY CONTROL
31			61	W	TRUNK LID REQUEST SW
			64	O	KEYLESS ENTRY (LHD models)
			67	G	TRUNK LID OPENER SW (LHD models)

JCMWA3928GB

PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (LHD MODELS)		S/L UNIT COMM	
Connector No.	M122	83	Y KEYLESS ENTRY RECEIVER COMM
Connector Name	BCM (BODY CONTROL MODULE)	84	GR DIMMER SIGNAL
Connector Type	TH40F6B-NH	85	V ALARM LINK
		86	BR DONGLE LINK
		87	BR COMBI SW INPUT 5
		88	BR COMBI SW INPUT 3
		89	BR PUSH SW
		90	P CAN-L
		91	L KEY SLOT ILL OUTPUT
		92	LG ON IND
		93	V ACC RELAY CONT
		95	O A/T SHIFT SELECTOR POWER SUPPLY
		96	SB A/T SHIFT SELECTOR POWER SUPPLY
Terminal No.	Color of Wire	Signal Name [Specification]	S/L CONDITION 1
72	R	ROOM ANT2-	R S/L CONDITION 2 [LHD models]
73	G	ROOM ANT2+	G SHIFT P
74	SB	PASSENGER DOOR ANT-	W PASSENGER DOOR REQUEST SW
75	BR	PASSENGER DOOR ANT+	V DRIVER DOOR REQUEST SW (LHD models)
76	V	DRIVER DOOR ANT-	0 BLOWER FAN MOTOR CONTROL
77	LG	DRIVER DOOR ANT+	LG KEYLESS ENTRY RECEIVER POWER SUPPLY
78	Y	ROOM ANT1-	P S/L UNIT POWER SUPPLY [LHD models]
79	BR	ROOM ANT1+	LG COMBI SW INPUT 1
80	GR	IMMOBILANTENA SIGNAL CONTROL	R COMBI SW INPUT 4
81	L	IMMOBILANTENA SIGNAL (LHD models)	Y COMBI SW INPUT 2
82	R	IGN RELAY (F/B) CONT [LHD models]	G HAZARD SW
		110	G
		133	W Push-BUTTON CINTION SW [LHD models]
		134	GR LOCK IND (LHD models)
		137	L RECEIVER SND
		140	BR SHIFT N/P
		141	G SECURITY INDICATOR
		142	O COMBI SW OUTPUT 5
		143	P COMBI SW OUTPUT 1
		144	G COMBI SW OUTPUT 2
		145	L COMBI SW OUTPUT 3
		146	SB COMBI SW OUTPUT 4
		150	GR DRIVER DOOR SW
		151	G REAR WIND/DOOR DEFROGER RELAY CONT
Terminal No.	Color of Wire	Signal Name [Specification]	
112	GR	L& SENSOR SERIAL LINK	
116	SB	STOP LAMP SW 1	
117	G	SENSOR CANCEL SW	
118	P	STOP LAMP SW 2 (LHD models)	
119	SB	DR DOOR UNL. SENS	
121	R	KEY SLOT SW	
123	BR	[IGN F/B (LHD models)]	
124	LG	PASSENGER DOOR SW	
128	P	DOOR LOCK/UNLOCK SW/LOCK (LHD models)	
129	O	TRUNK CANCEL SW	
131	BR	DOOR LOCK/UNLOCK SW/UNLOCK	

JCMWA4572GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

FOR EUROPE : Wiring Diagram - BCM (RHD models) -

INFOID:000000004991294

BCM (BODY CONTROL MODULE) (RHD MODELS)



A B C D E F G H I J K L M N O P Q R S T U V W Z


PWC

2009/05/07

JCMWA4573GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMW4574GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

⟨LR⟩ : With light & rain sensor




JCMWA4575GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
PWC

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMW4576GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMW4577GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (RHD MODELS) (RHD MODELS)

Connector No.		M118
Connector Name	BCM (BODY CONTROL MODULE)	
Connector Type	MOSFB-LC	
		NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	SE	OUTPUT 4
2	L	OUTPUT 3
5	V	INPUT 3
7	O	OUTPUT 5
8	Y	INPUT 2
9	R	INPUT 4
10	LG	INPUT 1
11	P	OUTPUT 1
12	D	INPUT 5
13	BR	INPUT 2
14	G	OUTPUT 5

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L) (RHD models)
2	R	POWER WINDOW POWER SUPPLY/BAT
3	W	POWER WINDOW POWER SUPPLY/RAP

Terminal No.	Color of Wire	Signal Name [Specification]
4	W	INTERIOR ROOM LAMP POWER SUPPLY (RHD models)
5	O	SUPER LOCK OUTPUT
7	Y	STEP LAMP
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	P	PASSENGER DOOR UNLOCK OUTPUT (RHD models)
11	R	BAT (FUSE)
13	B	GRD
14	P	PUSH+BUTTON/GNITION SW/L GNID
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT SIDE) OUTPUT

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
20	W	TURN SIGNAL RH (REAR) OUTPUT (RHD models)
21	G	TRUNK ID OPEN OUTPUT
22	R	REAR FOG OUTPUT
23	S6	TURN SIGNAL LH (REAR) OUTPUT (RHD models)
24	S6	TURN SIGNAL RH (FRONT) OUTPUT (RHD models)
25	L	TRUNK ROOM LAMP OUTPUT (RHD models)
30	L	TRUNK ROOM LAMP SW (RHD models)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG7-NH



Terminal No.	Color of Wire	Signal Name [Specification]
34	P	TRUNK ROOM ANT-
35	L	TRUNK ROOM ANT+
36	Q	REAR BUMPER ANT- (RHD models)
39	R	REAR BUMPER ANT+ (RHD models)
47	Y	IGN RELAY (FDM/FR/CONT)
50	BR	TRUNK ROOM LAMP SW (RHD models)
52	SB	STARTER RELAY CONT
61	W	TRUNK ID REQUEST SW
64	GR	KEYLESS BUZZER END ROOM (RHD models)
67	O	TRUNK LID OPENER SW (RHD models)

JCMWA3935GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2196: DONGLE NG	Inhibit engine cranking	Erase DTC
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Shift lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Shift lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Shift lever P position switch signal: Except P position (battery voltage) • Shift lever P/N position signal: Except P and N positions (0 V)
B2604: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> Starter motor relay control signal Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> Inhibit engine cranking Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> BCM steering lock control status Steering lock condition No. 1 signal status Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> Power position changes to ACC Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> Inhibit engine cranking Inhibit steering lock 	When any of the following conditions are fulfilled <ul style="list-style-type: none"> Steering lock unit status signal (CAN) is received normally The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: BCM	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> Inhibit engine cranking Inhibit steering lock 	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> Steering condition No. 1 signal: LOCK (0 V) Steering condition No. 2 signal: LOCK (Battery voltage)

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

FAIL-SAFE CONTROL BY LIGHT AND RAIN SENSOR MALFUNCTION

BCM detects the light and rain sensor serial link error and the light and rain sensor malfunction.

BCM controls the following fail-safe when light and rain sensor has a malfunction.

Fail-safe Control

- Auto light control: Headlamp low beam, parking lamp, license plate lamp and tail lamp are turned ON.
- Front wiper control
 - Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
 - Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

FOR EUROPE : DTC Inspection Priority Chart

INFOID:0000000004991296

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT(CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING • B2196: DONGLE NG
4	<ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP/CLUTCH SW • B2605: PNP/CLUTCH SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2612: S/L STATUS • B2614: BCM • B2615: BCM • B2616: BCM • B2617: BCM • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E9: S/L STATUS • B26EA: KEY REGISTRATION • U0415: VEHICLE SPEED
5	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA
6	B26E7: TPMS CAN COMM

FOR EUROPE : DTC Index

INFOID:0000000004991297

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-20, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)".](#)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM	—	—	—	BCS-38
U1010: CONTROL UNIT(CAN)	—	—	—	BCS-39
U0415: VEHICLE SPEED	—	—	—	BCS-40
B2013: ID DISCORD BCM-S/L	×	×	—	SEC-55
B2014: CHAIN OF S/L-BCM	×	×	—	SEC-56
B2190: NATS ANTENNA AMP	×	—	—	SEC-45
B2191: DIFFERENCE OF KEY	×	—	—	SEC-48
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-49
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-51
B2195: ANTI SCANNING	×	—	—	SEC-52
B2196: DONGLE NG	×	—	—	SEC-53
B2553: IGNITION RELAY	—	×	—	PCS-50
B2555: STOP LAMP	—	×	—	SEC-59
B2556: PUSH-BTN IGN SW	—	×	×	SEC-61
B2557: VEHICLE SPEED	×	×	×	SEC-63
B2560: STARTER CONT RELAY	×	×	×	SEC-64
B2562: LOW VOLTAGE	—	×	—	BCS-41
B2601: SHIFT POSITION	×	×	×	SEC-65
B2602: SHIFT POSITION	×	×	×	SEC-68
B2603: SHIFT POSI STATUS	×	×	×	SEC-71
B2604: PNP/CLUTCH SW	×	×	×	SEC-73
B2605: PNP/CLUTCH SW	×	×	×	SEC-75
B2606: S/L RELAY	×	×	×	SEC-77
B2607: S/L RELAY	×	×	×	SEC-78
B2608: STARTER RELAY	×	×	×	SEC-80
B2609: S/L STATUS	×	×	×	SEC-82
B260A: IGNITION RELAY	×	×	×	PCS-52
B260B: STEERING LOCK UNIT	—	×	×	SEC-86
B260C: STEERING LOCK UNIT	—	×	×	SEC-87
B260D: STEERING LOCK UNIT	—	×	×	SEC-88
B260F: ENG STATE SIG LOST	×	×	×	SEC-89
B2612: S/L STATUS	×	×	×	SEC-92
B2614: BCM	—	×	×	PCS-54
B2615: BCM	—	×	×	PCS-56
B2616: BCM	—	×	×	PCS-58
B2617: BCM	×	×	×	SEC-96
B2618: BCM	×	×	×	PCS-60
B2619: BCM	×	×	×	SEC-98
B261A: PUSH-BTN IGN SW	—	×	×	SEC-99

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Reference page
B261E: VEHICLE TYPE	×	×	×	(Turn ON for 15 seconds)
B2621: INSIDE ANTENNA	—	×	—	DLK-58
B2622: INSIDE ANTENNA	—	×	—	DLK-60
B2623: INSIDE ANTENNA	—	×	—	DLK-62
B26E7: TPMS CAN COMM	—	—	—	BCS-42
B26E9: S/L STATUS	×	×	×	(Turn ON for 15 seconds)
B26EA: KEY REGISTRATION	—	×	×	(Turn ON for 15 seconds)

FOR GENERAL AREAS

FOR GENERAL AREAS : Reference Value

INFOID:0000000004991298

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-RL	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	Off
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL UN-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
H/L WASH SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	Trunk lid opener cancel switch OFF	Off
	Trunk lid opener cancel switch ON	On
TR/BD OPEN SW	Trunk lid opener switch OFF	Off
	While the trunk lid opener switch is turned ON	On
TRNK/HAT MNTR	Trunk lid closed	Off
	Trunk lid opened	On
SEN CANCEL SW	Sensor cancel switch is not pressed	Off
	Sensor cancel switch is pressed	On
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off
	LOCK button of the Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed	On
RKE-TR/BD	TRUNK OPEN button of the Intelligent Key is not pressed	Off
	TRUNK OPEN button of the Intelligent Key is pressed	On
RKE-PANIC	NOTE: The item is indicated, but not monitored.	Off
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Trunk lid opener request switch is not pressed	Off
	Trunk lid opener request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Shift lever in P position	Off
	Shift lever in any position other than P	On
SFT PN/N SW	Shift lever in any position other than P and N	Off
	Shift lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Shift lever in any position other than P	Off
	Shift lever in P position	On
SFT PN -IPDM	Shift lever in any position other than P and N	Off
	Shift lever in P or N position	On
SFT P -MET	Shift lever in any position other than P	Off
	Shift lever in P position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT N -MET	Shift lever in any position other than N	Off
	Shift lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off
	Steering lock system are not the LOCK condition or the changing condition from LOCK to UNLOCK	On
VEH SPEED 1	While driving	Equivalent to speed-ometer reading
VEH SPEED 2	While driving	Equivalent to speed-ometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off
	The Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 L
 M
 N
 O
 P

PWC

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT




PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	—			
1 (GR)* ¹ (W)* ²	Ground	Battery power supply	Input	Ignition switch OFF
2 (R)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF
3 (W)	Ground	P/W power supply (RAP)	Output	Ignition switch ON
4 (R)* ¹ (O)* ²	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)
5 (L)	Ground	Super lock	Output	Super lock ac- tuator
				Actuator is activated
				Actuator is not activated
7 (Y)	Ground	Step lamp	Output	Step lamp
				ON
				OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid
				LOCK (Actuator is activated)
				Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid
				UNLOCK (Actuator is activated)
				Other than UNLOCK (Actuator is not activated)
10 (G)* ¹ (P)* ²	Ground	Passenger door UN- LOCK	Output	Passenger door
				UNLOCK (Actuator is activated)
				Other than UNLOCK (Actuator is not activated)
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF
13 (B)	Ground	Ground	—	Ignition switch ON
14 (P)	Ground	Push-button ignition switch illumination ground	Output	OFF
				ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch
				OFF (LOCK indicator is not illuminated)
				ACC





NOTE:
When the illumination brightening/dimming level is in the neutral position.



JSNIA0010GB

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
17 (W)	Ground	Turn signal RH (Front and side)	Output	Turn signal switch OFF Turn signal switch RH
				0 V  PKID0926E 6.5 V
18 (O)	Ground	Turn signal LH (Front and side)	Output	Turn signal switch OFF Turn signal switch LH
				0 V  PKID0926E 6.5 V
19 (V)* ¹ (GR)* ²	Ground	Room lamp timer control	Output	Interior room lamp OFF ON
				12 V 0 V
20 (SB)* ¹ (V)* ²	Ground	Turn signal RH (Rear)	Output	Turn signal switch OFF Turn signal switch RH
				0 V  PKID0926E 6.5 V
23 (G)	Ground	Trunk lid open	Output	Trunk lid OPEN (Trunk lid opener actuator is activated) Other than OPEN (Trunk lid opener actuator is not activated)
				12 V 0 V
25 (V)* ¹ (SB)* ²	Ground	Turn signal LH (Rear)	Output	Ignition switch ON Turn signal switch LH
				0 V  PKID0926E 6.5 V
30 (O)* ¹ (L)* ²	Ground	Trunk room lamp	Output	Trunk room lamp ON OFF
				0 V 12 V

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 PWC
 L
 M
 N
 O
 P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)			
	Signal name	Input/ Output					
+	-						
34 (P)	Ground	Trunk room antenna (-)	Output	When Intelligent Key is in the passenger compart- ment			
				 (V) 15 10 5 0 1 s JMKIA0062GB			
35 (L)	Ground	Trunk room antenna (+)	Output	When Intelligent Key is not in the passenger compart- ment			
				 (V) 15 10 5 0 1 s JMKIA0063GB			
38 (R)* ¹ (G)* ²	Ground	Rear bumper anten- na (-)	Output	When Intelligent Key is in the antenna detection area			
				 (V) 15 10 5 0 1 s JMKIA0062GB			
				When Intelligent Key is not in the antenna detection area			
				 (V) 15 10 5 0 1 s JMKIA0063GB			


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
39 (BR) ^{*1} (R) ^{*2}	Ground	Rear bumper antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the trunk lid opener request switch is operated with ignition switch OFF
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	OFF or ACC
				ON
50 (R) ^{*1} (BR) ^{*2}	Ground	Trunk room lamp switch	Input	OFF (Trunk lid is closed)
				ON (Trunk lid is opened)
52 (SB)	Ground	Starter relay control	Output	When shift lever is in P or N position
				When shift lever is not in P or N position
61 (W)	Ground	Trunk lid opener request switch	Input	ON (Pressed)
				OFF (Not pressed)
64 (O) ^{*1} (GR) ^{*2}	Ground	Intelligent Key warning buzzer	Output	Sounding
				Not sounding



JMKIA0062GB




JMKIA0063GB



JPMIA0011GB

11.8 V



JPMIA0016GB

1.0 V

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
67 (G)* ¹ (O)* ²	Ground	Trunk lid opener switch	Input	Pressed Trunk lid opener switch Not pressed
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	When Intelligent Key is in the passenger compartment Ignition switch OFF When Intelligent Key is not in the passenger compartment
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	When Intelligent Key is in the passenger compartment Ignition switch OFF When Intelligent Key is not in the passenger compartment

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
74 (SB)	Ground	Passenger door antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the passenger door request switch is operated with ignition switch OFF
75 (BR)	Ground	Passenger door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the passenger door request switch is operated with ignition switch OFF
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF

A

B

C

D

E

F

G

H

I

J

PWC







L

M

N

O


P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area
				When the driver door request switch is operated with ignition switch OFF
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment
				When the ignition switch is OFF
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment
				When the ignition switch is OFF




JMKIA0062GB




JMKIA0063GB




JMKIA0062GB



JMKIA0063GB




JMKIA0062GB



JMKIA0063GB

BCM (BODY CONTROL MODULE)






< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition		Value (Approx.)
	Signal name	Input/ Output			
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
81 (L)* ¹ (W)* ²	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move.
82 (R)* ¹ (SB)* ²	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC 0 V ON 12 V
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting	
				When operating either button on the Intelligent Key	
85 (V)	Ground	Alarm link	Input/ Output	Vehicle security system	Disarmed phase 12 V
					Pre-armed phase or armed phase  NNKIA0175ZZ
86 (BR)	Ground	Dongle link	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
PWC



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
87 (BR)	Ground	Combination switch INPUT 5	Input	<p>All switches OFF (Wiper intermittent dial 4)</p> <p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7
				 <p>JPMIA0041GB</p> <p>1.4 V</p>
88 (V)	Ground	Combination switch INPUT 3	Input	<p>All switches OFF (Wiper intermittent dial 4)</p> <p>Lighting switch HI (Wiper intermittent dial 4)</p> <p>Lighting switch 2ND (Wiper intermittent dial 4)</p> <p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3
				 <p>JPMIA0041GB</p> <p>1.4 V</p>
				 <p>JPMIA0036GB</p> <p>1.3 V</p>
				 <p>JPMIA0037GB</p> <p>1.3 V</p>
				 <p>JPMIA0040GB</p> <p>1.3 V</p>

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L M N O P
	Signal name	Input/ Output			
89 (BR)	Ground	Push-button ignition switch (Push switch)	Input Push-button ignition switch (Push switch)	Pressed	0 V
				Not pressed	12 V
90 (P)	Ground	CAN-L	Input/ Output	—	—
91 (L)	Ground	CAN-H	Input/ Output	—	—
92 (LG)	Ground	Key slot illumination	Output Key slot illumination	OFF	12 V
				Blinking	 JPMIA0015GB
				ON	0 V
93 (V)	Ground	ON indicator lamp	Output Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
				ON	0 V
95 (O)	Ground	ACC relay control	Output Ignition switch	OFF	0 V
				ACC or ON	12 V
96 (SB)	Ground	A/T shift selector (Detention switch) power supply	Output	—	12 V
97 (L)	Ground	Steering lock condition No. 1	Input Steering lock	LOCK status	0 V
				UNLOCK status	12 V
98 (R)* ¹ (P)* ²	Ground	Steering lock condition No. 2	Input Steering lock	LOCK status	12 V
				UNLOCK status	0 V
99 (G)	Ground	Shift lever P position switch	Input Shift lever	P position	0 V
				Any position other than P	12 V
100 (W)	Ground	Passenger door request switch	Input Passenger door request switch	ON (Pressed)	0 V
				OFF (Not pressed)	 JPMIA0016GB
					1.0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
101 (V)* ¹ (W)* ²	Ground	Driver door request switch	Input	ON (Pressed)
				OFF (Not pressed)
102 (O)	Ground	Blower fan motor relay control	Output	OFF or ACC
				ON
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF
106 (P)* ¹ (V)* ²	Ground	Steering lock unit power supply	Output	OFF or ACC
				ON



JPMIA0016GB



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J L M N O P PWC
	Signal name	Input/ Output			
+	-				
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	 1.4 V
				Turn signal switch LH	 1.3 V
				Turn signal switch RH	 1.3 V
				Front wiper switch LO	 1.3 V
				Front washer switch ON	 1.3 V







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
108 (R)	Ground	Combination switch INPUT 4	Input	<p>All switches OFF (Wiper intermittent dial 4)</p> <p>Lighting switch 1ST (Wiper intermittent dial 4)</p> <p>Any of the conditions below with all switches OFF</p> <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6
				 1.4 V
				 1.3 V



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J L M N O P PWC	
	Signal name	Input/ Output				
+	-					
109 (Y)	Ground	Combination switch INPUT 2	Input Combination switch (Wiper intermittent dial 4)	All switches OFF	 1.4 V <small>JPMIA0041GB</small>	A B C D E F G H I J L M N O
				Lighting switch PASS	 1.3 V <small>JPMIA0037GB</small>	E F G H I J L M N O
				Lighting switch 2ND	 1.3 V <small>JPMIA0036GB</small>	H I J L M N O
				Front wiper switch INT	 1.3 V <small>JPMIA0038GB</small>	PWC
				Front wiper switch HI	 1.3 V <small>JPMIA0040GB</small>	L M N O
110 (G)	Ground	Hazard switch	Input Hazard switch	ON	0 V	O P
				OFF	 1.1 V <small>JPMIA0012GB</small>	





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
111 (Y)	Ground	Steering lock unit communication	Input/ Output	LOCK status
				LOCK or UNLOCK
				(V)  JMKIA0066GB
				For 15 seconds after UN-LOCK 12 V
116 (SB)	Ground	Stop lamp switch 1	Input	15 seconds or later after UNLOCK 0 V
				— Battery voltage
117 (G)	Ground	Sensor cancel switch	Input	OFF (Not pressed)
				(V)  JPMIA0012GB 1.1 V
118 (P)* ¹ (BR)* ²	Ground	Stop lamp switch 2	Input	ON (Pressed) 0 V
				OFF (Brake pedal is not depressed) 0 V
				ON (Brake pedal is depressed) Battery voltage
119 (SB)	Ground	Driver side door lock assembly (Unlock sensor)	Input	LOCK status (Unlock sensor switch OFF) 1.1 V
				UNLOCK status (Unlock switch sensor ON) 0 V
121 (R)	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot 12 V
				When the Intelligent Key is not inserted into key slot 0 V
123 (BR)* ¹ (W)* ²	Ground	IGN feedback	Input	OFF or ACC 0 V
				Ignition switch ON Battery voltage





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P	
	Signal name	Input/ Output				
+	-					
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 11.8 V JPMIA0011GB
					ON (Door open)	
128 (P)* ¹ (GR)* ²	Ground	Door lock and unlock switch LOCK	Input	Door lock and unlock switch (Power window main switch or power window sub-switch)	NEUTRAL position	 11.8 V JPMIA0011GB
					LOCK position	
				Trunk lid opener cancel switch	CANCEL	 1.1 V JPMIA0012GB
					ON	
131 (BR)	Ground	Door lock and unlock switch UNLOCK	Input	Door lock and unlock switch (Power window main switch or power window sub-switch)	NEUTRAL position	 11.8 V JPMIA0011GB
					UNLOCK position	
				Push-button ignition switch illumination	ON (Tail lamps OFF)	9.5 V
133 (W)* ¹ (L)* ²	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON (Tail lamps ON)	 9.5 V JPMIA0159GB
					OFF	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
134 (GR) ^{*1} (R) ^{*2}	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage
					ON	0 V
137 (L)	Ground	Receiver ground	Input	Ignition switch ON		0 V
140 (BR)	Ground	Shift lever P/N position	Input	Shift lever	P or N position	12 V
					Except P and N positions	0 V
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 (V) 15 10 5 0 1 s
					OFF	Battery voltage
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	 (V) 15 10 5 0 2 ms
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7	 (V) 15 10 5 0 2 ms
					10.7 V	JPMIA0032GB
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6	 (V) 15 10 5 0 2 ms
					10.7 V	JPMIA0033GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J		
	Signal name	Input/ Output					
145 (L)	Ground	Combination switch OUTPUT 3	Output	All switches OFF	0 V	A B C D E F G H I J	
				Front wiper switch INT			
				Front wiper switch LO	 JPMIA0034GB 10.7 V		
146 (SB)	Ground	Combination switch OUTPUT 4	Output	All switches OFF	0 V	A B C D E F G H I J	
				Lighting switch 2ND			
				Lighting switch PASS	 JPMIA0035GB 10.7 V		
150 (GR)	Ground	Driver door switch	Input	Driver door switch	All switches OFF (Door close)	 JPMIA0011GB 11.8 V	A B C D E F G H I J
					ON (Door open)		
					0 V		
151 (G)	Ground	Rear window defogger relay control	Output	Rear window defogger	Active	0 V	PWC L M N O P
					Not activated	Battery voltage	

• *1: LHD models

• *2: RHD models


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

FOR GENERAL AREAS : Wiring Diagram - BCM -

INFOID:0000000004991299

BCM (BODY CONTROL MODULE) (EXCEPT FOR TAIWAN)




JCMWA4652GB

2009/05/07

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMWA4653GB

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMWA4654GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMW4655GB

PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWA4656GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (EXCEPT FOR TAIWAN)

Connector No.	M116	Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC	Connector Type	NS16FV-CS
			

1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
2	SB	OUTPUT 4	1	GR	BAT (F.L.) [RHD models]
5	L	OUTPUT 3	1	W	BAT (F.L.) [RHD models]
7	Y	INPUT 3	2	R	POWER WINDOW POWER SUPPLY (BAT)
8	O	OUTPUT 5	3	W	POWER WINDOW POWER SUPPLY (RAP/TON)
9	Y	INPUT 2			
10	R	INPUT 4	7	Y	STEP LAMP
11	LG	INPUT 1	8	V	ALL DOOR FUEL LID UNLOCK OUTPUT
12	P	OUTPUT 1	9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
13	BR	INPUT 5	10	G	PASSENGER DOOR UNLOCK OUTPUT [RHD models]
14	G	OUTPUT 2	11	R	PASSENGER DOOR UNLOCK OUTPUT [RHD models]
			12		BAT (FUSE)
			13	B	GROUND
			14	P	PUSH-BUTTON (IGNITION SW) SW GND

4	5	6	7	8	9	10
11	12	13	14	15	16	17
18	19	20	21	22	23	24
25	26	27	28	29	30	31

64	O	I-KEY/WARN BUZZER (ENG ROOM) [RHD models]
64	GR	I-KEY/WARN BUZZER (ENG ROOM) [RHD models]
67	G	TRUNK LID OPENER SW [RHD models]
67	O	TRUNK LID OPENER SW [RHD models]

20	21	22	23	24	25	26	27	28	29	30	31
----	----	----	----	----	----	----	----	----	----	----	----

64	O	I-KEY/WARN BUZZER (ENG ROOM) [RHD models]
64	GR	I-KEY/WARN BUZZER (ENG ROOM) [RHD models]
67	G	TRUNK LID OPENER SW [RHD models]
67	O	TRUNK LID OPENER SW [RHD models]

34	P	TRUNK ROOM ANT-
35	L	TRUNK ROOM ANT-
36	R	REAR BUMPER ANT [RHD models]
38	G	REAR BUMPER ANT- [RHD models]
39	BR	REAR BUMPER ANT- [RHD models]
39	R	REAR BUMPER ANT+ [RHD models]
47	Y	IGN RELAY (IDM ER/CONT)
50	R	TRUNK ROOM LAMP SW [RHD models]
50	BR	TRUNK ROOM LAMP SW [RHD models]
52	SB	STARTER RELAY CONT
61	W	TRUNK LID REQUEST SW

JCMWA4106GB

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (EXCEPT FOR TAIWAN)

	L/G	COMBI SW INPUT 1
107	R	COMBI SW INPUT 4
108	Y	COMBI SW INPUT 2
109	G	HAZARD SW
110	Y	S/UNIT COMM
111	Y	



82	R	IGN RELAY / E/BL/CONT [LHD models]
82	S8	IGN RELAY (F/F) CONT [RHD models]
83	S8	KEYLESS ENTRY RECEIVER/COMM
85	V	ALARM LINK
96	BR	DONGLE LINK
37	BR	COMBI SW IN/OUT 5
38	V	COMBI SW IN/OUT 3
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
32	LG	KEY SLOT IN/OUT
93	V	ON/IND
35	O	ACC RELAY /CONT
96	SB	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
38	R	S/L CONDITION 2 [LHD models]
98	P	S/L CONDITION 2 [RHD models]
99	G	S/HIFT P
100	W	PASSENGER DOOR REQUEST SW
101	W	DRIVER DOOR REQUEST SW [LHD models]
101	O	DRIVER DOOR REQUEST SW [RHD models]
102	O	BLOWER/FAN MOTOR RELAY CONT
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	P	S/L UNIT POWER SUPPLY [LHD models]
106	V	S/L UNIT POWER SUPPLY [RHD models]



129	O	TRUNK CANCEL SW
131	BR	DOOR LOCK/UNLOCK SW
133	S	PUSH-BUTTON IGNITION SW (POWER LH/RL mode)
133	W	PUSH-BUTTON IGNITION SW (POWER RH mode)
133	L	PUSH-BUTTON IGNITION SW (POWER LH mode)
134	GR	LOCK IND (LHD models)
134	R	LOCK IND (RHD models)
137	L	RECEIVER GND
140	BR	SHIFT IND
141	G	SECURITY INDICATOR
142	O	COMBI SW INPUT 5
143	P	COMBI SW INPUT 1
144	G	COMBI SW INPUT 2
145	S	COMBI SW INPUT 3
146	SB	COMBI SW INPUT 4
150	GR	DRIVER DOOR SW
151	E	FRONT/REAR DOOR SW
151	U	FRONT/REAR DOOR SW



Character No.	Character Name	Character Type	Terminal	Color of Wire	Signal Name [Source/Function]
M123			116	SB	STOP LAMP SW 1
	BCM (BODY CONTROL MODULE)		117	G	SENSOR CANCEL SW
			118	P	STOP LAMP SW (LHD models)
			119	BR	STOP LAMP SW (RHD models)
			121	R	DR DOOR UNLOCK SENSOR
			123	BR	KEY SLOT
			124	W	[IGN F/B (LHD models)]
			124	W	[IGN F/B (RHD models)]
			126	P	PASSENGER DOOR SW
			128	DC	DOOR UNLOCK SW (LHD models)
			129	DC	DOOR UNLOCK SW (RHD models)

JCMWA4657GB

INFOID:0000000004991300

FOR GENERAL AREAS : Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2196: DONGLE NG	Inhibit engine cranking	Erase DTC
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Shift lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Shift lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Shift lever P position switch signal: Except P position (battery voltage) • Shift lever P/N position signal: Except P and N positions (0 V)
B2604: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: BCM	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No. 1 signal: LOCK (0 V) • Steering condition No. 2 signal: LOCK (Battery voltage)

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

FOR GENERAL AREAS : DTC Inspection Priority Chart

INFOID:000000004991301

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT(CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING • B2196: DONGLE NG

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC	
4	<ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP/CLUTCH SW • B2605: PNP/CLUTCH SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2612: S/L STATUS • B2614: BCM • B2615: BCM • B2616: BCM • B2617: BCM • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E9: S/L STATUS • B26EA: KEY REGISTRATION • U0415: VEHICLE SPEED 	A B C D E F G H I
5	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA 	J
6	B26E7: TPMS CAN COMM	PWC

FOR GENERAL AREAS : DTC Index

INFOID:000000004991302

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-109. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)".](#)

CONSULT display	Fail-safe	Freeze Frame Data	Intelligent Key warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM	—	—	—	BCS-127
U1010: CONTROL UNIT(CAN)	—	—	—	BCS-128
U0415: VEHICLE SPEED	—	—	—	BCS-129
B2013: ID DISCORD BCM-S/L	×	×	—	SEC-55
B2014: CHAIN OF S/L-BCM	×	×	—	SEC-56
B2190: NATS ANTENNA AMP	×	—	—	SEC-45

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle condition	Intelligent Key warning lamp ON	Reference page
B2191: DIFFERENCE OF KEY	×	—	—	SEC-48
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-49
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-51
B2195: ANTI SCANNING	×	—	—	SEC-52
B2196: DONGLE NG	×	—	—	SEC-53
B2553: IGNITION RELAY	—	×	—	PCS-50
B2555: STOP LAMP	—	×	—	SEC-59
B2556: PUSH-BTN IGN SW	—	×	×	SEC-61
B2557: VEHICLE SPEED	×	×	×	SEC-63
B2560: STARTER CONT RELAY	×	×	×	SEC-64
B2562: LOW VOLTAGE	—	×	—	BCS-130
B2601: SHIFT POSITION	×	×	×	SEC-65
B2602: SHIFT POSITION	×	×	×	SEC-68
B2603: SHIFT POSI STATUS	×	×	×	SEC-71
B2604: PNP/CLUTCH SW	×	×	×	SEC-73
B2605: PNP/CLUTCH SW	×	×	×	SEC-75
B2606: S/L RELAY	×	×	×	SEC-77
B2607: S/L RELAY	×	×	×	SEC-78
B2608: STARTER RELAY	×	×	×	SEC-80
B2609: S/L STATUS	×	×	×	SEC-82
B260A: IGNITION RELAY	×	×	×	PCS-52
B260B: STEERING LOCK UNIT	—	×	×	SEC-86
B260C: STEERING LOCK UNIT	—	×	×	SEC-87
B260D: STEERING LOCK UNIT	—	×	×	SEC-88
B260F: ENG STATE SIG LOST	×	×	×	SEC-89
B2612: S/L STATUS	×	×	×	SEC-92
B2614: BCM	—	×	×	PCS-54
B2615: BCM	—	×	×	PCS-56
B2616: BCM	—	×	×	PCS-58
B2617: BCM	×	×	×	SEC-96
B2618: BCM	×	×	×	PCS-60
B2619: BCM	×	×	×	SEC-98
B261A: PUSH-BTN IGN SW	—	×	×	SEC-99
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	SEC-101
B2621: INSIDE ANTENNA	—	×	—	DLK-58
B2622: INSIDE ANTENNA	—	×	—	DLK-60
B2623: INSIDE ANTENNA	—	×	—	DLK-62
B26E7: TPMS CAN COMM	—	—	—	BCS-131
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	SEC-90
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	SEC-91

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

FOR TAIWAN

FOR TAIWAN : Reference Value

INFOID:0000000004991303

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT	Off
	Front wiper switch INT	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
RR FOG SW	Rear fog lamp switch OFF	Off
	Rear fog lamp switch ON	On
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-RL	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	Off
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL UN-SW	NOTE: The item is indicated, but not monitored.	Off
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is not pressed	Off
	Hazard switch is pressed	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	Trunk lid opener cancel switch OFF	Off
	Trunk lid opener cancel switch ON	On
TR/BD OPEN SW	Trunk lid opener switch OFF	Off
	While the trunk lid opener switch is turned ON	On
TRNK/HAT MNTR	Trunk lid closed	Off
	Trunk lid opened	On
RKE-LOCK	LOCK button of Intelligent Key is not pressed	Off
	LOCK button of Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed	On
RKE-TR/BD	TRUNK OPEN button of Intelligent Key is not pressed	Off
	TRUNK OPEN button of Intelligent Key is pressed	On
RKE-PANIC	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	On
REQ SW-DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW-AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW-RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW-RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW-BD/TR	Trunk lid opener request switch is not pressed	Off
	Trunk lid opener request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Shift lever in P position	Off
	Shift lever in any position other than P	On
SFT PN/N SW	Shift lever in any position other than P and N	Off
	Shift lever in P or N position	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN-DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Shift lever in any position other than P	Off
	Shift lever in P position	On
SFT PN -IPDM	Shift lever in any position other than P and N	Off
	Shift lever in P or N position	On
SFT P -MET	Shift lever in any position other than P	Off
	Shift lever in P position	On
SFT N -MET	Shift lever in any position other than N	Off
	Shift lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	Steering is unlocked	Off
	Steering is locked	On
S/L UNLK-IPDM	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK	On
VEH SPEED 1	While driving	Equivalent to speed- ometer reading

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Steering is locked	Reset
	Steering is unlocked	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	Intelligent Key is not inserted into key slot	Off
	Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



JPMIA0062ZZ


PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
1 (GR)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (R)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	12 V
3 (W)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	12 V
4 (R)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time	0 V
				Any other time after passing the interior room lamp battery saver operation time	12 V
5 (G)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
7 (Y)	Ground	Step lamp	Output	Step lamp	ON
					OFF
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)
					Other than LOCK (Actuator is not activated)
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)
					Other than UNLOCK (Actuator is not activated)
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON	0 V
14 (P)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF
					ON
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)
					ACC





NOTE:
When the illumination brightening/dimming level is in the neutral position



JSNIA0010GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P	
	Signal name	Input/ Output				
17 (W)	Ground	Turn signal RH (Front and side)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
18 (O)	Ground	Turn signal LH (Front and side)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	Battery voltage
					ON	0 V
20 (SB)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
23 (G)	Ground	Trunk lid open	Output	Trunk lid	Open (Trunk lid opener actuator is activated)	12 V
					Close (Trunk lid opener actuator is not activated)	0 V
24 (R)	Ground	Rear fog lamp	Output	Rear fog lamp	OFF	0 V
					ON	12 V
25 (V)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
30 (O)	Ground	Trunk room lamp	Output	Trunk room lamp	ON	0 V
					OFF	12 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
34 (P)	Ground	Trunk room antenna (-)	Output Ignition switch OFF	When Intelligent Key is in the passenger compart- ment
				 (V) 15 10 5 0 1 s JKMIA0062GB
35 (L)	Ground	Trunk room antenna (+)	Output Ignition switch OFF	When Intelligent Key is not in the passenger compart- ment
				 (V) 15 10 5 0 1 s JKMIA0063GB
38 (R)	Ground	Rear bumper anten- na (-)	Output When the trunk lid opener re- quest switch is operated with ig- nition switch OFF	When Intelligent Key is in the antenna detection area
				 (V) 15 10 5 0 1 s JKMIA0062GB
				When Intelligent Key is not in the antenna detection area
				 (V) 15 10 5 0 1 s JKMIA0063GB






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P		
	+	-	Signal name	Input/ Output			
39 (BR)	Ground	Rear bumper antenna (+)	Output	When the trunk lid opener request switch is operated with ignition switch OFF	 When Intelligent Key is in the antenna detection area	JMKA0062GB	
				When Intelligent Key is not in the antenna detection area			
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	12 V	G
					ON	0 V	
50 (R)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	OFF (Trunk is closed)	 11.8 V	J
					ON (Trunk is open)	0 V	
52 (SB)	Ground	Starter relay control	Output	Ignition switch ON	When shift lever is in P or N position	12 V	PWC
					When shift lever is not in P or N position	0 V	
61 (W)	Ground	Trunk lid opener request switch	Input	Trunk lid opener request switch	ON (Pressed)	0 V	M
					OFF (Not pressed)	 1.0 V	
64 (O)	Ground	Intelligent Key warning buzzer	Output	Intelligent Key warning buzzer	Sounding	0 V	N
					Not sounding	12 V	







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
67 (G)	Ground	Trunk lid opener switch	Input	Pressed Not pressed
				 11.8 V
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	When Intelligent Key is in the passenger compartment
				 JMKIA0062GB
				When Intelligent Key is not in the passenger compartment
				 JMKIA0063GB
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	When Intelligent Key is in the passenger compartment
				 JMKIA0062GB
				When Intelligent Key is not in the passenger compartment
				 JMKIA0063GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P	
	+	-	Signal name	Input/ Output		
74 (SB)	Ground	Passenger door antenna (-)	Output	When the passenger door request switch is operated with ignition switch OFF	 When Intelligent Key is in the antenna detection area	JMKA0062GB
				When Intelligent Key is not in the antenna detection area	 When Intelligent Key is not in the antenna detection area	
75 (BR)	Ground	Passenger door antenna (+)	Output	When the passenger door request switch is operated with ignition switch OFF	 When Intelligent Key is in the antenna detection area	JMKA0062GB
				When Intelligent Key is not in the antenna detection area	 When Intelligent Key is not in the antenna detection area	
76 (V)	Ground	Driver door antenna (-)	Output	When the driver door request switch is operated with ignition switch OFF	 When Intelligent Key is in the antenna detection area	JMKA0062GB
				When Intelligent Key is not in the antenna detection area	 When Intelligent Key is not in the antenna detection area	






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operated with ignition switch OFF
				When Intelligent Key is not in the antenna detection area
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment
				When Intelligent Key is not in the passenger compartment
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	When Intelligent Key is in the passenger compartment
				When Intelligent Key is not in the passenger compartment







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P	
	+	-	Signal name	Input/ Output		
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move.	B
81 (L)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot. Just after pressing ignition switch. Pointer of tester should move.	C
82 (R)	Ground	Ignition relay [fuse block (J/B)] control	Output	Ignition switch	OFF or ACC 0 V ON 12 V	D
83 (Y)	Ground	Remote keyless entry receiver communication	Input/ Output	During waiting	 JKMIA0064GB	E
				When operating either button on Intelligent Key	 JKMIA0065GB	F
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)  JPMIA0041GB 1.4 V	G
					Rear fog lamp switch ON (Wiper intermittent dial 4)  JPMIA0038GB 1.3 V	H
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7  JPMIA0040GB 1.3 V	I



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
+	-				
88 (V)	Ground	Combination switch INPUT 3	Input	 1.4 V	
				 1.3 V	
				 1.3 V	
				 1.3 V	
89 (BR)	Ground	Push-button ignition switch (push switch)	Input	Push-button igni- tion switch (push switch)	
				Pressed	
90 (P)	Ground	CAN - L	Input/ Output	—	—
91 (L)	Ground	CAN - H	Input/ Output	—	—
92 (LG)	Ground	Key slot illumination	Output	Key slot illumina- tion	OFF
					12 V
					 12 V
				Blinking	 6.5 V
					0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ON	0 V
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
96 (SB)	Ground	A/T shift selector (detention switch) power supply	Output	—		12 V
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	12 V
98 (R)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	12 V
					UNLOCK status	0 V
99 (G)	Ground	Shift lever P position switch	Input	Shift lever	P position	0 V
					Any position other than P	12 V
100 (W)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> 1.0 V
101 (V)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <small>JPMIA0016GB</small> 1.0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		12 V
106 (P)	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V

A

B

C

D

E

F

G

H

I

J

PWC

L

M






N

O

P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
107 (LG)	Ground	Combination switch INPUT 1	Combination switch (Wiper intermit- tent dial 4)	All switches OFF  1.4 V
				Turn signal switch LH  1.3 V
				Turn signal switch RH  1.3 V
				Front wiper switch LO  1.3 V
				Front washer switch ON  1.3 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J	
	Signal name	Input/ Output				
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switches OFF (Wiper intermittent dial 4)	 JPMIA0041GB 1.4 V
					Lighting switch 1ST (Wiper intermittent dial 4)	 JPMIA0036GB 1.3 V
					Any of the conditions below with all switches OFF • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6	 JPMIA0039GB 1.3 V

A
B
C
D
E
F
G
H
I
J

L

M

N







O

P

PWC




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
109 (Y)	Ground	Combination switch INPUT 2	Combination switch (Wiper intermittent dial 4)	All switches OFF
				 1.4 V JPMIA0041GB
				 1.3 V JPMIA0037GB
				 1.3 V JPMIA0036GB
				 1.3 V JPMIA0038GB
110 (G)	Ground	Hazard switch	Hazard switch	Pressed
				 0 V JPMIA0012GB
110 (G)	Ground	Hazard switch	Hazard switch	Not pressed
				 1.1 V JPMIA0012GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	A B C D E F G H I J PWC L M N O P
+	-	Signal name	Input/ Output			
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	12 V
					LOCK or UNLOCK	 JMKIA0066GB
					For 15 seconds after UN-LOCK	12 V
					15 seconds or later after UNLOCK	0 V
116 (SB)	Ground	Stop lamp switch 1	Input	—		Battery voltage
118 (P)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is depressed)	Battery voltage
119 (SB)	Ground	Driver side door lock actuator (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 JPMIA0011GB
					UNLOCK status (unlock sensor switch ON)	0 V
121 (R)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot		12 V
				When Intelligent Key is not inserted into key slot		0 V
123 (BR)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 JPMIA0011GB
					ON (Door open)	0 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
128 (P)	Ground	Door lock and unlock switch LOCK	Input	Door lock and unlock switch (power window main switch or power window sub-switch)	NEUTRAL position	 11.8 V JPMIA0011GB
					LOCK position	
129 (O)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	CANCEL	 1.1 V JPMIA0012GB
					ON	
131 (BR)	Ground	Door lock and unlock switch UNLOCK	Input	Door lock and unlock switch (power window main switch or power window sub-switch)	NEUTRAL position	 11.8 V JPMIA0011GB
					LOCK position	
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	ON (When tail lamps OFF)	9.5 V
					ON (When tail lamps ON)	NOTE: The pulse width of this wave is varied by the illumination brightening/dimming level.  JPMIA0159GB
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	ON	0 V
					OFF	Battery voltage
137 (L)	Ground	Receiver ground	Input	Ignition switch ON		0 V
140 (BR)	Ground	Shift lever P/N position	Input	Shift lever	P or N position	12 V
					Except P and N positions	0 V


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
141 (G)	Ground	Security indicator	Output	Security indicator	ON	0 V
					Blinking	 JPMIA0014GB
					OFF	11.3 V Battery voltage
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Lighting switch 1ST	
					Lighting switch HI	
					Lighting switch 2ND	
					Turn signal switch RH	 JPMIA0031GB
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	 JPMIA0032GB
					10.7 V	PWC
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 	 JPMIA0033GB
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermittent dial 4)	All switches OFF	0 V
					Front wiper switch INT	
					Front wiper switch LO	
					Rear fog lamp switch ON	
					10.7 V	PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
146 (SB)	Ground	Combination switch OUTPUT 4	Combination switch (Wiper intermit- tent dial 4)	All switches OFF
				Lighting switch 2ND
				Lighting switch PASS
				Turn signal switch LH
150 (GR)	Ground	Driver door switch	Driver door switch	 10.7 V
				OFF (Door close)
				ON (Door open)
				11.8 V
151 (G)	Ground	Rear window defog- ger relay control	Output	Active
				Not activated
				Battery voltage


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

FOR TAIWAN : Wiring Diagram - BCM -

INFOID:0000000004991304

BCM (BODY CONTROL MODULE) (FOR TAIWAN)



JCMWA4647GB

2009/05/07

PWC

L

M

Z

O

P

Q

U

—

—

—

—

—

—

—

A

B

C

D


T

G

—

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMW4648GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWA4649GB

PWC

L

M

N

O

P

A

B

C

D

E

F


G

H

I

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMW4650GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (FOR TAIWAN)

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH

Terminal No.		Signal Name [Specification]		Terminal No.	
Terminal No.	Code of Wire	Signal Name	Specification	Terminal No.	Code of Wire
2	SE	OUTPUT	4	1	GR
5	L	OUTPUT	3	2	R
7	V	INPUT	3	3	W
8	O	OUTPUT	5		
9	Y	INPUT	2		
10	R	INPUT	4		
11	LG	INPUT	1		
12	P	OUTPUT	1		
13	BR	INPUT	5		
14	G	OUTPUT	2		

Connector No.	M116
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	16FW-CS

Terminal No.	Color of Wire	Signal Name [Specification]
4	R	INTERIOR ROOM LAMP POWER [Up-P] [UD model]
5	G	PASSENGER DOOR LATCH OUTPUT [for Taiwan]
7	Y	STEP LAMP
8	V	ALL DOOR FUEL DOOR LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
11	R	BAT (USE)
13	B	GND
14	P	PUSH-BUTTON IGNITION SWN [L] GND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT, SIDE) OUTPUT
18	O	TURN SIGNAL LH (FRONT, SIDE) OUTPUT

19 V ROOM LAMP TIMER CONTROL (LHD model)

83	Y	KEYLESS ENTRY RECEIVER COMM
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	PUSH SW
90	L	CAN-H
91	L	CAN-L
92	LG	KEY SLOT/L OUTPUT
93	Y	ON IND
95	O	ACO-RELAY CONT
96	SB	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	R	S/L CONDITION 2 (LHD models)
99	G	SHFT
100	W	PASSENGER DOOR REQUEST SW
101	V	DRIVER DOOR REQUEST SW (LHD models)
102	O	BLOWER FAN MOTOR RELAY CONT
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
105	P	S/L UNIT POWER SUPPLY (LHD models)
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW
111	Y	S/L UNIT COMM

Connector No.	MI 22	Color of Wires	Signal Name [Specification]
Connector Name	BCM BODY CONTROL MODULE	R	ROOM ANT2-
Connector Type	TH40FB-NH	G	ROOM ANT2+
		SB	PASSENGER DOOR ANT-
		DR	PASSENGER DOOR ANT+
		V	DRIVER DOOR ANT-
		LG	DRIVER DOOR ANT+
		Y	ROOM ANT1-
		BR	ROOM ANT1+
		GR	IMMOBILANTENNA SIGNAL [LED mode's]
		L	IMMOBILANTENNA SIGNAL [LED mode's]

Connector No.	Terminating	Calc. of Wire	Signal Name [Specification]
M121			TRUNK ROOM ANT-
BCM	P	L	TRUNK ROOM ANT-
BCM (BODY CONTROL MODULE)		R	REAR BUMPER ANT- [L/D models]
		BR	REAR BUMPER ANT- [L/D models]
		47	IGN RELAY (F/R/CONT)
		R	TRUNK ROOM LAMP [L/D models]
		52	STARTER RELAY (CONT)
		SB	TRUNK LID REQUEST SW
		W	LKEY/WARN BLZD (ENG ROOM) [L/D models]
		O	TRUNK LID OPENER (L/D models)
		67	TRUNK LID OPENER (L/D models)

Connector No.	M120	Connector Name	BGM (BODY CONTROL MODULE)
Connector Type	NTSFN-05		
			
			
Term No.	Order of Wires	Name [Specification]	
20	SB	TURN SIGNAL RH (REAR) OUTPUT [LHD models]	
23	G	TRUNK ID (OPEN) OUTPUT	
24	R	REAR FOG OUTPUT	
25	V	TURN SIGNAL LH (REAR) OUTPUT [LHD models]	
30	O	TRUNK ROOM LAMP [LHD models]	

JCMWA4651GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE) (FOR TAIWAN)	
Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH
HS	
Terminal No.	Color of Wire
16	SE
18	P
19	S
21	R
23	BR
24	LG
28	P
29	O
31	BR
33	W
34	GR
Signal Name [Specification]	
16	STOP LAMP SW 1
18	STOP LAMP SW 2 [LHD models]
19	DR DOOR UNLK SENSOR
21	KEY SLOW SW
23	IGN F/B [LHD models]
24	PASSENGER DOOR SW
28	DOOR LOCK/UNLOCK SW [LHD models]
29	TRUNK CANSEL SW
31	DOOR LOCK/UNLOCK SW UNLOCK
33	PUSH-BUTTON/REMOTE SW/L POWER [LHD models]
34	LOCK IND [LHD models]

JCMWA4100GB

FOR TAIWAN : Fail-safe

INFOID:000000004991305

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Shift lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Shift lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 km/h (2.5 MPH) or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Shift lever P position switch signal: Except P position (battery voltage) • Shift lever P/N position signal: Except P and N positions (0 V)
B2604: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Power position: IGN • Shift lever P/N position signal: Except P and N positions (0 V) • Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Shift lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: BCM	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E9: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> • Steering condition No. 1 signal: LOCK (0 V) • Steering condition No. 2 signal: LOCK (Battery voltage)

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

FOR TAIWAN : DTC Inspection Priority Chart

INFOID:000000004991306

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT(CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC	
4	<ul style="list-style-type: none"> B2013: ID DISCORD BCM-S/L B2014: CHAIN OF S/L-BCM B2553: IGNITION RELAY B2555: STOP LAMP B2556: PUSH-BTN IGN SW B2557: VEHICLE SPEED B2560: STARTER CONT RELAY B2601: SHIFT POSITION B2602: SHIFT POSITION B2603: SHIFT POSI STATUS B2604: PNP/CLUTCH SW B2605: PNP/CLUTCH SW B2606: S/L RELAY B2607: S/L RELAY B2608: STARTER RELAY B2609: S/L STATUS B260A: IGNITION RELAY B260B: STEERING LOCK UNIT B260C: STEERING LOCK UNIT B260D: STEERING LOCK UNIT B260F: ENG STATE SIG LOST B2612: S/L STATUS B2614: BCM B2615: BCM B2616: BCM B2617: BCM B2618: BCM B2619: BCM B261A: PUSH-BTN IGN SW B261E: VEHICLE TYPE B26E9: S/L STATUS B26EA: KEY REGISTRATION U0415: VEHICLE SPEED 	A B C D E F G H I
5	<ul style="list-style-type: none"> B2621: INSIDE ANTENNA B2622: INSIDE ANTENNA B2623: INSIDE ANTENNA 	J
6	B26E7: TPMS CAN COMM	PWC

FOR TAIWAN : DTC Index

INFOID:000000004991307

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-189. "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)".](#)

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Reference page
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM	—	—	—	BCS-207
U1010: CONTROL UNIT(CAN)	—	—	—	BCS-208
U0415: VEHICLE SPEED	—	—	—	BCS-209
B2013: ID DISCORD BCM-S/L	×	×	—	SEC-55
B2014: CHAIN OF S/L-BCM	×	×	—	SEC-56
B2190: NATS ANTENNA AMP	×	—	—	SEC-45

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning lamp ON	Reference page
B2191: DIFFERENCE OF KEY	×	—	—	SEC-48
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-49
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-51
B2195: ANTI SCANNING	×	—	—	SEC-51
B2553: IGNITION RELAY	—	×	—	PCS-50
B2555: STOP LAMP	—	×	—	SEC-59
B2556: PUSH-BTN IGN SW	—	×	×	SEC-61
B2557: VEHICLE SPEED	×	×	×	SEC-63
B2560: STARTER CONT RELAY	×	×	×	SEC-64
B2562: LOW VOLTAGE	—	×	—	BCS-210
B2601: SHIFT POSITION	×	×	×	SEC-65
B2602: SHIFT POSITION	×	×	×	SEC-68
B2603: SHIFT POSI STATUS	×	×	×	SEC-71
B2604: PNP/CLUTCH SW	×	×	×	SEC-73
B2605: PNP/CLUTCH SW	×	×	×	SEC-75
B2606: S/L RELAY	×	×	×	SEC-77
B2607: S/L RELAY	×	×	×	SEC-78
B2608: STARTER RELAY	×	×	×	SEC-80
B2609: S/L STATUS	×	×	×	SEC-82
B260A: IGNITION RELAY	×	×	×	PCS-52
B260B: STEERING LOCK UNIT	—	×	×	SEC-86
B260C: STEERING LOCK UNIT	—	×	×	SEC-87
B260D: STEERING LOCK UNIT	—	×	×	SEC-88
B260F: ENG STATE SIG LOST	×	×	×	SEC-89
B2612: S/L STATUS	×	×	×	SEC-92
B2614: BCM	—	×	×	PCS-54
B2615: BCM	—	×	×	PCS-56
B2616: BCM	—	×	×	PCS-58
B2617: BCM	×	×	×	SEC-96
B2618: BCM	×	×	×	PCS-60
B2619: BCM	×	×	×	SEC-98
B261A: PUSH-BTN IGN SW	—	×	×	SEC-99
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	SEC-101
B2621: INSIDE ANTENNA	—	×	—	DLK-409
B2622: INSIDE ANTENNA	—	×	—	DLK-411
B2623: INSIDE ANTENNA	—	×	—	DLK-413
B26E7: TPMS CAN COMM	—	—	—	BCS-211
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	SEC-90
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	SEC-91


POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW MOTOR FOR EUROPE

FOR EUROPE : Wiring Diagram - POWER WINDOW SYSTEM (LHD models) -

INFOID:0000000004994559



JCKWA2488GB

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	Bl	Connector No.	B21	Connector No.	B201	Connector No.	B221
Connector Name	WIRE TO WIRE	Connector Name	DRIVER SIDE DOOR SWITCH	Connector Name	WIRE TO WIRE	Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	TH80FW-CS16-TM4	Connector Type	A03FW	Connector Type	TH80FW-CS16-TM4	Connector Type	A03FW
							
Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire
63	LG	2	LG	64	GR	2	GR
Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—

Connector No.	D1	Connector No.	D8	Connector No.	D10	Connector No.	D31
Connector Name	WIRE TO WIRE	Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	DRIVER SIDE POWER WINDOW MOTOR	Connector Name	WIRE TO WIRE
Connector Type	TH140FW-CS15	Connector Type	NS16FW-CS	Connector Type	NU05FW-DY	Connector Type	TH40FW-CS15
							
Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire	Terminal No.	Color of Wire
9	R	2	W	1	R	9	R
10	W	3	R	2	W	10	W
11	Y	6	SB	3	O	11	Y
12	O	7	O	4	L	12	O
13	LG	8	B	6	GR	13	LG
14	SB	9	—	7	R	14	SB
15	B	10	G	8	B	15	B
16	GR	11	L	15	LG	16	LG
Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—	Signal Name [Specification]	—

JCKWA2489GB

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]
D38	POWER WINDOW SUB-SWITCH	TH140MW-CS16	3 V	—
			5 SB	—
			6 O	—
			7 LG	—
			8 B	—
			11 W	—
			14 R	—
			15 G	—
			16 L	—

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]
M5	WIRE TO WIRE	TH140MW-CS16	1 R	—
			2 W	—
			3 G	—
			4 L	—
			6 LG	—
			7 R	—
			8 B	—

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]
E106	WIRE TO WIRE	TH160FW-CS16-TM4	91 GR	—
			7A R	—
			7A LG	—

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]
M7	WIRE TO WIRE	TH160MW-CS16-TM4	91 GR	—
			7A R	—
			7A LG	—

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]
M117	WIRE TO WIRE	TH160MW-CS16-TM4	91 GR	—
			7A R	—
			7A LG	—

JCKWA2490GB

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (LHD MODELS)		
Connector No. M118	Connector No. M119	Connector No. M124
Connector Name BCM (BODY CONTROL MODULE)	Connector Name BCM (BODY CONTROL MODULE)	Connector Name WIRE TO WIRE
Connector Type M03FB-LC	Connector Type NS16FW-CS	Connector Type TH40FG-NH

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	BAT (F/L) [LHD models]	11	R	BAT (FUSE)
2	R	POWER WINDOW POWER SUPPLY(BAT)	13	B	QND
3	W	POWER WINDOW POWER SUPPLY(GAP)			

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
			124	LG	PASSENGER DOOR SW
			150	GR	DRIVER DOOR SW
			11	W	-
			12	W	-
			13	LG	-
			14	SB	-
			15	B	-
			40	LG	-

JCKWA2491GB


POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

FOR EUROPE : Wiring Diagram - POWER WINDOW SYSTEM (RHD models) -

INFOID:000000004994560

POWER WINDOW SYSTEM (RHD MODELS)



POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	Bl	Connector No.	B63
Connector Name	WIRE TO WIRE	Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	TH80FW-CS16-TM4	Connector Type	A03FW
			
Terminal No.	63	Color of Wire	LG
		Signal Name [Specification]	-

Connector No.	D2	Connector No.	D8
Connector Name	WIRE TO WIRE	Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	TH140FW-CS15-S	Connector Type	NS16FW-CS
			
Terminal No.	63	Color of Wire	LG
		Signal Name [Specification]	-

Connector No.	B201	Connector No.	B263
Connector Name	WIRE TO WIRE	Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	TH80FW-CS16-TM4	Connector Type	A03FW
			
Terminal No.	2	Color of Wire	GR
		Signal Name [Specification]	- [RHD models]

Connector No.	D10	Connector No.	D32
Connector Name	DRIVER SIDE POWER WINDOW MOTOR	Connector Name	WIRE TO WIRE
Connector Type	NU05FW	Connector Type	TH40FW-CS15-S
			
Terminal No.	81	Color of Wire	GR
		Signal Name [Specification]	-

Connector No.	D1	Connector No.	D15
Connector Name	POWER WINDOW MAIN SWITCH	Connector Name	DRIVER SIDE POWER WINDOW MOTOR
Connector Type	NS16FW-CS	Connector Type	NU05FW
			
Terminal No.	1	Color of Wire	LG
		Signal Name [Specification]	-

Connector No.	D12	Connector No.	D16
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TH140FW-CS15-S	Connector Type	TH40FW-CS15-S
			
Terminal No.	1	Color of Wire	LG
		Signal Name [Specification]	-

JCKWA2493GB

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (RHD MODELS)

Contractor No.	D36
Contractor Name	POWER WINDOW SUB-SWITCH
Contractor Type	NS16FW-CS

Connector No.	DM0
Connector Name	PASSENGER SIDE POWER WINDOW MOTOR
Connector Type	NU08EDGY

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	THB07W-CS16-TM4

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2

Terminal No.	Order of Wire	Signal Name [String/Fraction]
1	R	-
2	W	-
3	G	-
4	L	-
5	LG	-
6	-	-
7	R	-
8	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
5	GR	- [RFID modules]

Terminal No.	Color of Wire	Signal Name [Specification]
7A	R	—

111

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	THINOW-CS16-TM4

Connector No.	MB
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	T180MM-CS16-TH4

卷之三

Terminal No.	Color of Wire	Signal Name [Specification]
100	Black	Common
101	Black	Common


Terminal No.	Color of Wire	Signal Name [Specification]
2	Black	

Terminal No.	Color of Wires	Signal Name [Specification]
1	Red	Ground
2	Blue	Ground

JCKWA2494GB

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >



JCKWA2495GB

EXCEPT FOR EUROPE

EXCEPT FOR EUROPE : Wiring Diagram - POWER WINDOW SYSTEM (LHD mod-


POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

els) -

INFOID:000000004641556

POWER WINDOW SYSTEM (LHD MODELS)





A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
PWC



POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	Bl	Connector No.	B21
Connector No.	WIRE TO WIRE	Connector No.	B201
Connector Name	DRIVER SIDE DOOR SWITCH	Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4	Connector Type	TH80FW-CS16-TM4
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
63	LG	2	LG
Signal Name [Specification]	—	Signal Name [Specification]	—

Connector No.	D1	Connector No.	D10
Connector No.	WIRE TO WIRE	Connector Name	DRIVER SIDE POWER WINDOW MOTOR
Connector Name	POWER WINDOW MAIN SWITCH	Connector Type	NU05FW-C5
Connector Type	TH140FW-CS15		
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
15	14	1	2
14	13	2	10
13	12	3	9
12	11	4	8
11	10	5	7
10	9	6	6
9	8	7	5
8	7	8	4
7	6	9	3
6	5	10	2
5	4	11	1
4	3	12	—
3	2	13	—
2	1	14	—
1	—	15	—
—	—	16	—
Signal Name [Specification]	—	Signal Name [Specification]	—

Connector No.	D31	Connector No.	D31
Connector No.	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Name	TH40FW-CS15	Connector Type	TH40FW-CS15
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	2	1	2
2	3	2	W
3	4	3	W
4	5	4	W
5	6	5	W
6	7	6	W
7	8	7	W
8	9	8	W
9	10	9	W
10	11	10	W
11	12	11	W
12	13	12	W
13	14	13	W
14	15	14	W
15	16	15	W
16	—	16	W
Signal Name [Specification]	—	Signal Name [Specification]	—

JCKWA2586GB

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]
D38	POWER WINDOW SUB-SWITCH	TH140FW-CS	3 V	-
			5 SB	-
			6 O	-
			7 LG	-
			8 B	-
			11 W	-
			14 R	-
			15 G	-
			16 L	-

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]
M5	WIRE TO WIRE	TH140MW-CS16	1 2 3 4 5 6	-
			7 8 9 10 11 12	-
			13 14 15 16	-

Connector No.	Connector Name	Connector Type	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
E106	WIRE TO WIRE	TH160FW-CS16-TM4	1 R	-	7A	GR	-	7A	R	-
			2 W	-						
			3 G	-						
			4 L	-						
			6 LG	-						
			7 R	-						
			8 B	-						

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (LHD MODELS)		
Connector No. M118	Connector No. M119	Connector No. M124
Connector Name BCM (BODY CONTROL MODULE)	Connector Name BCM (BODY CONTROL MODULE)	Connector Name WIRE TO WIRE
Connector Type M03FB-LC	Connector Type NS16FW-CS	Connector Type TH40FG-NH

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	BAT (F/L) (LHD models)	12	LG	PASSENGER DOOR SW
2	R	POWER WINDOW POWER SUPPLY(BAT)	13	GR	DRIVER DOOR SW
3	W	POWER WINDOW POWER SUPPLY(GND)	14	SB	-

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
11	R	BAT (F/L)	9	R	-
12	LG	PASSENGER DOOR SW	10	W	-
13	GR	DRIVER DOOR SW	11	V	-
14	SB	-	12	W	-
15	B	-	13	LG	-
40	LG	-	14	SB	-
			15	B	-
			40	LG	-

JCKWA2588GB


EXCEPT FOR EUROPE : Wiring Diagram - POWER WINDOW SYSTEM (RHD mod-

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

els) -

INFOID:0000000004936543



PWC-155

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	Bl	Connector No.	B63
Connector Name	WIRE TO WIRE	Connector Name	PASSENGER SIDE DOOR SWITCH
Connector Type	TH80FW-CS16-TM4	Connector Type	A03FW
			
Terminal No.	63	Color of Wire	LG
		Signal Name [Specification]	-
Terminal No.	2	Color of Wire	LG
		Signal Name [Specification]	-

Connector No.	D2	Connector No.	D8
Connector Name	WIRE TO WIRE	Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	TH140FW-CS15-S	Connector Type	NS16FW-CS
			
Terminal No.	63	Color of Wire	LG
		Signal Name [Specification]	-
Terminal No.	2	Color of Wire	LG
		Signal Name [Specification]	-

Connector No.	B201	Connector No.	B263
Connector Name	WIRE TO WIRE	Connector Name	DRIVER SIDE DOOR SWITCH
Connector Type	TH80FW-CS16-TM4	Connector Type	A03FW
			
Terminal No.	2	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	81	Color of Wire	GR
		Signal Name [Specification]	-
Connector No.	D10	Connector No.	D32
Connector Name	DRIVER SIDE POWER WINDOW MOTOR	Connector Name	WIRE TO WIRE
Connector Type	NU05FW	Connector Type	TH40FW-CS15-S
			
Terminal No.	1	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	2	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	3	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	4	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	5	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	6	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	7	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	8	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	9	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	10	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	11	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	12	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	13	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	14	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	15	Color of Wire	GR
		Signal Name [Specification]	-
Terminal No.	16	Color of Wire	GR
		Signal Name [Specification]	-

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (RHD MODELS)

Contractor No.	D36
Contractor Name	POWER WINDOW SUB-SWITCH
Contractor Type	NS16FW-CS

Connector No.	DM0
Connector Name	PASSENGER SIDE POWER WINDOW MOTOR
Connector Type	NJU08FDGY

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	THB07W-CS16-TM4

Connector No.	M1
Connector Name	FUSE BLOCK (J/E)
Connector Type	NS0607W-M2

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.
3	V	-	1
5	SB	-	2
6	O	-	3
7	LG	-	4
8	B	-	6
11	W	-	7
14	R	-	8
15	G	-	
16	L	-	

Terminal No.	Color of Wire	Signal Name [Specification]
5	GR	- [RFID models]

Terminal No.	Color of Wire	Signal Name [Specification]
7A	R	—

123

Connector No.	MB
Connector Name	WIRE TO WIRE

Connector No.	M117
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
a	□	—
b	□	—

Terminal	No.	Color of Wire	Signal Name [Specification]
91	CD	—	[DUD mode]

JCKWA2590GB

PWC-157

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	M119	Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS	Connector Type	TH40FW-CS15

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Connector No.	M127
Connector Name	WIRE TO WIRE
Connector Type	TH46MMW-CS15

Terminal No.	Color of Wire	Signal Name [Specification]
9	R	-
10	W	-
11	V	-
12	O	-
13	LG	-
14	SB	-
15	B	-
40	LG	-

Terminal No.	Color of Wire	Signal Name [Specification]
124	LG	PASSENGER DOOR SW
150	GR	DRIVER DOOR SW

Terminal No.	Color of Wire	Signal Name (Specification)
11	R	BAT (FUSE)
13	B	GND

Terminal No.	Color of Wire	Serial Name [Specification]
1	W	BAT (f.1) (RID, models)
2	R	POWER WINDOW POWER SUPPLY (BAT)
3	W	POWER WINDOW POWER SUPPLY (FRAP (IGN))

JCKWA2591GB

INFOID:0000000004641557

Fail-Safe

FAIL-SAFE CONTROL

Fail-safe control is activated when the actual glass position that is out of the specified value is detected compared to the fully closed position memorized in module in power window motor, or when a malfunction is detected in the encoder signal that indicates UP or DOWN speed and direction of door glass.

POWER WINDOW MOTOR

< ECU DIAGNOSIS INFORMATION >

Malfunction	Malfunction condition
Pulse direction malfunction (opposite backlash pulse detection)	When a pulse signal indicates that the window is moving in the opposite direction against the power window motor is detected for the specified value or more, while door glass is being operated UP or DOWN.
Pulse sensor (Hall IC) malfunction (one side pulse shut-off detection)	When one pulse signal that is the specified value or more is detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Both pulse sensor malfunction (both sides pulse shut-off detection)	When both pulse signals are not detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 1 (UP overrun)	When the actual door glass position that is out of the specified value is detected compared to the door glass fully closed position memorized in module, while door glass is being operated UP. (Actual door glass fully closed position is detected to be higher than the memorized position in module for the specified value or more.)
Glass recognition position malfunction 2 (Out of memorized area)	When the actual door glass position that is out of the specified value is detected compared to the door glass fully closed position memorized in module, while door glass is being operated UP. (Actual door glass fully closed position is detected to be lower than the memorized position in module for the specified value or more.)
Glass recognition position malfunction 3 (Full stroke malfunction)	When pulse count that is out of the door glass full stroke value or more is detected, while door glass is being operated UP.
Fully closed position update malfunction	When door glass is continuously operated UP and DOWN for the specified value or more without fully closing door glass.

In fail-safe control, the system changes to a non-initialized condition and the following functions do not operate.

- AUTO UP operation
- Anti-pinch function
- Timer function
- Automatic window adjusting function

When fail-safe control is activated, perform initializing operation to recover. If a malfunction is detected in power window motor, fail-safe control is activated again.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P