


SYSTEM DESCRIPTION

HEADLAMP SYSTEM

System Diagram

INFOID:000000004785222



System Description

INFOID:000000004785223

OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.

HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.


HEADLAMP SYSTEM

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Component Parts Location

INFOID:000000004785224



JPLIA1167ZZ

1. Headlamp (HI)	2. Headlamp (LO)	3. Combination switch
4. BCM	5. IPDM E/R	6. High beam indicator lamp
A. Dash side lower (passenger side)	B. Engine room dash panel (RH)	C. On the combination meter

Component Description

INFOID:000000004785225

EXL

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges that the headlamp is turned ON according to the vehicle condition. Requests the headlamp relay (HI/LO) ON to IPDM E/R (with CAN communication). Requests the high beam indicator lamp ON to the combination meter (with CAN communication).
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-101, "System Diagram" .
Combination meter (High beam indicator lamp)	Turns the high beam indicator lamp ON according to the request from BCM (with CAN communication).
Front combination lamp assembly	<ul style="list-style-type: none"> HID control unit Xenon bulb Refer to EXL-310, "Description" .

HEADLAMP AIMING CONTROL SYSTEM (AUTO)


< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

HEADLAMP AIMING CONTROL SYSTEM (AUTO)

System Diagram

INFOID:0000000004992270



JPLIA0171GB

System Description

INFOID:0000000004992271

OUTLINE

- Headlamp aiming control system is controlled by auto levelizer control unit.
- Auto levelizer control unit controls the headlamp light axis height appropriately depending on the vehicle rear height.
- Auto levelizer control unit detects the vehicle condition necessary for the aiming motor control with the following signals.
 - Sensor lever signal (detected by the sensor lever)
 - Tail lamp signal (inputted from IPDM E/R)
 - Vehicle speed signal (8-pulse) (inputted from combination meter)

HEADLAMP AUTO AIMING OPERATION

- Auto levelizer control unit calculates vehicle pitch angle from sensor lever signal and determines the necessary correction to compensate the deviation from standard light axis position.
- Auto levelizer control unit outputs aiming motor drive signal when operating conditions are satisfied.

Operating condition

- Ignition switch ON
- Tail lamp ON
- Auto levelizer control unit changes the aiming motor drive signal when any of the correcting condition is detected. Output is maintained if other condition is detected.

Correcting condition

- Tail lamp is turned ON.
- Vehicle posture becomes stable after the vehicle posture change is detected with the tail lamp ON and the vehicle stopped.
- Vehicle speed is maintained with the tail lamp ON and the vehicle driven.

CAUTION:

Adjusted axis position may differ from the preset position although the headlamp auto aiming activates properly when the suspension is replaced or worn.


HEADLAMP AIMING CONTROL SYSTEM (AUTO)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Component Parts Location

INFOID:000000004992272



1. Combination meter	2. IPDM E/R	3. Aiming motor
4. Auto levelizer control unit		
A. Engine room dash panel (RH)	B. Front combination lamp (back)	C. Rear suspension member (LH)

Component Description

INFOID:000000004992273

EXL

Part	Description
Auto levelizer control unit	Refer to EXL-290, "Description" .
Aiming motor	Refer to EXL-312, "Description" .
IPDM E/R	Outputs the tail lamp signal to auto levelizer control unit.
Combination meter	Outputs the vehicle speed signal (8-pulse) to auto levelizer control unit.

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

System Diagram

INFOID:0000000004992274



System Description

INFOID:0000000004992275

OUTLINE

Turn signal and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is turned ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is turned ON. BCM blinks the hazard warning lamp.

TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter with CAN communication while the turn signal lamp and the hazard warning lamp operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator status signal.

HIGH FLASHER OPERATION (FAIL-SAFE)

- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while operating the hazard warning lamp.


TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Component Parts Location

INFOID:000000004992276



NNLIA0057ZZ

1. Hazard switch	2. Side turn signal lamp	3. Front turn signal lamp
4. Combination switch	5. Rear turn signal lamp	6. BCM
7. Turn signal indicator lamp		
A. Dash side lower (Passenger side)	B. On the combination meter	

Component Description

INFOID:000000004992277

EXL

M

N

O

P

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges the blinks of the turn signal lamp and the hazard warning lamp from each switch status. The applicable turn signal lamp blinks. Requests the turn signal indicator lamp blink to the combination meter (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-101, "System Diagram" .
Hazard switch (Set-up switch)	Refer to EXL-320, "Description" .
Combination meter (Turn signal indicator lamp & buzzer)	Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (with CAN communication).

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

System Diagram

INFOID:0000000004785246



System Description

INFOID:0000000004785247

OUTLINE

Parking, license plate and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter with CAN communication according to the ON/OFF condition of the parking, license plate and tail lamps.

Parking, license plate and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking lamp, the license plate and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.


PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Component Parts Location

INFOID:000000004785248



NNLIA0058ZZ

1. Parking lamp	2. Combination switch	3. Tail lamp
4. License plate lamp	5. BCM	6. IPDM E/R
7. Tail lamp indicator lamp		
A. Dash side lower (passenger side)	B. Engine room dash panel (RH)	C. On the combination meter

Component Description

INFOID:000000004785249

EXL

M

N

O

P

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges the ON/OFF status of the clearance, license plate and tail lamps according to the vehicle condition. Requests the tail lamp relay ON to IPDM E/R (with CAN communication).
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-101, "System Diagram" .
Combination meter (Tail lamp indicator lamp)	Turns the tail lamp indicator lamp ON according to the request from BCM (with CAN communication).

BACK-UP LAMP SYSTEM


< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

BACK-UP LAMP SYSTEM

System Diagram

INFOID:0000000004992278



NNLIB0014GB

System Description

INFOID:0000000004992279

OUTLINE

Back-up lamp is controlled by back-up lamp relay control function of TCM.

BACK-UP LAMP OPERATION

- TCM detects the A/T shift selector condition.
- TCM turns the back-up lamp relay ON according to the back-up lamp ON condition.

Back-up lamp ON condition.

- Ignition switch ON
- Shift position "R"


BACK-UP LAMP SYSTEM

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Component Parts Location

INFOID:000000004992280



1. A/T shift selector	2. Back-up lamp	3. TCM relay
4. Back-up lamp relay	5. TCM	
A. Inside of rear wheel house finisher (LH)	B. Inside of trunk front finisher	

INFOID:000000004992281

EXL

Component Description

M

N

O

P

Part	Description
TCM	<ul style="list-style-type: none">Detects the A/T shift selector condition.Judges the back-up lamp relay ON/OFF by shift lever position status.
A/T shift selector	Refer to TM-13, "Main Device (NHPC)".

EXTERIOR LAMP BATTERY SAVER SYSTEM


< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

EXTERIOR LAMP BATTERY SAVER SYSTEM

System Diagram

INFOID:0000000004785266



System Description

INFOID:0000000004785267

OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

Control by IPDM E/R

- Relay control function
- BCM turns the exterior lamp* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamp ON.

*: Headlamp (HI/LO), parking lamp, tail lamp and license plate lamp

EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM turns the exterior lamps OFF (battery saver is activated) when all of following condition.

- Exterior lamps ON
- BCM power supply position is turned from "RUN" → "LOCK", "OFF" or "ACC"
- Front door switch (driver side) is turned from OFF → ON (door opening)

NOTE:

When any of following condition (after the exterior lamp battery saver is activated), exterior lamps can be turned ON.

- BCM power supply position is turned from "LOCK", "OFF" or "ACC" → "RUN"
- Lighting switch is turned from OFF → 1ST/2ND


EXTERIOR LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Component Parts Location

INFOID:000000004785268



1. Front door switch (Driver side)	2. Combination switch	3. Combination meter
4. BCM	5. IPDM E/R	6. Daytime running light relay (With daytime running light system)
A. Dash side lower (Passenger side)	B. Engine room dash panel (RH)	C. Engine room dash panel (RH)

NNLIA0077ZZ

Component Description

INFOID:000000004785269

EXL

M

N

O

P

Part	Description
BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Judges the exterior lamp OFF according to the vehicle condition. Requests each relay OFF to IPDM E/R (with CAN communication).
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to BCS-101, "System Diagram" .
Front door switch (driver side)	Inputs the door switch signal to BCM.

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000004994250

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> • Read and save the vehicle specification. • Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x*2	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITIONER*1			
• Intelligent Key system • Engine start system	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Trunk lid open	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x

NOTE:

- *1: This item is displayed, but is not used.
- *2: At models with light and rain sensor this mode is displayed, but is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC	While turning power supply position from "LOCK" to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and shift lever is except P position.)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> The number is 0 when a malfunction is detected now. The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

HEADLAMP

HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:000000004785276

WORK SUPPORT

Service item	Setting item	Setting
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Service item	Setting item	Setting
ILL DELAY SET	MODE 1	NOTE: The item is indicated, but not operated.
	MODE 2	
	MODE 3	
	MODE 4	
	MODE 5	
	MODE 6	
	MODE 7	
	MODE 8	

*: Factory setting

DATA MONITOR

Monitor item [Unit]	Description
PUSH SW [On/Off]	The switch status input from push-button ignition switch
ENGINE STATE [Stop/Stall/Crank/Run]	The engine status received from ECM with CAN communication
VEH SPEED 1 [km/h]	The value of the vehicle speed received from combination meter with CAN communication
KEY SW-SLOT [On/Off]	Key switch status input from key slot
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW1 [On/Off]	
HEAD LAMP SW2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	NOTE: The item is indicated, but not monitored.
FR FOG SW [On/Off]	
RR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	The switch status input from driver side door switch
DOOR SW-AS [On/Off]	The switch status input from passenger side door switch
DOOR SW-RR [On/Off]	NOTE: The item is indicated, but not monitored.
DOOR SW-RL [On/Off]	NOTE: The item is indicated, but not monitored.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Monitor item [Unit]	Description
DOOR SW-BK [On/Off]	NOTE: The item is indicated, but not monitored.
OPTICAL SENSOR [V]	NOTE: The item is indicated, but not monitored.

ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R and combination meter with CAN communication to turn the tail lamp and tail lamp indicator lamp ON.
	Off	Stops the position light request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal to IPDM E/R and combination meter with CAN communication to turn the headlamp (HI) and high beam indicator lamp.
	Low	Transmits the low beam request signal to IPDM E/R with CAN communication to turn the headlamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP	On	NOTE: The item is indicated, but cannot be tested.
	Off	
RR FOG LAMP	On	NOTE: The item is indicated, but cannot be tested.
	Off	
DAYTIME RUNNING LIGHT	On	NOTE: The item is indicated, but cannot be tested.
	Off	
CORNERRING LAMP	RH	NOTE: The item is indicated, but cannot be tested.
	LH	
	Off	
ILL DIM SIGNAL	On	NOTE: The item is indicated, but cannot be tested.
	Off	

FLASHER

FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:0000000004785277

EXL

WORK SUPPORT

Service item	Setting item	Setting	
HAZARD ANSWER BACK	Lock Only*	With locking only	Sets the hazard warning lamp answer back function when the door is lock/unlock with the request switch or the key fob.
	Unlk Only	With unlocking only	
	Lock/Unlk	With locking/unlocking	
	Off	Without the function	

*: Factory setting

DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from the request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from the request switch (passenger side)

DIAGNOSIS SYSTEM (BCM)

[XENON (FOR GENERAL AREAS)]

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
PUSH SW [On/Off]	The switch status input from the push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch condition that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Lock signal status received from the remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from the remote keyless entry receiver
RKE-PANIC [On/Off]	NOTE: The item is indicated, but not monitored.

ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to blink the right side turn signal lamps.
	LH	Outputs the voltage to blink the left side turn signal lamps.
	Off	Stops the voltage to turn the turn signal lamps OFF.

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:0000000004992313

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Tail lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

CAUTION:

Close passenger door.

4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-65, "Component Function Check"](#) (With super lock), [DLK-416, "Component Function Check"](#) (Without super lock).
- Do not start the engine.

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 5 steps are repeated 3 times.

EXL

Operation sequence	Inspection location	Operation
1	Front wiper	LO for 5 seconds → HI for 5 seconds
2	• Parking lamps • License plate lamps • Tail lamps	10 seconds
3	Headlamps	LO for 10 seconds → HI ON ⇔ OFF 5 times
4	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
5*	Cooling fan	MID for 5 seconds → HI for 5 seconds

*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

M

N

O


P

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Any of the following components do not operate <ul style="list-style-type: none"> • Parking lamps • License plate lamps • Tail lamps • Headlamp (LO, HI) • Front wiper (LO, HI) 	Perform auto active test. Does the applicable system operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES	<ul style="list-style-type: none"> • A/C amp. signal input circuit • CAN communication signal between A/C amp. and ECM • CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> • Cooling fan • Harness or connector between cooling fan and cooling fan control module • Cooling fan control module • Harness or connector between IPDM E/R and cooling fan control module • Cooling fan relay • Harness or connector between IPDM E/R and cooling fan relay • IPDM E/R

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

CONSULT-III Function (IPDM E/R)

INFOID:000000004992314

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

SELF DIAGNOSTIC RESULT

Refer to [EXL-417. "DTC Index"](#).

DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIG- NALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	NOTE: The item is indicated, but not monitored.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper stop position signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST ON/INHI ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the A/T shift selector (detention switch) judged by IPDM E/R.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

Monitor Item [Unit]	MAIN SIG- NALS	Description
S/L RLY -REQ [Off/On]		Displays the status of the steering lock relay request signal received from BCM via CAN communication.
S/L STATE [LOCK/UNLOCK/UNKWN]		Displays the status of the steering lock judged by IPDM E/R.
DTRL REQ [Off/On]	×	Displays the status of the daytime running light request signal received from BCM via CAN communication. NOTE: This item is monitored only the vehicle with daytime running light system.
OIL P SW [Open/Close]		NOTE: The item is indicated, but not monitored.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		Displays the status of the headlamp washer request signal received from BCM via CAN communication. NOTE: This item is monitored only the vehicle with headlamp washer system.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off/On]		NOTE: The item is indicated, but not monitored.

ACTIVE TEST

Test item

Test item	Operation	Description
CORNERRING LAMP	Off	NOTE: The item is indicated, but cannot be tested.
	LH	
	RH	
HORN	On	Operates horn relay 1 and horn relay 2 for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Outputs 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Outputs 80% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Outputs 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	Off	OFF
	On	Operates the headlamp washer relay for 1 second.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	NOTE: The item is indicated, but cannot be tested.

DIAGNOSIS SYSTEM (HEADLAMP LEVELIZER)

< SYSTEM DESCRIPTION >

[XENON (FOR GENERAL AREAS)]

DIAGNOSIS SYSTEM (HEADLAMP LEVELIZER)

CONSULT-III Functions (HEADLAMP LEVELIZER)

INFOID:0000000004992283

Function item

Diagnosis mode	Description
ECU IDENTIFICATION	Allows confirmation of auto levelizer control unit part number.
SELF DIAGNOSTIC RESULT	Displays the diagnosis results judged by auto levelizer control unit.
WORK SUPPORT	Performs settings on sensors.
DATA MONITOR	Displays input data for headlamp auto aiming motor control unit in real time.
ACTIVE TEST	Transmits a drive signal to the load to check their operation.
CONFIGURATION	Writes the vehicle specification when replacing auto levelizer control unit.

WORK SUPPORT

Work item	Setting details
SENSOR INITIALIZE	Adjusts sensor lever signal output under unladen conditions.

DATA MONITOR

Monitor item [Unit]	Display item
INT SEN VALUE [%]	Displays the sensor lever angle corresponding to the maximum value of sensor lever angle that is recognized with auto levelizer control unit by ratio
ACT OUTPUT [%]	Displays the control value of aiming motor drive signal that is calculated by auto levelizer control unit with the ratio corresponding to the ignition power supply
ACT MEASURED [%]	Displays the measured value of aiming motor drive signal that is output from auto levelizer control unit with the ratio corresponding to ignition power supply
SPEED SIG [km/h]	Displays the vehicle speed judged from vehicle speed signal (8-pulse) that is input to auto levelizer control unit
LIGHT SIGNAL [V]	Displays the status judged from tail lamp signal that is input to auto levelizer control unit
INT SEN VOLT [V]	Displays the ignition power supply status that is input to auto levelizer control unit
EXT SEN VOLT [V]	NOTE: The item is indicated, but not monitored.
EXT SEN SIG [V]	NOTE: The item is indicated, but not monitored.

ACTIVE TEST

Test item	Operation item	Operation status
LAMP TEST	MIN	Moves the light axis to the highest position.
	MID	Moves the light axis to the initial position.
	MAX	Moves the light axis to the lowest position.