

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
 N
 O
 P

CONTENTS

BASIC INSPECTION	5	HEATED SEAT CONTROL UNIT	16
DIAGNOSIS AND REPAIR WORKFLOW	5	HEATED SEAT CONTROL UNIT : Diagnosis Procedure	16
WorkFlow	5		
SYSTEM DESCRIPTION	6	HEATED SEAT SWITCH	18
POWER SEAT	6	HEATED SEAT SWITCH : Diagnosis Procedure	18
System Description	6	POWER RETURN SWITCH	21
Component Parts Location	6	LH	21
Component Description	7	LH : Description	21
HEATED SEAT	8	LH : Component Function Check	21
System Diagram	8	LH : Diagnosis Procedure	21
System Description	8	LH : Component Inspection	22
Component Parts Location	9	RH	22
Component Description	9	RH : Description	22
LUMBAR SUPPORT	10	RH : Component Function Check	22
System Description	10	RH : Diagnosis Procedure	22
Component Parts Location	10	RH : Component Inspection	23
Component Description	10	REAR SEATBACK SWITCH	25
REAR SEATBACK RELEASE CONTROL	11	LH	25
System Description	11	LH : Description	25
Component Parts Location	11	LH : Component Function Check	25
Component Description	11	LH : Diagnosis Procedure	25
REAR SEATBACK POWER RETURN SYSTEM	12	LH : Component Inspection	26
System Diagram	12	RH	26
System Description	12	RH : Description	26
Component Parts Location	15	RH : Component Function Check	26
Component Description	15	RH : Diagnosis Procedure	26
DTC/CIRCUIT DIAGNOSIS	16	RH : Component Inspection	27
POWER SUPPLY AND GROUND CIRCUIT	16	PRIMARY POSITION LIMIT SWITCH	29
REAR SEATBACK POWER RETURN CONTROL UNIT	16	LH	29
REAR SEATBACK POWER RETURN CONTROL UNIT : Diagnosis Procedure	16	LH : Description	29
		LH : Component Function Check	29
		LH : Diagnosis Procedure	29
		LH : Component Inspection	30

RH	30	HEATED SEAT RELAY	51
RH : Description	30	Description	51
RH : Component Function Check	30	Component Function Check	51
RH : Diagnosis Procedure	31	Diagnosis Procedure	51
RH : Component Inspection	32	Component Inspection	52
RETURN COMPLETE LIMIT SWITCH	33	HEAT SENSOR	53
LH	33	DRIVER SIDE	53
LH : Description	33	DRIVER SIDE : Description	53
LH : Component Function Check	33	DRIVER SIDE : Component Function Check	53
LH : Diagnosis Procedure	33	DRIVER SIDE : Diagnosis Procedure	53
LH : Component Inspection	34	DRIVER SIDE : Component Inspection	54
RH	34	PASSENGER SIDE	55
RH : Description	34	PASSENGER SIDE : Description	55
RH : Component Function Check	34	PASSENGER SIDE : Component Function Check	55
RH : Diagnosis Procedure	35	PASSENGER SIDE : Diagnosis Procedure	55
RH : Component Inspection	36	PASSENGER SIDE : Component Inspection	57
MOTOR SENSOR	37	SEAT CUSHION HEATER	58
LH	37	DRIVER SIDE	58
LH : Description	37	DRIVER SIDE : Description	58
LH : Component Function Check	37	DRIVER SIDE : Component Function Check	58
LH : Diagnosis Procedure	37	DRIVER SIDE : Diagnosis Procedure	58
LH : Component Inspection	37	DRIVER SIDE : Component Inspection	59
RH	39	PASSENGER SIDE	59
RH : Description	39	PASSENGER SIDE : Description	59
RH : Component Function Check	39	PASSENGER SIDE : Component Function Check	59
RH : Diagnosis Procedure	39	PASSENGER SIDE : Diagnosis Procedure	59
RH : Component Inspection	39	PASSENGER SIDE : Component Inspection	61
POWER RETURN MOTOR	42	SEATBACK HEATER	62
LH	42	DRIVER SIDE	62
LH : Description	42	DRIVER SIDE : Description	62
LH : Component Function Check	42	DRIVER SIDE : Component Function Check	62
LH : Diagnosis Procedure	42	DRIVER SIDE : Diagnosis Procedure	62
LH : Component Inspection	42	PASSENGER SIDE	62
RH	43	PASSENGER SIDE : Description	62
RH : Description	43	PASSENGER SIDE : Component Function Check	62
RH : Component Function Check	43	PASSENGER SIDE : Diagnosis Procedure	62
RH : Diagnosis Procedure	43	PASSENGER SIDE : Component Inspection	62
VEHICLE SPEED SIGNAL CIRCUIT	45	HEATED SEAT SWITCH INDICATOR	64
Description	45	DRIVER SIDE	64
Component Function Check	45	DRIVER SIDE : Description	64
Diagnosis Procedure	45	DRIVER SIDE : Component Function Check	64
Component Inspection	45	DRIVER SIDE : Diagnosis Procedure	64
Component Inspection	45	DRIVER SIDE : Component Inspection	64
HEATED SEAT SWITCH	47	PASSENGER SIDE	65
DRIVER SIDE	47	PASSENGER SIDE : Description	65
DRIVER SIDE : Description	47	PASSENGER SIDE : Component Function Check	65
DRIVER SIDE : Component Function Check	47	DRIVER SIDE : Diagnosis Procedure	65
DRIVER SIDE : Diagnosis Procedure	47	DRIVER SIDE : Component Inspection	65
DRIVER SIDE : Component Inspection	48	PASSENGER SIDE	65
DRIVER SIDE : Component Inspection	48	PASSENGER SIDE : Description	65
PASSENGER SIDE	48	PASSENGER SIDE : Component Function Check	65
PASSENGER SIDE : Description	48	PASSENGER SIDE : Diagnosis Procedure	65
PASSENGER SIDE : Component Function Check	48	PASSENGER SIDE : Component Inspection	65
PASSENGER SIDE : Diagnosis Procedure	48	PASSENGER SIDE	65
PASSENGER SIDE : Component Inspection	49	PASSENGER SIDE : Description	65

PASSENGER SIDE : Component Inspection	65	
POWER SEAT	67	
Wiring Diagram - POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER) -	67	A
Wiring Diagram - POWER SEAT FOR PASSENGER SIDE -	72	B
LUMBAR SUPPORT	77	C
Wiring Diagram - LUMBAR SUPPORT SYSTEM	77	D
REAR SEATBACK RELEASE CONTROL	82	E
Wiring Diagram - REAR SEATBACK RELEASE CONTROL -	82	F
ECU DIAGNOSIS INFORMATION	87	G
REAR SEAT BACK POWER RETURN CONTROL UNIT	87	H
Reference Value	87	I
Wiring Diagram - REAR SEATBACK POWER RETURN SYSTEM -	90	J
Fail-safe	97	K
HEATED SEAT CONTROL UNIT	99	L
Reference Value	99	M
Wiring Diagram - HEATED SEAT SYSTEM -	100	N
SYMPTOM DIAGNOSIS	108	O
REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE	108	P
BOTH SIDES	108	SE
BOTH SIDES : Diagnosis Procedure	108	K
LH	108	L
LH : Diagnosis Procedure	108	M
RH	109	N
RH : Diagnosis Procedure	109	O
MALFUNCTION DETECTION BUZZER SOUNDS DURING POWER RETURN MOTOR INVERSE ROTATION	111	P
LH	111	SE
LH : Diagnosis Procedure	111	K
RH	111	L
RH : Diagnosis Procedure	111	M
DOES NOT RETURN BUT MALFUNCTION DETECTION BUZZER SOUNDS	113	N
LH	113	O
LH : Diagnosis Procedure	113	P
RH	113	SE
RH : Diagnosis Procedure	113	K
ANTI-PINCH FUNCTION DOES NOT OPERATE	114	L
Diagnosis Procedure	114	M
HEATED SEAT DOES NOT OPERATE	115	N
BOTH SIDES	115	O
BOTH SIDES : Diagnosis Procedure	115	P
DRIVER SIDE	115	SE
DRIVER SIDE : Diagnosis Procedure	115	K
PASSENGER SIDE	116	L
PASSENGER SIDE : Diagnosis Procedure	116	M
SEATBACK HEATER ONLY DOES NOT OPERATE	117	N
DRIVER SIDE	117	O
DRIVER SIDE : Diagnosis Procedure	117	P
PASSENGER SIDE	117	SE
PASSENGER SIDE : Diagnosis Procedure	117	K
CANNOT ADJUST HEATED SEAT TEMPERATURE	118	L
DRIVER SIDE	118	M
DRIVER SIDE : Diagnosis Procedure	118	N
PASSENGER SIDE	118	O
PASSENGER SIDE : Diagnosis Procedure	118	P
HEATED SEAT SWITCH INDICATOR DOES NOT TURN ON	119	SE
DRIVER SIDE	119	K
DRIVER SIDE : Diagnosis Procedure	119	L
PASSENGER SIDE	119	M
PASSENGER SIDE : Diagnosis Procedure	119	N
SQUEAK AND RATTLE TROUBLE DIAGNOSES	120	O
Work Flow	120	P
Inspection Procedure	122	SE
Diagnostic Worksheet	124	K
PRECAUTION	126	L
PRECAUTIONS	126	M
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	126	N
Precaution Necessary for Steering Wheel Rotation after Battery Disconnect	126	O
Service Notice	127	P
Precaution for Work	127	SE
PREPARATION	128	K
PREPARATION	128	L
Special Service Tool	128	M

Commercial Service Tool	128
REMOVAL AND INSTALLATION	129
FRONT SEAT	129
Exploded View	129
Removal and Installation	132
Disassembly and Assembly	133
REAR SEAT	140
Exploded View	140
Removal and Installation	141
Disassembly and Assembly	143
REAR SEAT BACK POWER RETURN CONTROL UNIT	147
Exploded View	147
Removal and Installation	147
HEATED SEAT CONTROL UNIT	148
Exploded View	148
Removal and Installation	148
POWER SEAT SWITCH	149
Exploded View	149
Removal and Installation	149
LUMBAR SUPPORT SWITCH	150
Exploded View	150
Removal and Installation	150
HEATED SEAT SWITCH	151
Exploded View	151
Removal and Installation	151
POWER RETURN SWITCH	152
Exploded View	152
Removal and Installation	152
REAR SEATBACK SWITCH	153
Exploded View	153
Removal and Installation	153
REAR SEATBACK RELEASE SWITCH	154
Exploded View	154
Removal and Installation	154

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

WorkFlow

INFOID:000000005172713

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2. REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 3.

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

POWER SEAT

System Description

INFOID:000000005172714

BCM can operate regardless of the ignition switch position, because battery power is supplied at all times to power seat switch.

SLIDING OPERATION

While operating the sliding switch located in power seat switch, sliding motor operates and makes possible the seat front and back position adjustment.

RECLINING OPERATION


While operating the reclining switch located in power seat switch, reclining motor operates and makes possible the seat back forward and backward position adjustment.

LIFTING OPERATION

While operating the lifting switch located in power seat switch, lifting motor operates and makes possible the seat cushion up and down position adjustment.

Component Parts Location

INFOID:000000005172715



JMJA1540ZZ

1. Sliding switch and lifting switch	2. Reclining switch	3. Reclining motor
4. Lifting motor (rear)	5. Lifting motor (front)	6. Sliding motor
A. View with seat cushion pad and seat back pad are removed.		B. Backside of seat cushion

POWER SEAT

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000005172716

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P


Item	Function
BCM	Supplies at all times the power received from battery to power seat switch
Power seat switch	Built-in reclining switch, sliding switch and lifting switch, controls the power supplied to each motor
Reclining motor	With the power supplied from power seat switch, operates forward and backward movement of seatback
Sliding motor	With the power supplied from power seat switch, operates forward and backward slide of seat
Lifting motor (front/rear)	With the power supplied from power seat switch, operates up and down movement of seat cushion

HEATED SEAT

< SYSTEM DESCRIPTION >

HEATED SEAT

System Diagram



INFOID:0000000005531536

JMJIA3352GB

System Description

INFOID:0000000005531537

- Heated seat is activated by heated seat switch while ignition switch is ON, and has the function to warm seat cushion and seatback.
- Heated seat equips the 6-stage temperature adjustment function that adjusts temperature by operating heated seat switch to the optimal position.
- Heated seat equips a thermostat in heater unit to prevent heater unit overheating.

OPERATION DESCRIPTION


- When operating heated seat switch to any position between 1 and 6 while ignition switch is ON, indicator illuminates, heated seat control unit supplies power supply to heater unit, and warms seat cushion and seatback.
- Heat sensor that is built in seat cushion heater detects seat cushion heater temperature and outputs to heated seat control unit.
- Heated seat control unit monitors the heated seat switch position and heater sensor temperature, and interrupts power supply to heater unit when the heat sensor temperature reaches preset temperature.
- Heated seat control unit adjusts temperature to preset temperature by supplying or interrupting power supply to heater unit.

HEATED SEAT

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000005531538



JMJIA2336ZZ

1. Heated seat switch	2. Seatback heater	3. Seat cushion heater
4. Heated seat relay	5. Heated seat control unit	
A. Behind cluster lid C	B. Backside of seat cushion	

SE

Component Description

INFOID:000000005531539

K

L

M

N

O

P

Item	Function
Heated seat switch	<ul style="list-style-type: none">• Adjusts heated seat temperature and deactivates heated seat• Equips indicator that indicates the operating condition
Seat cushion heater	<ul style="list-style-type: none">• Warms seat cushion• Contains heater sensor that outputs seat cushion heater temperature to heated seat control unit
Seatback heater	Warms seatback
Heated seat relay	Supplies power to the heated seat being controlled by ignition power supply
Heated seat control unit	Controls heated seat temperature and is independently placed in each seat cushion (driver seat and passenger seat)

LUMBAR SUPPORT

< SYSTEM DESCRIPTION >

LUMBAR SUPPORT


System Description

INFOID:0000000005172720

- Lumbar support can operate regardless of the ignition switch position because battery power is supplied to it at all times.
- While operating the lumbar support switch, lumbar support motor operates which allows forward and backward operation of seatback support.

Component Parts Location

INFOID:0000000005172721



1. Lumbar support switch 2. Lumbar support motor
A. View with seat back pad is removed

Component Description

INFOID:0000000005172722

Item	Function
Lumbar support switch	Controls the power supplied to lumbar support motor
Lumbar support motor	With the power supplied from lumbar support switch, operates forward and backward movement of seatback support device

REAR SEATBACK RELEASE CONTROL

< SYSTEM DESCRIPTION >

REAR SEATBACK RELEASE CONTROL


System Description

INFOID:000000005172723

- Rear seatback release control is composed of rear seatback release switch and rear seatback release actuator
- When rear seatback release switch is pressed, the rear seatback release actuator operate in order to unlock the rear seatback lock
- When the rear seatback is unlocked, the spring located inside the rear seat device rebound, and the rear seatback return to the fall down position

Component Parts Location

INFOID:000000005172724



1. Rear seatback release switch (LH)
2. Rear seatback release actuator (RH)
3. Rear seatback release relay (LH)
4. Rear seatback release relay (RH)

A. In seatback
B. Behind of rear seat (RH)

Component Description

INFOID:000000005172725

Item	Function
Rear seatback release switch	Release the rear seatback when it is locked
Rear seatback release actuator	Press the rear seatback release switch to release the rear seatback when it is locked


REAR SEATBACK POWER RETURN SYSTEM

< SYSTEM DESCRIPTION >

REAR SEATBACK POWER RETURN SYSTEM

System Diagram

INFOID:000000005172726



JMJA1539GB

System Description

INFOID:000000005172727

DESCRIPTION

Rear Seatback Release Control

- Rear seatback release control is composed of rear seatback release switch and rear seatback release actuator
- When rear seatback switch is pressed in release direction, the rear seatback release actuator operate in order to unlock the rear seatback lock
- When the rear seatback is unlocked, the spring located inside the rear seat device rebound, and the rear seatback return to the fall down position.

Rear Seatback Power Return System

- The rear seat back power return system is the system that enables the return operation of the left and right rear seatbacks independently by pressing and holding the power return switch or the rear seatback switch in the UP direction.
- As for the safety mechanism, the reverse operation is performed if the switch is released during the return operation. The anti-pitch function is installed so that the automatic reverse operation is performed if the pinching of foreign materials between the left and right rear seatbacks is detected.

OPERATION DESCRIPTION

The rear seatback power return system consists of the sector gear that transmits the movement information of rear seatback power return control unit, power return switch, power return motor, motor sensor, primary position limit switch, return complete limit switch and power return motor.

Return Operation Starting Condition

The rear seat back return operation starts when all of the following conditions are satisfied.

- Vehicle speed 2 km/h (1 MPH) or less
- Return complete limit switch: ON
- The battery voltage is normal

Operation sequence	Rear seatback condition	Sector gear condition	Primary position limit switch	Return complete limit switch
1	Return completion position	Initial position	OFF	OFF
2	Fold-down position	Initial position	OFF	ON
3	Active	Return non-completion position	OFF → ON	ON

REAR SEATBACK POWER RETURN SYSTEM

< SYSTEM DESCRIPTION >

Operation sequence	Rear seatback condition	Sector gear condition	Primary position limit switch	Return complete limit switch
4	Return completion position	Return completion position	ON	OFF
5		Initial position	OFF	OFF

- In the condition that the rear seatback is raised (return completion position), the sector gear is in the initial position and the primary position limit switch and return complete limit switch are OFF.
- When the rear seatback to the fold-down position, the return complete limit switch turns ON, and the rear seatback power return control unit judges that the rear seatback is tilted (return non-completion position).
- When pressing and holding the power return switch or the rear seatback switch in the UP direction, the rear seatback power return control unit detects the power return ON signal and supplies the power to the power return motor. Then, the rear seatback power return control unit sounds the operation start buzzer.
- With the power supplied from the rear seat back power control unit, the power return motor rotates in the return direction. The rear seatback starts the return operation via the sector gear.
- When the sector gear starts rotating in the return direction, the primary position limit switch turns ON. The rear seatback power return control unit judges that the sector gear is in any position other than the initial position.
- When the rear seatback moves to the return position, the return complete limit switch turns OFF. The rear seatback power return control unit activates the return completion buzzer and stops the power return motor. Then, the rear seatback power return control unit reverses the power return motor after 0.2 seconds so that the sector gear returns to the initial position.
- When the sector gear returns to the initial position by reverse rotation of the power return motor, the primary position limit switch turns OFF. The rear seatback power return control unit stops the reverse operation of the power return motor. The return operation is completed.
- When releasing the switch during the return operation (both the primary position limit switch and return complete limit switch are ON), the rear seatback power return control unit detects the power switch OFF signal and returns the rear seatback to the fold-down position by the reverse rotation of the power return motor. When pushing the switch again during the reverse operation, the return operation restarts.

NOTE:

Disconnect the battery with the sector gear in any position other than the initial position (primary position limit switch: ON). The sector gear is returned to the initial position when the battery is connected again.

ANTI-PINCH OPERATION

When the pinch between RH/LH rear seatbacks is detected during the return operation, the malfunction detecting buzzer sounds and the rear seatback returns to the fold-down position.

- If there is a pinching of foreign materials between the left and right rear seatbacks during the return operation (both the primary position limit switch and return complete switch are ON), the voltage pulse of motor sensor changes.
- When inputting the pinching signal from the motor sensor, the rear seatback power return control unit sounds the malfunction detecting buzzer and stops the power return motor. Then, the rear seatback power return control unit reverses the power return motor after 0.2 second so that the rear seatback returns to the fold-down position.

SECTOR GEAR REVERSE STARTING CONDITION

If any of the following conditions are satisfied, the sector gear may be reversed.

- Rear seatback return is completed (return complete limit switch: OFF)
- Release the power return switch before completing the return
- Pinch detection
- Lock detection of power return motor
(Lock at normal rotation)
- The rear seatback return is not completed within 60 seconds
- Detect the battery voltage malfunction during the return operation
- Return to the normal condition after detecting the battery voltage malfunction during the return operation
- The primary position limit switch does not turn OFF → ON within the specified motor pulse number from starting the return operation.

SECTOR GEAR REVERSE STOP CONDITION

If any of the following conditions are satisfied, the reverse operation stops.

- Sector gear initial position (primary position limit switch: OFF)
- Lock detection of power return motor (Lock during reverse operation)
- The sector gear initial position is not completed within 60 seconds

REAR SEATBACK POWER RETURN SYSTEM

< SYSTEM DESCRIPTION >

NOTE:

The battery voltage indicates the voltage between battery voltage (system) terminal 17 and GND (system) terminal 32 of rear seatback power return control unit. It is normal when the voltage is $7.5 \pm 10\%$ or more. If it is less than the specified value, there is a malfunction.

POWER CONSUMPTION CONTROL SYSTEM

Rear seatback power return control unit incorporates a power consumption control function that reduces the power consumption according to the vehicle status.

Low Power Consumption Mode

If all of the following conditions are satisfied for 30 seconds period of time, the system shifts to the low power consumption mode.

- Power return switch or rear seatback switch is OFF
- Power return motor does not operate
- Vehicle speed 2 km/h (1 MPH) or less




If any of the following conditions are satisfied, the low power consumption mode is released.

- When the power return switch or rear seatback switch is pressed
- When the change occurs to the pulse of vehicle speed sensor

There are the following functions as the low power consumption mode.

- Turn the power supply of primary position limit switch and return complete limit switch to OFF
- Turn the power supply of the motor sensor to OFF when the power return motor is not operated

BUZZER OPERATION PATTERN AND ORDER OF PRIORITY


Operation type	Sound pattern	Priority
Malfunction		1
Return operation completed		2
Start return operation		3

REAR SEATBACK POWER RETURN SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000005172728



JMJA1544ZZ

1. Rear seatback power return control unit	2. Rear seatback release relay (LH)	3. Rear seatback release relay (RH)
4. Power return switch (LH)	5. Power return switch (RH)	6. Rear seatback switch (LH)
7. Primary position limit switch (RH)	8. Sector gear (RH)	9. Power return motor assembly (RH)
10. Return complete limit switch (LH)	11. Rear seatback release actuator (LH)	12. Unified meter and A/C amp.
A. Behind of rear seat (RH)	B. In seat device	C. View with seatback pad is removed
D. Behind cluster lid C		

SE

K

L

M

N

O

P

Component Description

INFOID:000000005172729

Item	Function
Rear seatback power return control unit	Control the rear seatback power return system
Power return motor	Operate the rear seatback
Motor sensor	Detect the operation of power return motor
Power return switch	Switch that performs the return operation
Rear seatback switch	Performs the return operation or release the rear seatback when it is locked
Rear seatback release actuator	Pressed the rear seatback release switch to release the rear seatback when it is locked
Primary position limit switch	Detect the initial position of sector gear
Return complete limit switch	Detect the return position of rear seatback
Unified meter and A/C amp.	Transmit the vehicle speed signal
Sector gear	Transmit the operation of power return motor to rear seatback

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

REAR SEATBACK POWER RETURN CONTROL UNIT

REAR SEATBACK POWER RETURN CONTROL UNIT : Diagnosis Procedure

INFOID:000000005172730

1. CHECK FUSE

Check that the following fuses are not fusing.

Terminal No.	Signal name	Fuse No.
16		32 (30A)
17	Battery power supply	6 (10A)

Is the fuse fusing?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.
NO >> GO TO 2.

2. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect rear seatback power return control unit connector.
3. Check voltage between rear seatback power return control unit harness connector and ground.

(+) Rear seatback power return control unit		(-)	Voltage (Approx.)
Connector	Terminal		
B226	17	Ground	Battery voltage
B227	16		

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT GROUND CIRCUIT

Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	32		
B227	13		Existed

Is the inspection result normal?

YES >> INSPECTION END
NO >> Repair harness or connector.

HEATED SEAT CONTROL UNIT

HEATED SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:000000005531542

1. CHECK FUSE

Check that the following fuse is not blown.

Signal name	Fuse No.
Battery power supply	35 (15A)

Is the inspection result normal?

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if fuse is blown.

2.CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY 1

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Turn ignition switch ON.
4. Check voltage between heated seat control unit harness connector and ground.

(+) Heated seat control unit		(-)	Voltage (V) (Approx.)
Connector	Terminal		
Driver side	B439	60	Ground
Passenger side	B462		Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Check continuity between heated seat control unit harness connector and heated seat relay terminal connector.

Heated seat control unit		Heated seat relay		Continuity
Connector	Terminal	Connector	Terminal	
Driver side	B439	60	M70	3
Passenger side	B462			Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
Driver side	B439	60	
Passenger side	B462		Not existed

Is the inspection result normal?

YES >> Repair or replace harness between heated seat relay and fuse holder.

NO >> Repair or replace harness between heated seat control unit and heated seat relay.

4.CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY 2

Check voltage between heated seat control unit harness connector and ground.

(+) Heated seat control unit		(-)	Condition	Voltage (V) (Approx.)		
Connector	Terminal					
Driver side	B439	66	Heated seat switch	ON		
				Battery voltage		
	B462			OFF		
				0		

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 5.

5.CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY CIRCUIT 2

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat control unit harness connector and heated seat switch harness connector.

Heated seat control unit		Heated seat switch		Continuity
Connector	Terminal	Connector	Terminal	
Driver side	B439	66	M177	Existed
Passenger side	B462		M178	

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
Driver side	B439	66	Existed
Passenger side	B462		

Is the inspection result normal?

YES >> GO TO 6.
NO >> Repair or replace harness.

6.CHECK HEATED SEAT SWITCH

Check heated seat switch.

- Driver side: Refer to [SE-48, "DRIVER SIDE : Component Inspection"](#).
- Passenger side: Refer to [SE-49, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.
NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

7.CHECK HEATED SEAT CONTROL UNIT GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
Driver side	B439	59	Exists
Passenger side	B462		

Is the inspection result normal?

YES >> INSPECTION END
NO >> Repair or replace harness.

8.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

HEATED SEAT SWITCH

HEATED SEAT SWITCH : Diagnosis Procedure

INFOID:000000005531543

1.CHECK FUSE

Check that the following fuse is not blown.

Signal name	Fuse No.
Ignition power supply	3 (10A)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if fuse is blown.

2.CHECK HEATED SEAT SWITCH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Turn ignition switch ON.
4. Check voltage between heated seat switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Heated seat switch			
Connector		Terminal	
Driver side	M177	5	Ground
Passenger side	M178		Battery voltage

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 3.

3.CHECK HEATED SEAT SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between heated seat switch harness connector and fuse block (J/B) harness connector.

Heated seat switch		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
Driver side	M177	5	M1	2A
Passenger side	M178			Existed

4. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		
Driver side	M177	5	
Passenger side	M178		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK FUSE BLOCK (J/B)

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) connector (fuse block side) and ground.

(+)		(-)	Voltage (V) (Approx.)
Fuse block (J/B)			
Connector	Terminal		
M1	2A	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace fuse block (J/B).

5.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

SE

K

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

POWER RETURN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

POWER RETURN SWITCH

LH

A

LH : Description

INFOID:000000005172731

Switch that performs the return operation.

B

LH : Component Function Check

INFOID:000000005172732

1. CHECK POWER RETURN SWITCH (LH) FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH).

C

Is the inspection result normal?

D

YES >> Power return switch (LH) is OK.

NO >> Refer to [SE-21, "LH : Diagnosis Procedure".](#)

E

LH : Diagnosis Procedure

INFOID:000000005172733

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power return switch (LH) connector.
3. Check voltage between power return switch (LH) harness connector and ground.

F

G

H

I

SE

K

L

M

N

O

P

(+) Power return switch (LH)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M174	1	Ground	5

Is the inspection result normal?

J

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK FRONT POWER RETURN SWITCH (LH) CIRCUIT

SE

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return switch (LH) harness connector.

K

L

M

N

O

P

Rear seatback power return control unit		Power return switch (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	28	M174	1	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

J

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
M226	28		Not existed

Is the inspection result normal?

I

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation".](#)
NO >> Repair or replace harness.

3. CHECK POWER RETURN SWITCH (LH) GROUND CIRCUIT

P

Check continuity power return switch (LH) harness connector and ground.

Power return switch (LH)		Ground	Continuity
Connector	Terminal		
M174	2		Existed

POWER RETURN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK POWER RETURN SWITCH (LH)

Check power return switch (LH).

Refer to [SE-22, "LH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power return switch (LH). Refer to [SE-152, "Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

LH : Component Inspection

INFOID:000000005172734

1. CHECK FRONT POWER RETURN SWITCH (LH)

1. Turn ignition OFF.
2. Disconnect power return switch (LH) connector.
3. Check power return switch (LH) terminals.

Power return switch (LH) connector	Terminal		Condition	Continuity
M174	1	2	Power return switch (LH) is pressed	Existed
			Power return switch (LH) is released	Not existed

Is the inspection result normal?

YES >> Power return switch (LH) is OK.

NO >> Replace power return switch (LH). Refer to [SE-152, "Removal and Installation"](#).

RH

RH : Description

INFOID:000000005172735

Switch that performs the return operation.

RH : Component Function Check

INFOID:000000005172736

1. CHECK POWER RETURN SWITCH (RH) FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH).

Is the inspection result normal?

YES >> Power return switch (RH) is OK.

NO >> Refer to [SE-22, "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:000000005172737

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power return switch (RH) connector.
3. Check voltage between power return switch (RH) harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Power return switch (RH)			
Connector	Terminal		
M175	1	Ground	5

Is the inspection result normal?

POWER RETURN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK POWER RETURN SWITCH (RH) CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return switch (RH) harness connector.

Rear seatback power return control unit		Power return switch (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	20	M175	1	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	20		Not existed

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK POWER RETURN SWITCH (RH) GROUND CIRCUIT

Check continuity power return switch (RH) harness connector and ground.

Power return switch (RH)		Ground	Continuity
Connector	Terminal		
M175	2		Existed

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK POWER RETURN SWITCH (RH)

Check power return switch (RH).

Refer to [SE-23, "RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.
NO >> Replace power return switch (RH). Refer to [SE-152, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

RH : Component Inspection

INFOID:000000005172738

1.CHECK POWER RETURN SWITCH (RH)

1. Turn ignition OFF.
2. Disconnect power return switch (RH) connector.
3. Check power return switch (RH) terminals.

Power return switch (RH) connector	Terminal		Condition	Continuity
M175	1	2	Power return switch (RH) is pressed	Existed
			Power return switch (RH) is released	Not existed

Is the inspection result normal?

YES >> Power return switch (RH) is OK.

POWER RETURN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace power return switch (RH). Refer to [SE-152, "Removal and Installation".](#)

REAR SEATBACK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

REAR SEATBACK SWITCH

LH

LH : Description

INFOID:000000005172739

Switch that performs the return operation or release operation.

LH : Component Function Check

INFOID:000000005172740

1. CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the rear seatback switch (LH) in UP direction.

Is the inspection result normal?

YES >> Rear seatback switch (LH) is OK.

NO >> Refer to [SE-25, "LH : Diagnosis Procedure"](#).

LH : Diagnosis Procedure

INFOID:000000005172741

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (LH) connector.
3. Check voltage between rear seatback switch (LH) harness connector and ground.

(+) Rear seatback switch (LH)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B52	2	Ground	5

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK REAR SEAT BACK SWITCH (LH) CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback switch (LH) harness connector.

Rear seatback power return control unit		Rear seatback switch (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	28	B52	2	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	28		Not existed

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK REAR SEATBACK SWITCH (LH) GROUND CIRCUIT

Check continuity rear seatback switch (LH) harness connector and ground.

Rear seatback switch (LH)		Ground	Continuity
Connector	Terminal		
B52	3		Existed

REAR SEATBACK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK REAR SEATBACK SWITCH (LH)

Check rear seatback switch (LH).

Refer to [SE-26, "LH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace rear seatback switch (LH). Refer to [SE-154, "Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

LH : Component Inspection

INFOID:0000000005172742

1. CHECK REAR SEATBACK SWITCH (LH)

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (LH) connector.
3. Check rear seatback switch (LH) terminals.

Rear seatback switch (LH) connector	Terminal		Condition	Continuity
B52	2	3	Rear seatback switch (LH) is pressed in UP direction	Existed
			Rear seatback switch (LH) is released in UP direction	Not existed

Is the inspection result normal?

YES >> Rear seatback switch (LH) is OK.

NO >> Replace seatback return switch (LH). Refer to [SE-154, "Removal and Installation"](#).

RH

RH : Description

INFOID:0000000005172743

Switch that performs the return operation or release operation.

RH : Component Function Check

INFOID:0000000005172744

1. CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the rear seatback switch (RH) in UP direction.

Is the inspection result normal?

YES >> Rear seatback switch (RH) is OK.

NO >> Refer to [SE-26, "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:0000000005172745

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (RH) connector.
3. Check voltage between rear seatback switch (RH) harness connector and ground.

REAR SEATBACK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

(+)	(-)	Voltage (V) (Approx.)
Rear seatback switch (RH)		
Connector	Terminal	
B239	2	Ground
5		

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK REAR SEATBACK SWITCH (RH) CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback switch (RH) harness connector.

Rear seatback power return control unit		Rear seatback switch (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	20	B239	2	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	20		Not existed

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK REAR SEATBACK SWITCH (RH) GROUND CIRCUIT

Check continuity rear seatback switch (RH) harness connector and ground.

Rear seatback switch (RH)		Ground	Continuity
Connector	Terminal		
B239	3		Existed

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK REAR SEATBACK SWITCH (RH)

Check rear seatback switch (RH).

Refer to [SE-27, "RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.
NO >> Replace rear seatback switch (RH). Refer to [SE-153, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

RH : Component Inspection

INFOID:000000005172746

1.CHECK REAR SEATBACK SWITCH (RH)

1. Turn ignition switch OFF.
2. Disconnect rear seatback switch (RH) connector.
3. Check rear seatback switch (RH) terminals.

REAR SEATBACK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Rear seatback switch (RH) connector	Terminal		Condition	Continuity
B239	2	3	Rear seatback switch (RH) is pressed in UP direction	Existed
			Rear seatback switch (RH) is released in UP direction	Not existed

Is the inspection result normal?

YES >> Rear seatback switch (RH) is OK.

NO >> Replace rear seatback switch (RH). Refer to [SE-153. "Removal and Installation".](#)

PRIMARY POSITION LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

PRIMARY POSITION LIMIT SWITCH

LH

LH : Description

INFOID:000000005172747

Detect the initial position of sector gear (LH).

LH : Component Function Check

INFOID:000000005172748

1. CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?

YES >> Primary position limit switch (LH) is OK.
NO >> Refer to [SE-29, "LH : Diagnosis Procedure"](#).

LH : Diagnosis Procedure

INFOID:000000005172749

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect primary position limit switch (LH) connector.
3. Check voltage between primary position limit switch (LH) connector and ground.

(+) Primary position limit switch (LH)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B512	6	Ground	Battery voltage

NOTE:

It is not low power consumption mode.

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK PRIMARY POSITION LIMIT SWITCH (LH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (LH) harness connector.

Rear seatback power return control unit		Primary position limit switch (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	21	B512	6	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	21		

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK PRIMARY POSITION LIMIT SWITCH (LH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (LH) harness connector.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

PRIMARY POSITION LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Rear seatback power return control unit		Primary position limit switch (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	31	B512	9	Existed

2. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	31		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK PRIMARY POSITION LIMIT SWITCH (LH)

Check primary position limit switch (LH).

Refer to [SE-30, "LH : Component Inspection".](#)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace primary position limit switch (LH) [seat device assembly (LH)]. Refer to [SE-140, "Exploded View".](#)

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident".](#)

>> INSPECTION END

LH : Component Inspection

INFOID:0000000005172750

COMPONENT INSPECTION

1. CHECK PRIMARY POSITION LIMIT SWITCH (LH)

1. Turn ignition switch OFF.
2. Disconnect primary position limit switch (LH) connector.
3. Check primary position limit switch (LH) terminals.

Primary position limit switch (LH) connector	Terminal		Condition	Continuity
B512	6	9	Primary position limit switch (LH) is pressed	Existed
			Primary position limit switch (LH) is released	Not existed

Is the inspection result normal?

YES >> Primary position limit switch (LH) is OK.

NO >> Replace primary position limit switch (LH) [seat device assembly (LH)]. Refer to [SE-140, "Exploded View".](#)

RH

RH : Description

INFOID:0000000005172751

Detect the initial position of sector gear (RH).

RH : Component Function Check

INFOID:0000000005172752

1. CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

YES >> Primary position limit switch (RH) is OK.

PRIMARY POSITION LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Refer to [SE-31, "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:0000000005172753

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Connect primary position limit switch (RH) connector.
3. Check voltage between primary position limit switch (RH) harness connector and ground.

(+) Primary position limit switch (RH)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B505	15	Ground	Battery voltage

NOTE:

It is not low power consumption mode.

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK PRIMARY POSITION LIMIT SWITCH (RH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (RH) harness connector.

Rear seatback power return control unit		Primary position limit switch (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	22	B505	15	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	22		Not existed

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK PRIMARY POSITION LIMIT SWITCH (RH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and primary position limit switch (RH) harness connector.

Rear seatback power return control unit		Primary position limit switch (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	23	B505	14	Existed

2. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	23		Not existed

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK PRIMARY POSITION LIMIT SWITCH (RH)

PRIMARY POSITION LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Check primary position limit switch (RH).

Refer to [SE-32, "RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace primary position limit switch (RH) [seat device assembly (RH)]. Refer to [SE-140, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

RH : Component Inspection

INFOID:000000005172754

COMPONENT INSPECTION

1.CHECK PRIMARY POSITION LIMIT SWITCH (RH)

1. Turn ignition switch OFF.
2. Disconnect primary position limit switch (RH) connector.
3. Check primary position limit switch (RH) terminals.

Primary position limit switch (RH) connector	Terminal		Condition	Continuity
B505	14	15	Primary position limit switch (RH) is pressed	Existed
			Primary position limit switch (RH) is released	Not existed

Is the inspection result normal?

YES >> Primary position limit switch (RH) is OK.

NO >> Replace primary position limit switch (RH) [seat device assembly (RH)]. Refer to [SE-140, "Exploded View"](#).

RETURN COMPLETE LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

RETURN COMPLETE LIMIT SWITCH

LH

LH : Description

INFOID:000000005172755

Detect the return completion position of rear seatback (LH).

LH : Component Function Check

INFOID:000000005172756

1. CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?

YES >> Return complete limit switch (LH) is OK.
NO >> Refer to [SE-33, "LH : Diagnosis Procedure"](#).

LH : Diagnosis Procedure

INFOID:000000005172757

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback lock assembly (LH) connector.
3. Check voltage between rear seatback lock assembly (LH) harness connector and ground.

(+) Rear seatback lock assembly (LH)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B513	8	Ground	Battery voltage

NOTE:

It is not low power consumption mode.

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK RETURN COMPLETE LIMIT SWITCH (LH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (LH) harness connector.

Rear seatback power return control unit		Rear seatback lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	29	B513	8	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	29		Not existed

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK RETURN COMPLETE LIMIT SWITCH (LH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (LH) harness connector.

RETURN COMPLETE LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Rear seatback power return control unit		Rear seatback lock assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	31	B513	9	Existed

2. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		Not existed
B226	31		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK RETURN COMPLETE LIMIT SWITCH (LH)

Check return complete limit switch (LH).

Refer to [SE-34, "LH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace return complete limit switch (LH) [rear seatback lock assembly (LH)]. Refer to [SE-140, "Exploded View"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

LH : Component Inspection

INFOID:000000005172758

COMPONENT INSPECTION

1. CHECK RETURN COMPLETE LIMIT SWITCH (LH)

1. Turn ignition switch OFF.
2. Disconnect rear seatback lock assembly (LH) connector.
3. Check rear seatback lock assembly (LH) terminals.

Rear seatback lock assembly (LH) connector	Terminal		Condition	Continuity
B513	8	9	Return complete limit switch (LH) is pressed	Existed
			Return complete limit switch (LH) is released	Not existed

Is the inspection result normal?

YES >> Return complete limit switch (LH) is OK.

NO >> Replace return complete limit switch (LH) [rear seatback lock assembly (LH)]. Refer to [SE-140, "Exploded View"](#).

RH

RH : Description

INFOID:000000005172759

Detect the return completion position of rear seatback (RH).

RH : Component Function Check

INFOID:000000005172760

1. CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

YES >> Return complete limit switch (RH) is OK.

RETURN COMPLETE LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Refer to [SE-35, "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:000000005172761

1. CHECK REAR SEATBACK POWER RETURN CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seatback lock assembly (RH) connector.
3. Check voltage between rear seatback lock assembly (RH) harness connector and ground.

(+) Rear seatback lock assembly (RH)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B506	13	Ground	Battery voltage

NOTE:

It is not low power consumption mode.

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK RETURN COMPLETE LIMIT SWITCH (RH) SIGNAL CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (RH) harness connector.

Rear seatback power return control unit		Rear seatback lock assembly (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	30	B506	13	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	30		Not existed

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK RETURN COMPLETE LIMIT SWITCH (RH) GROUND CIRCUIT

1. Check continuity between rear seatback power return control unit harness connector and rear seatback lock assembly (RH) harness connector.

Rear seatback power return control unit		Rear seatback lock assembly (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B226	23	B506	14	Existed

2. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	23		Not existed

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK RETURN COMPLETE LIMIT SWITCH (RH)

RETURN COMPLETE LIMIT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Check return complete limit switch (RH).

Refer to [SE-36, "RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace return complete limit switch (RH) [rear seatback lock assembly (RH)]. Refer to [SE-140, "Exploded View"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

RH : Component Inspection

INFOID:000000005172762

COMPONENT INSPECTION

1.CHECK RETURN COMPLETE LIMIT SWITCH (RH)

1. Turn ignition switch OFF.
2. Disconnect rear seatback lock assembly (RH) connector.
3. Check rear seatback lock assembly (RH) terminals.

Rear seatback lock assembly (RH) connector	Terminal		Condition	Continuity
B506	13	14	Return complete limit switch (RH) is pressed	Existed
			Return complete limit switch (RH) is released	Not existed

Is the inspection result normal?

YES >> Return complete limit switch (RH) is OK.

NO >> Replace return complete limit switch (RH) [rear seatback lock assembly (RH)]. Refer to [SE-140, "Exploded View"](#).

MOTOR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

MOTOR SENSOR

LH

LH : Description

INFOID:000000005172763

Detect the operation condition of power return motor (LH).

LH : Component Function Check

INFOID:000000005172764

1. CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?

YES >> Motor sensor (LH) is OK.


NO >> Refer to [SE-37, "LH : Diagnosis Procedure".](#)

LH : Diagnosis Procedure

INFOID:000000005172765

1. CHECK MOTOR SENSOR (LH) OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between rear seatback power return control unit harness connector and ground.

(+) Rear seatback power return control unit		(-) Connector	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B227	10	Ground	During the power return motor (LH) operation	 10 ms
			When pinching between LH/RH seats occurs	The above pulse width should be expanded

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 2.

2. CHECK MOTOR SENSOR (LH) SIGNAL CIRCUIT

1. Disconnect power return motor assembly (LH) connector and rear seatback power return control unit connector.
2. Check continuity between power return motor assembly (LH) harness connector and rear seatback power return control unit harness connector.

Rear seatback power return control unit		Power return motor assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	10	B511	4	Existed

3. Check continuity between power return motor assembly (LH) harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B227	10		Not existed

Is the inspection result normal?

MOTOR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK MOTOR SENSOR (LH) POWER SUPPLY

1. Connect rear seatback power return control unit connector.
2. Check voltage between power return motor assembly (LH) harness connector and ground.

(+) Power return motor assembly (LH)		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B511	3	Ground	When the power return switch is operated	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK MOTOR SENSOR (LH) POWER SUPPLY CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return motor assembly (LH) harness connector.

Rear seatback power return control unit		Power return motor assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	11	B511	3	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B227	11		Not existed

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

5. CHECK MOTOR SENSOR (LH) GROUND CIRCUIT 1

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between power return motor assembly harness connector and ground.

Rear seatback power return control unit		Power return motor assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	9	B511	5	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK MOTOR SENSOR (LH) GROUND CIRCUIT 2

1. Connect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B227	9		Existed

Is the inspection result normal?

YES >> Replace motor sensor (LH) [seat device assembly (LH)]. Refer to [SE-140, "Exploded View"](#).

NO >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).

MOTOR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

RH

RH : Description

INFOID:000000005172766

Detect the operation condition of power return motor (RH).

RH : Component Function Check

INFOID:000000005172767

1. CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

YES >> Motor sensor (RH) is OK.


NO >> Refer to [SE-39, "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:000000005172768

1. CHECK MOTOR SENSOR (RH) OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between rear seatback power return control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B227	2	Ground	During the power return motor (RH) operation	 JMKA0070GB
			When pinching between LH/RH seats occurs	The above pulse width should be expanded

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 2.

2. CHECK MOTOR SENSOR (RH) SIGNAL CIRCUIT

1. Disconnect power return motor assembly (RH) connector and rear seatback power return control unit connector.
2. Check continuity between power return motor assembly (RH) harness connector and rear seatback power return control unit harness connector.

Rear seatback power return control unit		Power return motor assembly (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	2	B504	18	Existed

3. Check continuity between power return motor assembly (RH) harness connector and ground.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

MOTOR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		Not existed
B227	2		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK MOTOR SENSOR (RH) POWER SUPPLY

1. Connect rear seatback power return control unit connector.
2. Check voltage power return motor assembly (RH) harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Power return motor assembly (RH)	Connector			
B504	17	Ground	When the power return switch is operated	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK MOTOR SENSOR (RH) POWER SUPPLY CIRCUIT

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and power return motor assembly (RH) harness connector.

Rear seatback power return control unit		Power return motor assembly (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	3	B504	17	Existed

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B227	3		

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

5. CHECK MOTOR SENSOR (RH) GROUND CIRCUIT 1

1. Disconnect rear seatback power return control unit connector.
2. Check continuity between power return motor assembly harness connector and power return motor assembly (RH) harness connector.

Rear seatback power return control unit		Power return motor assembly (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	1	B504	19	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6. CHECK MOTOR SENSOR (LH) GROUND CIRCUIT 2

1. Connect rear seatback power return control unit connector.
2. Check continuity between rear seatback power return control unit harness connector and ground.

MOTOR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		Existed
B227	1		

Is the inspection result normal?

YES >> Replace motor sensor (RH) [seat device assembly (RH)]. Refer to [SE-140, "Exploded View"](#).
NO >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

POWER RETURN MOTOR

< DTC/CIRCUIT DIAGNOSIS >

POWER RETURN MOTOR

LH

LH : Description

INFOID:000000005172769

Operate the rear seatback.

LH : Component Function Check

INFOID:000000005172770

1. CHECK FUNCTION

Check that the rear seatback (LH) rises when pressing and holding the power return switch (LH) or rear seatback switch (LH) in UP direction.

Is the inspection result normal?

YES >> Power return motor (LH) is OK.

NO >> Refer to [SE-42, "LH : Diagnosis Procedure"](#).

LH : Diagnosis Procedure

INFOID:000000005172771

1. CHECK POWER RETURN MOTOR (LH) INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between power return motor assembly (LH) harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
B511	1	Ground	During the power return motor (LH) reverse operation	Battery voltage	
			Other than the above	0	
	2		During the power return motor (LH) return operation	Battery voltage	
			Other than the above	0	

Is the inspection result normal?

YES >> Replace power return motor assembly (LH) [seat device assembly (LH)]. Refer to [SE-140, "Exploded View"](#).

NO >> GO TO 2.

2. CHECK POWER RETURN MOTOR (LH) CIRCUIT

1. Disconnect rear seatback power return control unit connector and power return motor assembly (LH) connector.
2. Check continuity between rear seatback power return control unit harness connector and power return motor assembly (LH) harness connector.

Rear seatback power return control unit		Power return motor assembly (LH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	5	B511	1	Existed
	6		2	

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B227	5		
	6		Not existed

Is the inspection result normal?

POWER RETURN MOTOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
NO >> Repair or replace harness.

RH

RH : Description

INFOID:000000005172772

Operate the rear seatback.

RH : Component Function Check

INFOID:000000005172773

1. CHECK FUNCTION

Check that the rear seatback (RH) rises when pressing and holding the power return switch (RH) or rear seatback switch (RH) in UP direction.

Is the inspection result normal?

YES >> Power return motor (RH) is OK.
NO >> Refer to [SE-43, "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:000000005172774

1. CHECK POWER RETURN MOTOR (RH) INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between power return motor assembly (RH) harness connector and ground.

(+) Power return motor assembly (RH)		(-) Connector	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B504	20	Ground	During the power return motor (RH) reverse operation	Battery voltage
			Other than the above	0
	21		During the power return motor (RH) return operation	Battery voltage
			Other than the above	0

Is the inspection result normal?

YES >> Replace power return motor assembly (RH) [seat device assembly (RH)]. Refer to [SE-140, "Exploded View"](#).
NO >> GO TO 2.

2. CHECK POWER RETURN MOTOR (RH) CIRCUIT

1. Disconnect rear seatback power return control unit connector and power return motor assembly (RH) connector.
2. Check continuity between rear seatback power return control unit harness connector and power return motor assembly (RH) harness connector.

Rear seatback power return control unit		Power return motor assembly (RH)		Continuity
Connector	Terminal	Connector	Terminal	
B227	7	B504	20	Existed
	8		21	

3. Check continuity between rear seatback power return control unit harness connector and ground.

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B227	7		
	8		

Is the inspection result normal?

POWER RETURN MOTOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation"](#).
- NO >> Repair or replace harness.

VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

VEHICLE SPEED SIGNAL CIRCUIT

Description

INFOID:0000000005172775

Transmits vehicle speed signal to rear seatback power return control unit.

Component Function Check

INFOID:0000000005172776

1. CHECK FUNCTION

Check that the rear seatback rises when pressing and holding the power return switch or rear seatback switch in UP direction.

Is the inspection result normal?

YES >> Vehicle speed signal circuit is OK.
NO >> Refer to [SE-45, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000005172777

1. CHECK VEHICLE SPEED OPERATION


1. Check speed meter operate normally.

Is the inspection result normal?

YES >> GO TO 2.
NO >> Refer to [MWI-4, "Work flow"](#).

2. CHECK VEHICLE SPEED INPUT SIGNAL

Check voltage between rear seatback power return control unit harness connector and ground.

(+) Rear seatback power return control unit		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B226	24	Ground	When vehicle speed is approx.40 km/h (25MPH)	<p>NOTE: Maximum voltage may be 12V due to specifications (connected units)</p> <p>(V)</p>  <p>SKIA6649J</p>

Is the inspection result normal?

YES >> GO TO 3.
NO >> Refer to [MWI-4, "Work flow"](#).

3. CHECK VEHICLE SPEED SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear seatback power return control unit connector and unified meter and A/C amp. connector.
3. Check continuity between power return control unit harness connector and unified meter and A/C amp. harness connector.

Rear seatback power return control unit		Unified meter and A/C amp.		Continuity
Connector	Terminal	Connector	Terminal	
B226	24	M66	28	Existed

4. Check continuity between rear seatback power return control unit harness connector and ground.

VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Rear seatback power return control unit		Ground	Continuity
Connector	Terminal		
B226	24		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

HEATED SEAT SWITCH DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005531544

Adjusts heated seat temperature and deactivates heated seat.

DRIVER SIDE : Component Function Check

INFOID:000000005531545

1. CHECK HEATED SEAT SWITCH FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Heated seat switch function is OK.

NO >> Refer to [SE-47, "DRIVER SIDE : Diagnosis Procedure".](#)

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005531546

1. CHECK HEATED SEAT CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Turn ignition switch ON.
4. Check voltage between heated seat control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)		
Heated seat control unit	Connector					
B439	67	Ground	Heated seat switch position	OFF		
				0		
				1 (Min. temperature)		
				12.24		
				2		
				12.33		
				3		
				12.49		
				4		
				12.63		
				5		
				12.76		
				6 (Max. temperature)		
				12.90		

Is the inspection result normal?

YES >> Heated seat switch circuit is OK.

NO >> GO TO 2.

2. CHECK HEATED SEAT SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat switch harness connector and heated seat control unit harness connector.

Heated seat switch		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M177	2	B439	67	Existed

4. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		
M177	2		
			Not existed

Is the inspection result normal?

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-48, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:0000000005531547

1. CHECK FRONT HEATED SEAT SWITCH

1. Turn ignition OFF.
2. Disconnect heated seat switch connector.
3. Check resistance between heated seat switch terminals as follows.

Heated seat switch		Condition	Resistance (KΩ) (Approx.)	
Connector	Terminal			
M177	5	Heated seat switch position	ON	
			0	
			∞	
			1 (Min. temperature)	
			2.400	
			2	
			1.800	
			3	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000005531548

Adjusts heated seat temperature and deactivates heated seat.

PASSENGER SIDE : Component Function Check

INFOID:0000000005531549

1. CHECK HEATED SEAT SWITCH FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Heated seat switch function is OK.

NO >> Refer to [SE-48, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000005531550

1. CHECK HEATED SEAT CONTROL UNIT INPUT SIGNAL

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Turn ignition switch ON.
4. Check voltage between heated seat control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Heated seat control unit	Connector			
B462	67	Ground	Heated seat switch position	OFF
				1 (Min. temperature)
				2
				3
				4
				5
				6 (Max. temperature)

Is the inspection result normal?

YES >> Heated seat switch circuit is OK.
NO >> GO TO 2.

2. CHECK HEATED SEAT SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat switch harness connector and heated seat control unit harness connector.

Heated seat switch		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M178	2	B462	67	Existed

4. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		Existed
M178	2		Not existed

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-49, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.
NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:000000005531551

1. CHECK FRONT HEATED SEAT SWITCH

HEATED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition OFF.
2. Disconnect heated seat switch connector.
3. Check resistance between heated seat switch terminals as follows.

Heated seat switch		Condition	Resistance (KΩ) (Approx.)
Connector	Terminal		
M178	5	1	ON
			∞
		2	1 (Min. temperature)
			2.400
			2
			1.800
			3
			1.200
			4
			0.910
			5
			0.620
			6 (Max. temperature)
			0.348

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

HEATED SEAT RELAY

< DTC/CIRCUIT DIAGNOSIS >

HEATED SEAT RELAY

Description

INFOID:0000000005531552

Power is supplied to the heated seat using ignition power supply control.

Component Function Check

INFOID:0000000005531553

1. CHECK HEATED SEAT RELAY FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Heated seat relay function is OK.
NO >> Refer to [SE-51, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:0000000005531554

1. CHECK HEATED SEAT RELAY POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Turn ignition switch ON.
4. Check voltage between heated seat relay terminal connector and ground.

(+) Heated seat relay		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M70	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HEATED SEAT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between heated seat relay terminal connector and fuse block (J/B) harness connector.

Heated seat relay		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M70	2	M1	2A	Existed

4. Check continuity between heated seat relay terminal connector and ground.

Heated seat relay		Ground	Continuity
Connector	Terminal		
M70	2		Not existed

Is the inspection result normal?

YES >> GO TO 5.
NO >> Repair or replace harness.

3. CHECK HEATED SEAT RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between heated seat relay terminal connector and ground.

HEATED SEAT RELAY

< DTC/CIRCUIT DIAGNOSIS >

Heated seat relay		Ground	Continuity
Connector	Terminal		Existed
M70	1		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK HEATED SEAT RELAY

Check heated seat relay.

Refer to [SE-52, "Component Inspection"](#).

Is the inspection result normal?

YES >> Heated seat relay is OK.

NO >> Replace heated seat relay.

5. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000005531555

1. CHECK HEATED SEAT RELAY


1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Check continuity between heated seat relay terminals.

Terminal	Condition	Continuity
3	12 V direct current supply between terminals 1 and 2.	Existed
	No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace heated seat relay.



HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

HEAT SENSOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005531556

Detects seat cushion heater temperature and outputs to heated seat control unit.

DRIVER SIDE : Component Function Check

INFOID:000000005531557

1. CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Heat sensor function is OK.

NO >> Refer to [SE-51, "Diagnosis Procedure"](#)

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005531558

1. CHECK HEAT SENSOR INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between heated seat control unit harness connector and ground.

(+) Heated seat control unit		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B439	69	Ground	OFF	0
			1 (Min. temperature)	10.87 – 11.02
			2	10.93 – 11.07
			3	11.04 – 11.17
			4	11.13 – 11.26
			5	11.22 – 11.34
			6 (Max. temperature)	11.31 – 11.43

NOTE:

Voltage is repeated within the value shown as per the following list depending on heater unit temperature.

Is the inspection result normal?

YES >> Heat sensor function is OK.

NO >> GO TO 2.

2. CHECK HEAT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector and seat cushion heater connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

Heated seat control unit		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B439	69	B440	69	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
B439	69		Not existed

Is the inspection result normal?

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK HEAT SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between seat cushion heater harness connector and ground.

(+) (Seat cushion heater)		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B440	66	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK HEAT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

Heated seat switch		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
M177	1	B440	66	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		Not existed
M177	1		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

5. CHECK HEAT SENSOR

Check heat sensor. Refer to [SE-54, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).

6. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:0000000005531559

1. CHECK HEAT SENSOR

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Check resistance between seat cushion heater terminals as follows.

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Seat cushion heater			Condition	Resistance (KΩ) (Approx.)
Connector	Terminal			
B440	66	69	When heat sensor temperature is 25°C (77°F)	9.9 – 10.1

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000005531560

Detects seat cushion heater temperature and outputs to heated seat control unit.

PASSENGER SIDE : Component Function Check

INFOID:0000000005531561

1. CHECK HEATER SENSOR FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Heat sensor function is OK.

NO >> Refer to [SE-51, "Diagnosis Procedure"](#)

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000005531562

1. CHECK HEAT SENSOR INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between heated seat control unit harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Heated seat control unit	Terminal			
B462	69	Ground	OFF	0
			1 (Min. temperature)	10.87 – 11.02
			2	10.93 – 11.07
			3	11.04 – 11.17
			4	11.13 – 11.26
			5	11.22 – 11.34
			6 (Max. temperature)	11.31 – 11.43

NOTE:

Voltage is repeated within the value shown as per the following list depending on heater unit temperature.

Is the inspection result normal?

YES >> heat sensor function is OK.

NO >> GO TO 2.

2. CHECK HEAT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector and seat cushion heater connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Heated seat control unit		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B462	69	B463	69	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat control unit		Ground	Continuity
Connector	Terminal		
B462	69		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK HEAT SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between seat cushion heater harness connector and ground.

(+) Seat cushion heater		(-)	Voltage (V) (Approx.)
Connector	Terminal		
B463	66	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK HEAT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat control unit harness connector and seat cushion heater harness connector.

Heated seat switch		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
M178	1	B463	66	Existed

4. Check continuity between heated seat control unit harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		
M178	1		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

5.CHECK HEAT SENSOR

Check heat sensor. Refer to [SE-57. "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace seat cushion heater. Refer to [SE-129. "Exploded View"](#).

6.CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37. "Intermittent Incident"](#).

HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:000000005531563

1. CHECK HEAT SENSOR

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Check resistance between seat cushion heater terminals as follows.

Seat cushion heater		Condition	Resistance (KΩ) (Approx.)	
Connector	Terminal			
B463	66	69	When heat sensor temperature is 25°C (77°F)	9.9 – 10.1

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

SEAT CUSHION HEATER DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005531564

Warms the seat cushion.

DRIVER SIDE : Component Function Check

INFOID:000000005531565

1. CHECK SEAT CUSHION HEATER FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seat cushion heater function is OK.
NO >> Refer to [SE-58, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005531566

1. CHECK SEAT CUSHION HEATER INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Turn ignition switch ON.
4. Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
B440	68	Ground	Heated seat	Operated 0 – Battery voltage
				Other than the above 0

NOTE:

Voltage is repeated within the value shown as per the following list depending on heater unit temperature.

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK SEAT CUSHION HEATER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Check continuity between seat cushion heater harness connector and heated seat control unit harness connector.

Seat cushion heater		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B440	68	B439	68	Existed

4. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B440	68		Not existed

Is the inspection result normal?

YES >> Replace heated seat control unit. Refer to [SE-148, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK SEAT CUSHION HEATER

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

Check seat cushion heater.

Refer to [SE-59, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).

4. CHECK SEAT CUSHION HEATER GROUND CIRCUIT

Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		Existed
B440	59		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:0000000005531567

1. CHECK SEAT CUSHION HEATER

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector and seatback heater connector.
3. Check resistance between seat cushion heater terminals as follows.

Seat cushion heater			Condition	Resistance (Ω) (Approx.)
Connector	Terminal			
B440	59	68	When heat sensor temperature is 20°C (68°F)	2.6 – 3.0

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000005531568

Warms the seat cushion.

PASSENGER SIDE : Component Function Check

INFOID:0000000005531569

1. CHECK SEAT CUSHION HEATER FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seat cushion heater function is OK.

NO >> Refer to [SE-59, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000005531570

1. CHECK FRONT SEAT CUSHION HEATER INPUT SIGNAL

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector.
3. Turn ignition switch ON.
4. Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition		Voltage (V) (Approx.)
Connector	Terminal		Heated seat	Operated	
B463	68	Ground	Heated seat	Operated	0 – Battery voltage
				Other than the above	0

NOTE:

Voltage is repeated within the value shown as per the following list depending on heater unit temperature.

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK SEAT CUSHION HEATER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect heated seat control unit connector.
3. Check continuity between seat cushion heater harness connector and heated seat control unit harness connector.

Seat cushion heater		Heated seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B463	68	B462	68	Existed

4. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B463	68		Not existed

Is the inspection result normal?

YES >> Replace heated seat control unit. Refer to [SE-148, "Removal and Installation".](#)

NO >> Repair or replace harness.

3. CHECK SEAT CUSHION HEATER

Check seat cushion heater.

Refer to [SE-61, "PASSENGER SIDE : Component Inspection".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace seat cushion heater. Refer to [SE-129, "Exploded View".](#)

4. CHECK SEAT CUSHION HEATER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B463	59		Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:000000005531571

1. CHECK SEAT CUSHION HEATER

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector and seatback heater connector.
3. Check resistance between seat cushion heater terminals as follows.

Seat cushion heater			Condition	Resistance (Ω) (Approx.)
Connector	Terminal			
B463	59	68	When heat sensor temperature is 20°C (68°F)	2.6 – 3.0

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

SEATBACK HEATER

< DTC/CIRCUIT DIAGNOSIS >

SEATBACK HEATER

DRIVER SIDE

DRIVER SIDE : Description

INFOID:0000000005531572

Warms the seat back heater.

DRIVER SIDE : Component Function Check

INFOID:0000000005531573

1. CHECK SEATBACK HEATER FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seatback heater function is OK.
NO >> Refer to [SE-62, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000005531574

1. CHECK SEATBACK HEATER

1. Turn ignition switch OFF.
2. Disconnect seatback heater connector.
3. Check resistance between seatback heater terminals.

Seatback heater			Condition	Resistance (Ω) (Approx.)
Connector	Terminal			
B442	1	2	When heat sensor temperature is 20°C (68°F)	4.0 – 4.7

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).
NO >> Replace seatback heater. Refer to [SE-129, "Exploded View"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000005531575

Warms the seat back heater.

PASSENGER SIDE : Component Function Check

INFOID:0000000005531576

1. CHECK SEATBACK HEATER FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> Seatback heater function is OK.
NO >> Refer to [SE-62, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000005531577

1. CHECK SEATBACK HEATER

1. Turn ignition switch OFF.
2. Disconnect seatback heater connector.
3. Check resistance between seatback heater terminals.

SEATBACK HEATER

< DTC/CIRCUIT DIAGNOSIS >

Seatback heater			Condition	Resistance (Ω) (Approx.)
Connector	Terminal			
B465	1	2	When heat sensor temperature is 20°C (68°F)	4.0 – 4.7

NOTE:

Resistance value changes according to temperature.

Is the inspection result normal?

YES >> Replace seat cushion heater. Refer to [SE-129, "Exploded View"](#).

NO >> Replace seatback heater. Refer to [SE-129, "Exploded View"](#).

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

HEATED SEAT SWITCH INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

HEATED SEAT SWITCH INDICATOR

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005531578

Illuminates the indicator that indicates the operating status of heated seat.

DRIVER SIDE : Component Function Check

INFOID:000000005531579

1. CHECK HEATED SEAT SWITCH INDICATOR FUNCTION

Check that the related indicator lamp illuminates when heated seat switch is turned ON.

Is the inspection result normal?

YES >> Heated seat switch indicator function is OK.

NO >> Refer to [SE-64, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005531580

1. CHECK HEATED SEAT SWITCH INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		
M177	6		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-64, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

3. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:000000005531581

1. CHECK HEATED SEAT SWITCH

1. Turn ignition OFF.
2. Disconnect heated seat switch connector.
3. Set the heated seat switch ON.
4. Check continuity between heated seat switch terminals as follows.

Heated seat switch			Continuity	
Connector	Terminal			
	(+)*	(-)*		
M177	5	6	Existed	
	6	5	Not existed	

HEATED SEAT SWITCH INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

*For a digital tester.

NOTE:

- Use a tester that can perform LED (light-emitting diode) measurement.
- The polarity (+ and -) reverses when checking using an analog tester.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000005531582

Illuminates the indicator that indicates the operating status of heated seat.

PASSENGER SIDE : Component Function Check

INFOID:0000000005531583

1. CHECK FUNCTION

Check that the related indicator lamp illuminates when heated seat switch is turned ON.

Is the inspection result normal?

YES >> Heated seat switch indicator function is OK.

NO >> Refer to [SE-65, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000005531584

1. CHECK HEATED SEAT SWITCH INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF
2. Disconnect heated seat switch connector.
3. Check continuity between heated seat switch harness connector and ground.

Heated seat switch		Ground	Continuity
Connector	Terminal		
M178	6		Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-65, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation"](#).

3. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-37, "Intermittent Incident"](#).

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:0000000005531585

1. CHECK HEATED SEAT SWITCH

1. Turn ignition OFF.
2. Disconnect heated seat switch connector.
3. Set the heated seat switch ON.
4. Check continuity between heated seat switch terminals.

HEATED SEAT SWITCH INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

Heated seat switch				Continuity	
Connector	Terminal				
	(+)*	(-)*			
M178	5	6	Existed	Not existed	
	6	5	Not existed		

*For a digital tester.

NOTE:

- Use a tester that can perform LED (light-emitting diode) measurement.
- The polarity (+ and -) reverses when checking using an analog tester.

Is the inspection result normal?

YES >> Heated seat switch is OK.

NO >> Replace heated seat switch. Refer to [SE-151, "Removal and Installation".](#)


POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT

Wiring Diagram - POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER) - INFOID:000000005568536

POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)



2009/2016

JCJWA1110GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)

POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)					
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	BL	-	63	R	-
2	WIRE TO WIRE	-	64	G	-
3	SHIELD	-	65	SHIELD	-
4	WIRE TO WIRE	-	66	W	-
5	SHIELD	-	67	V	-
6	SB	-	68	SB	-
7	SB	-	69	SHIELD	-
8	SB	-	70	W	-
9	SB	-	73	SB	-
10	SB	-	74	L	-
11	SB	-	75	W	-
12	BR	-	76	BR	-
13	R	-	77	R	-
14	G	-	78	P	-
15	GR	-	79	GR	-
16	SB	-	83	O	-
17	V	-	85	V	-
18	B	-	86	LG	-
19	L	-	87	Y	-
20	P	-	88	R	-
21	BR	-	89	B	-
22	Y	-	90	O	-
23	P	-	91	G	-
24	B	-	92	BR	-
25	R	-	93	G	-
26	BR	-	94	SB	-
27	Y	-	95	G	-
28	P	-	96	Y	-
29	BR	-	97	W	-
30	SB	-	98	GR	-
31	SHIELD	-	32	W	-
33	SB	-	34	L	-
35	P	-	36	L	-
37	P	-	38	BR	-
39	Y	-	40	Y	-
41	Y	-	42	Y	-
43	GR	-	44	GR	-
45	G	-	46	G	-
47	B	-	48	G	-
49	G	-	50	V	-
51	P	-	52	P	-
53	L	-	54	L	-
55	SHIELD	-	56	SHIELD	-
57	SB	-	58	SB	-
59	SB	-	60	GR	-
61	SB	-	62	SHIELD	-
63	R	-	64	R	-
65	B	-	66	B	-
67	V	-	68	V	-
69	LG	-	70	LG	-
71	Y	-	72	Y	-
73	R	-	74	R	-
75	B	-	76	B	-
77	V	-	78	V	-
79	LG	-	80	LG	-
81	Y	-	82	Y	-
83	R	-	84	R	-
85	B	-	86	B	-
87	V	-	88	V	-
89	LG	-	90	LG	-
91	Y	-	92	Y	-
93	R	-	94	R	-
95	B	-	96	B	-
97	V	-	98	V	-
99	LG	-	100	LG	-

JCJWA1111GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

M

T

G

I

—

SE

K

M

Z

O

P

POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)

Connector No. B018		
Connector Name	LIFTING MOTOR (REAR)	
Connector Type	NS50PFW-CS	
		
Terminal No.	Color of Wire	Signal Name [Specification]
7	L/Y	—
8	L	—



Connector No. E108		
Connector Name	WIRE TO WIRE	
Connector Type	TH80PFW-CS16-TM4	
		



Connector No. MI		
Connector Name	FUSE BLOCK (J-B)	
Connector Type	NS50FW-H2	
		
Terminal No.	Color of Wire	Signal Name [Specification]
56	BR	—
57	BR	—
59	W	—
60	G	—
61	G	—
62	SB	—
63	W	—
64	B	—
65	G	—
66	R	—
67	SHIELD	—
68	Y	—
69	LG	—
70	W	—
71	R	—
72	Y	—
73	B	—
74	BR	— [With ICC]
75	G	— [Without ICC]
76	W	— [With ICC]
77	R	— [Without ICC]
78	P	— [Without ICC]
78	L	— [With ICC]
78	BR	— [Without ICC]
79	Y	— [With ICC]

JCJWA1112GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)		
Connector No.	Signal Name [Specification]	Terminal No.
M6	WIRE TO WIRE	49 L
Connector Name		50 P
Connector Type	THB8MW-CS16-TM4	51 BR
		52 L
		53 P
		54 Y
		56 BR
		57 G
		59 W
		60 L
		61 G
		62 SG
		63 G
		64 B
		65 W
		66 R
		67 SHIELD
		68 GR
		70 LG
		71 LG
		72 Y
		73 SB
		74 BR
		74 L
		75 G
		76 W
		77 R
		78 O
		79 BR
		80 V
		81 SB
		82 SB
		83 V
		84 G
		85 L
		86 P
		87 W
		89 GR
		90 SHIELD
		91 W
		92 Y
		93 BR
		94 P
		95 GR
		96 W
		97 L
		98 SHIELD
POWER SEAT (WITH AUTOMATIC DRIVE POSITIONER)		
Connector No.	Signal Name [Specification]	Terminal No.
M6	WIRE TO WIRE	49 V
Connector Name		50 SB
Connector Type	THB8MW-CS16-TM4	100 SB
		101 P
		102 L
		103 SHIELD
		104 R
		105 G
		106 SB
		107 V
		108 LG
		109 SHIELD
		110 W
		111 G
		112 R
		113 B
		114 BR
		115 P
		116 V
		117 SB
		118 Y
		119 O
		120 L
		121 W
		122 P
		123 BR
		124 Y
		125 SB
		126 V
		127 G
		128 G
		129 L
		130 G
		131 P
		132 G
		133 B
		134 W
		135 R
		136 SHIELD
		137 V
		138 O
		139 BR
		140 Y
		141 W
		142 O
		143 O
		144 G
		145 W
		146 G
		147 G

JCJWA1113GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

POWER SEAT FOR DRIVER SIDE (WITHOUT AUTOMATIC DRIVE POSITIONER)

Connector No.	M119
Connector Name	BGM (BODY CONTROL MODULE)
Connector Type	MINI-FE-LC
	



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	W	POWER WINDOW POWER SUPPLY (BAT)
3	Y	POWER WINDOW POWER SUPPLY (MAP)

Connector No.	M119
Connector Name	BGM (BODY CONTROL MODULE)
Connector Type	MINI-FE-LC



Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	L	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GRD
14	W	PUSH-BUTTON IGNITION SW (L/GND)
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)
18	O	TURN SIGNAL LH (FRONT)
19	V	ROOM LAMP TIMER CONTROL

JCJWA1114GB

POWER SEAT


< DTC/CIRCUIT DIAGNOSIS >

Wiring Diagram - POWER SEAT FOR PASSENGER SIDE -

INFOID:0000000005568537

POWER SEAT FOR PASSENGER SIDE

 8W : With 8-way power passenger's seat



Digitized by srujanika@gmail.com

30009/07/16

JCJWA1115GE

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT FOR PASSENGER SIDE

Connector No. B70101

Connector Name WIRE TO WIRE

Connector Type TH80FW-CS16-TH4



Terminal No. Signal Name [Specification]

82 LG

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-

-


</div

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT FOR PASSENGER SIDE

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	THBDFW-CS16-TH4



Terminal No.	Color	Signal Name [Specification]	Signal Name [Specification]	Terminal No.	Color	Signal Name [Specification]
1	R	-	-	64	B	-
2	W	-	-	65	G	-
3	B	-	-	66	R	-
4	GR	-	-	67	SHIELD	-
5	GR	-	-	68	Y	-
8	Y	-	-	69	LG	-
9	BR	-	-	70	W	-
10	O	-	-	71	R	-
11	SB	-	-	72	Y	-
12	O	-	-	73	B	-
13	L	-	-	74	BR	-
14	R	-	-	74	L	-
15	P	-	-	75	G	-
16	V	-	-	75	W	-
17	SE	-	-	76	Y	-
18	V	-	-	76	LG	-
20	O	-	-	77	R	-
21	L	-	-	77	P	-
22	V	-	-	78	LG	-
23	G	-	-	78	BR	-
24	P	-	-	79	Y	-
25	Y	-	-	79	L	-
26	V	-	-	80	SB	-
27	W	-	-	81	R	-
28	G	-	-	82	SE	-
31	O	-	-	83	O	-
32	W	-	-	84	G	-
33	B	-	-	85	L	-
34	R	-	-	86	P	-
35	G	-	-	87	V	-
36	SHIELD	-	-	89	GR	-
37	V	-	-	90	SHIELD	-
38	BR	-	-	91	W	-
39	O	-	-	92	Y	-
41	W	-	-	93	V	-
42	G	-	-	94	LG	-
43	BR	-	-	95	O	-
45	W	-	-	96	P	-
				97	R	-

JCJWA1117GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT FOR PASSENGER SIDE

Connector No. M6

Connector Name WIRE TO WIRE

Connector Type TH80MW-CS16-TM4



Terminal Color No. Signal Name [Specification]

49	L	-	99	V	-
50	P	-	100	SB	-
51	BR	-	75	W	-
52	L	-	80	V	-
53	P	-	81	SB	-
54	Y	-	82	V	-
56	BR	-	83	P	-
57	G	-	84	R	-
59	W	-	85	L	-
60	L	-	86	O	-
61	G	-	87	L	-
62	SB	-	88	P	-
63	G	-	91	V	-
64	B	-	92	G	-
65	W	-	94	G	-
66	R	-	95	W	-
67	SHIELD	-	96	G	-
68	Y	-	97	Y	-
69	GR	-	98	BR	-
70	LG	-	99	V	- [With BOSE audio]
71	LG	-	100	P	- [Without BOSE audio]
72	Y	-	100	SB	- [With BOSE audio]
73	SB	-	100	L	- [Without BOSE audio]
74	BR	- [With ICC]	10	W	-
74	L	- [Without ICC]	15	SB	-
75	G	-	16	Y	-
76	W	- [With ICC]	17	BR	-
76	GR	- [Without ICC]	26	BR	-
77	R	- [With ICC]	27	LG	-
77	P	- [Without ICC]	28	Y	-
78	L	- [With ICC]	29	SB	-
78	R	- [Without ICC]	30	V	-
79	Y	- [With ICC]	51	R	-
79	W	- [Without ICC]	52	L	-
80	SB	-	55	W	-
81	SB	-	56	B	-
82	SB	-	57	R	-
83	V	-	58	G	-
84	G	-	59	SHIELD	-
85	L	-	60	V	-
86	P	-	61	LG	-
87	W	-	62	BR	-
89	GR	-	63	L	-
90	SHIELD	-	64	LG	-
91	W	-	65	B	-
92	Y	-	66	R	-
93	BR	-	67	W	-
94	P	-	68	SHIELD	-
95	GR	-	69	V	-
96	W	-	70	Y	-
97	L	-	71	SB	-
98	SHIELD	-	72	W	-

SE

JCJWA1118GB

POWER SEAT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT FOR PASSENGER SIDE

Connector No.	M.19
Connector Name	BOM (BODY CONTROL MODULE)
Connector Type	NS15FW-CS



4	5	6	7	8	9	10
11	12	13	14	15	16	17

Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	INTERIOR ROOM LAMP POWER SUPPLY
5	L	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BA1 (FUSE)
13	B	GRD
14	W	PUSH-BUTTON IGNITION SW (L GND)
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)
18	O	TURN SIGNAL LH (FRONT)
19	V	ROOM LAMP TIMER CONTROL

JCJWA1119GB

LUMBAR SUPPORT


< DTC/CIRCUIT DIAGNOSIS >

LUMBAR SUPPORT

Wiring Diagram - LUMBAR SUPPORT SYSTEM -

INFOID:0000000005568538

LUMBAR SUPPORT




* : This connector is not shown in "Harness Layout".

2008/08/28

JCJWA0755GB

LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >



JCJWA1120GB

LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

SE

K

L

M


N

O

P

LUMBAR SUPPORT

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-1M4



Signal Name [Specification]

Terminal No.	Color of Wire	Signal Name	Specification
1	R	-	-
2	W	-	-
3	G	-	-
4	GR	-	-
5	GR	-	-
8	Y	-	-
9	BR	-	-
10	O	-	-
11	SB	-	-
12	O	-	-
13	L	-	-
14	R	-	-
15	P	-	-
16	Y	-	-
17	SB	-	-
18	Y	-	-
20	O	-	-
21	L	-	-
22	Y	-	-
23	G	-	-
24	P	-	-
25	Y	-	-
26	Y	-	-
27	W	-	-
28	G	-	-
31	O	-	-
32	W	-	-
33	B	-	-
34	R	-	-
35	G	-	-
36	SHEILD	-	-
37	V	-	-
38	BR	-	-
39	O	-	-
41	W	-	-
42	G	-	-
43	BR	-	-
45	W	-	-
49	L	-	-
50	P	-	-
51	L	-	-
52	L	-	-
53	P	-	-
54	O	-	-
56	BR	-	-
57	BR	-	-
59	W	-	-
60	LG	-	-
61	G	-	-
62	SB	-	-
63	W	-	-
64	B	-	-
65	G	-	-
66	R	-	-
67	SHEILD	-	-
68	Y	-	-
69	LG	-	-
70	W	-	-
71	R	-	-
72	Y	-	-
73	Y	-	-
74	BR	-	-
74	L	-	-
75	G	-	-
75	W	-	-
76	W	-	-
76	Y	-	-
77	R	-	-
77	P	-	-
78	L	-	-
78	LG	-	-
79	Y	-	-
79	L	-	-
80	SB	-	-
81	R	-	-
82	SB	-	-
83	O	-	-
84	G	-	-
85	L	-	-
86	P	-	-
87	V	-	-
89	GR	-	-
90	SHEILD	-	-
91	W	-	-
92	Y	-	-
93	V	-	-
94	LG	-	-
95	O	-	-
96	P	-	-
97	R	-	-

JCJWA1121GB

LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >

LUMBAR SUPPORT		M6		M7	
Connector No.	WIRE TO WIRE	49	L	49	V
Connector Name		50	P	50	R
Connector Type	THB8MW-CS16-TM4	51	BR	51	P
		52	L	52	L
		53	P	53	P
		54	Y	54	Y
		56	BR	56	BR
		57	G	57	G
		59	W	59	W
		60	L	60	L
		61	G	61	G
		62	SG	62	SG
		63	G	63	G
		64	B	64	B
		65	W	65	W
		66	R	66	R
		67	SHEILD	67	SHEILD
		68	GR	68	GR
		69		69	
Terminal No.	Signal Name [Specification]	70	LG	70	LG
1	W	71	LG	71	LG
2	R	72	Y	72	Y
3	B	73	SG	73	SG
4	SHEILD	74	BR	74	BR
5	G	74		74	
8	Y	75	G	75	G
9	BR	76	W	76	W
10	R	76	GR	76	GR
11	BR	77	R	77	R
12	O	77	P	77	P
13	L	78	L	78	L
14	R	78		78	
15	P	79	Y	79	Y
16	V	79	W	79	W
17	SG	80	SG	80	SG
18	V	81	SG	81	SG
20	O	82	SG	82	SG
21	L	83	V	83	V
22	W	84	G	84	G
23	P	85	L	85	L
24	BR	86	P	86	P
25	Y	87	W	87	W
26	V	89	GR	89	GR
27	G	90	SHEILD	90	SHEILD
28	G	91	W	91	W
31	L	92	Y	92	Y
32	G	93	BR	93	BR
33	B	94	P	94	P
34	W	95	GR	95	GR
35	R	96	W	96	W
36	SHEILD	97	L	97	L
37	V	98	SHEILD	98	SHEILD
		99	V	99	V
		100	SG	100	SG

LUMBAR SUPPORT		M6		M7	
Connector No.	WIRE TO WIRE	49	L	49	V
Connector Name		50	P	50	R
Connector Type	THB8MW-CS16-TM4	51	BR	51	P
		52	L	52	L
		53	P	53	P
		54	Y	54	Y
		56	BR	56	BR
		57	G	57	G
		59	W	59	W
		60	L	60	L
		61	G	61	G
		62	SG	62	SG
		63	G	63	G
		64	B	64	B
		65	W	65	W
		66	R	66	R
		67	SHEILD	67	SHEILD
		68	GR	68	GR
Terminal No.	Signal Name [Specification]	69		69	
1	W	70	LG	70	LG
2	R	71	LG	71	LG
3	B	72	Y	72	Y
4	SHEILD	73	SG	73	SG
5	G	74	BR	74	BR
8	Y	75	G	75	G
9	BR	76	W	76	W
10	R	76	GR	76	GR
11	BR	77	R	77	R
12	O	77	P	77	P
13	L	78	L	78	L
14	R	78		78	
15	P	79	Y	79	Y
16	V	79	W	79	W
17	SG	80	SG	80	SG
18	V	81	SG	81	SG
20	O	82	SG	82	SG
21	L	83	V	83	V
22	W	84	G	84	G
23	P	85	L	85	L
24	BR	86	P	86	P
25	Y	87	W	87	W
26	V	89	GR	89	GR
27	G	90	SHEILD	90	SHEILD
28	G	91	W	91	W
31	L	92	Y	92	Y
32	G	93	BR	93	BR
33	B	94	P	94	P
34	W	95	GR	95	GR
35	R	96	W	96	W
36	SHEILD	97	L	97	L
37	V	98	SHEILD	98	SHEILD
		99	V	99	V
		100	SG	100	SG

LUMBAR SUPPORT		M6		M7	
Connector No.	WIRE TO WIRE	49	L	49	V
Connector Name		50	P	50	R
Connector Type	THB8MW-CS16-TM4	51	BR	51	P
		52	L	52	L
		53	P	53	P
		54	Y	54	Y
		56	BR	56	BR
		57	G	57	G
		59	W	59	W
		60	L	60	L
		61	G	61	G
		62	SG	62	SG
		63	G	63	G
		64	B	64	B
		65	W	65	W
		66	R	66	R
		67	SHEILD	67	SHEILD
		68	GR	68	GR
Terminal No.	Signal Name [Specification]	69		69	
1	W	70	LG	70	LG
2	R	71	LG	71	LG
3	B	72	Y	72	Y
4	SHEILD	73	SG	73	SG
5	G	74	BR	74	BR
8	Y	75	G	75	G
9	BR	76	W	76	W
10	R	76	GR	76	GR
11	BR	77	R	77	R
12	O	77	P	77	P
13	L	78	L	78	L
14	R	78		78	
15	P	79	Y	79	Y
16	V	79	W	79	W
17	SG	80	SG	80	SG
18	V	81	SG	81	SG
20	O	82	SG	82	SG
21	L	83	V	83	V
22	W	84	G	84	G
23	P	85	L	85	L
24	BR	86	P	86	P
25	Y	87	W	87	W
26	V	89	GR	89	GR
27	G	90	SHEILD	90	SHEILD
28	G	91	W	91	W
31	L	92	Y	92	Y
32	G	93	BR	93	BR
33	B	94	P	94	P
34	W	95	GR	95	GR
35	R	96	W	96	W
36	SHEILD	97	L	97	L
37	V	98	SHEILD	98	SHEILD
		99	V	99	V
		100	SG	100	SG

JCJWA1122GB

LUMBAR SUPPORT

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

SE

K


L

M

N

O

P



JCJWA1123GB

REAR SEATBACK RELEASE CONTROL

< DTC/CIRCUIT DIAGNOSIS >


REAR SEATBACK RELEASE CONTROL

Wiring Diagram - REAR SEATBACK RELEASE CONTROL -

INFOID:000000005568539

REAR SEATBACK RELEASE CONTROL

* : This connector is not shown in "Harness Layout".



28/08/2008

JCJWA0769GI

REAR SEATBACK RELEASE CONTROL

< DTC/CIRCUIT DIAGNOSIS >

REAR SEATBACK RELEASE CONTROL

Connector No.	BB9
Connector Name	REAR SEATBACK RELEASE SWITCH (LH)
Connector Type	TH20FW-IV
	

WIRE TO WIRE

TH20FW-CS16-TM4

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

—

REAR SEATBACK RELEASE CONTROL

< DTC/CIRCUIT DIAGNOSIS >

REAR SEATBACK RELEASE CONTROL

Connector No.	BS46	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	REAR SEATBACK RELEASE RELAY (LH)	3	G	-	1	LG	-	1	LG/B	-
Connector Type	MSDFL-M2-LC	4	GB	-	2	R/W	-	2	LG	-
		5	GR	-	3	G	-	3	GR	-
		6	SB	-	4	GB	-	4	GR/B	-
		8	O	-	5	GR	-	5	GR/R	-
		9	Y	-	6	SB	-	6	LG/W	-
		10	B	-	7	W	-	7	LG	-
		11	V/W	-	8	W	-	8	LG	-
		12	W	-	9	Y	-	9	LG	-
		13	L	-	10	B	-	10	LG	-
		14	LG	-	11	V/W	-	11	LG	-
		15	L/W	-	12	W	-	12	LG	-
		17	GR	-	13	L	-	13	LG	-
		18	GR/B	-	14	LB	-	14	LG/B	-
		19	GR/R	-	22	B	-	22	LG	-
		22	B	-						

Connector No.	BS247	Terminal No.	Color of Wire	Signal Name [Specification]	Connector No.	BS503	Terminal No.	Color of Wire	Signal Name [Specification]	Connector No.	BS10	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	REAR SEATBACK RELEASE RELAY (RH)	1	BR	-	Connector Name	WIRE TO WIRE	1	LG	-	Connector Name	WIRE TO WIRE	1	LG	-
Connector Type	MSDFL-M2-LC	2	O	-	Connector Type	NSUDFW-CS	2	W	-	Connector Type	NSUDFW-CS	2	W	-
		3	W	-			3	W	-			3	W	-
		5	W	-			4	W	-			4	W	-

Connector No.	BS501	Terminal No.	Color of Wire	Signal Name [Specification]	Connector No.	BS501	Terminal No.	Color of Wire	Signal Name [Specification]	Connector No.	BS501	Terminal No.	Color of Wire	Signal Name [Specification]
Connector Name	WIRE TO WIRE	1	R	-	Connector Name	WIRE TO WIRE	1	LG/B	-	Connector Name	WIRE TO WIRE	1	LG/B	-
Connector Type	NSUDFW-CS	2	Y	-	Connector Type	NSUDFW-CS	2	R/W	-	Connector Type	NSUDFW-CS	2	LG	-
		3	W	-			3	G	-			3	GR	-
		5	W	-			4	GB	-			4	GR/B	-
							5	GR	-			5	GR/R	-
							6	SB	-			6	LG/W	-
							8	O	-			8	LG	-
							9	Y	-			9	LG/B	-
							10	B	-			10	B	-
							11	V/W	-			11	W	-

JCJWA1139GB

REAR SEATBACK RELEASE CONTROL

< DTC/CIRCUIT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

SE

K

M

N

O

P

REAR SEATBACK RELEASE CONTROL

Connector No.	EW06
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-1M4



49	L	—	—
50	P	—	—
51	L	—	—
52	L	—	—
53	P	—	—
54	O	—	—
56	BR	—	—
57	BR	—	—
59	W	—	—
60	LG	—	—
61	G	—	—
62	SB	—	—
63	W	—	—
64	B	—	—
65	G	—	—
66	R	—	—
67	SHIELD	—	—
68	Y	—	—
69	LG	—	—
70	W	—	—
71	R	—	—
72	Y	—	—
73	Y	—	—
74	BR	—	—
74	L	—	—
75	G	—	—
75	W	—	—
76	W	—	—
76	Y	—	—
76	R	—	—
77	P	—	—
78	L	—	—
78	BR	—	—
78	Y	—	—
79	Y	—	—
79	L	—	—
80	SB	—	—
81	R	—	—
82	SB	—	—
83	O	—	—
84	G	—	—
85	L	—	—
86	P	—	—
87	V	—	—
89	GR	—	—
90	SHIELD	—	—
91	W	—	—
92	Y	—	—
93	V	—	—
94	LG	—	—
95	O	—	—
96	P	—	—
97	R	—	—

Connector No.	M2
Connector Name	FUSE BLOCK (J-B)
Connector Type	NS10FW-CS

Terminal No.	Signal Name [Specification]	Signal Name [Specification]
1	R	—
2	W	—
3	G	—
4	GR	—
5	GR	—
8	Y	—
9	BR	—
10	O	—
11	SB	—
12	O	—
13	L	—
14	R	—
15	P	—
16	Y	—
17	SB	—
18	V	—
20	O	—
21	L	—
22	Y	—
23	G	—
24	P	—
25	Y	—
26	V	—
27	W	—
28	G	—
31	O	—
32	W	—
33	B	—
34	R	—
35	G	—
36	SHIELD	—
37	V	—
38	BR	—
39	O	—
41	W	—
42	G	—
43	BR	—
45	W	—

JCJWA1140GB

REAR SEATBACK RELEASE CONTROL

< DTC/CIRCUIT DIAGNOSIS >

REAR SEATBACK RELEASE CONTROL		Signal Name [Specification]		Signal Name [Specification]	
Connector No.	M6				
Connector Name	WIRE TO WIRE				
Connector Type	THB0MW-CS16-TM4				
					
Terminal No.					
Color of Wire					
1	W	-	-	1	L
2	R	-	-	2	G
3	B	-	-	3	GR
4	SHIELD	-	-	4	SB
5	Y	-	-	5	BR
6	BR	-	-	6	V
7	R	-	-	7	W
8	Y	-	-	8	- [Without ICC]
9	BR	-	-	9	- [Without ICC]
10	R	-	-	10	- [Without BOSE audio]
11	BR	-	-	11	- [Without BOSE audio]
12	O	-	-	12	- [Without BOSE audio]
13	L	-	-	13	- [Without BOSE audio]
14	R	-	-	14	- [Without BOSE audio]
15	P	-	-	15	- [Without BOSE audio]
16	V	-	-	16	- [Without BOSE audio]
17	SB	-	-	17	- [Without BOSE audio]
18	V	-	-	18	- [Without BOSE audio]
20	O	-	-	20	- [Without BOSE audio]
21	L	-	-	21	- [Without BOSE audio]
22	W	-	-	22	- [Without BOSE audio]
23	P	-	-	23	- [Without BOSE audio]
24	BR	-	-	24	- [Without BOSE audio]
25	Y	-	-	25	- [Without BOSE audio]
26	V	-	-	26	- [Without BOSE audio]
27	G	-	-	27	- [Without BOSE audio]
28	G	-	-	28	- [Without BOSE audio]
31	L	-	-	31	- [Without BOSE audio]
32	G	-	-	32	- [Without BOSE audio]
33	B	-	-	33	- [Without BOSE audio]
34	W	-	-	34	- [Without BOSE audio]
35	R	-	-	35	- [Without BOSE audio]
36	SHIELD	-	-	36	- [Without BOSE audio]
37	V	-	-	37	- [Without BOSE audio]
38	O	-	-	38	- [Without BOSE audio]
39	BR	-	-	39	- [Without BOSE audio]
41	W	-	-	41	- [Without BOSE audio]
42	O	-	-	42	- [Without BOSE audio]
43	O	-	-	43	- [Without BOSE audio]
45	W	-	-	45	- [Without BOSE audio]
49	L	-	-	49	- [Without BOSE audio]
50	P	-	-	50	- [Without BOSE audio]
51	BR	-	-	51	- [Without BOSE audio]
52	L	-	-	52	- [Without BOSE audio]
53	P	-	-	53	- [Without BOSE audio]
54	Y	-	-	54	- [Without BOSE audio]
56	BR	-	-	56	- [Without BOSE audio]
57	G	-	-	57	- [Without BOSE audio]
59	W	-	-	59	- [Without BOSE audio]
60	L	-	-	60	- [Without BOSE audio]
61	G	-	-	61	- [Without BOSE audio]
62	SG	-	-	62	- [Without BOSE audio]
63	G	-	-	63	- [Without BOSE audio]
65	W	-	-	65	- [Without BOSE audio]
66	R	-	-	66	- [Without BOSE audio]
67	SHIELD	-	-	67	- [Without BOSE audio]
68	GR	-	-	68	- [Without BOSE audio]
70	LG	-	-	70	- [Without BOSE audio]
71	LG	-	-	71	- [Without BOSE audio]
72	Y	-	-	72	- [Without BOSE audio]
73	SB	-	-	73	- [Without BOSE audio]
74	BR	-	-	74	- [Without BOSE audio]
75	G	-	-	75	- [Without BOSE audio]
76	W	-	-	76	- [Without BOSE audio]
77	R	-	-	77	- [Without BOSE audio]
77	P	-	-	77	- [Without BOSE audio]
78	L	-	-	78	- [Without BOSE audio]
78	R	-	-	78	- [Without BOSE audio]
79	Y	-	-	79	- [Without BOSE audio]
79	W	-	-	79	- [Without BOSE audio]
80	SB	-	-	80	- [Without BOSE audio]
81	SB	-	-	81	- [Without BOSE audio]
82	SB	-	-	82	- [Without BOSE audio]
83	V	-	-	83	- [Without BOSE audio]
84	G	-	-	84	- [Without BOSE audio]
85	L	-	-	85	- [Without BOSE audio]
86	P	-	-	86	- [Without BOSE audio]
87	W	-	-	87	- [Without BOSE audio]
89	GR	-	-	89	- [Without BOSE audio]
90	SHIELD	-	-	90	- [Without BOSE audio]
91	W	-	-	91	- [Without BOSE audio]
92	Y	-	-	92	- [Without BOSE audio]
93	BR	-	-	93	- [Without BOSE audio]
94	P	-	-	94	- [Without BOSE audio]
95	GR	-	-	95	- [Without BOSE audio]
96	W	-	-	96	- [Without BOSE audio]
97	L	-	-	97	- [Without BOSE audio]
98	SHIELD	-	-	98	- [Without BOSE audio]
99	V	-	-	99	- [Without BOSE audio]
100	SB	-	-	100	- [Without BOSE audio]
100	L	-	-	100	- [Without BOSE audio]
100	W	-	-	100	- [Without BOSE audio]
101	W	-	-	101	- [Without BOSE audio]
102	Y	-	-	102	- [Without BOSE audio]
103	Y	-	-	103	- [Without BOSE audio]
104	SB	-	-	104	- [Without BOSE audio]
105	BR	-	-	105	- [Without BOSE audio]
106	V	-	-	106	- [Without BOSE audio]
107	W	-	-	107	- [Without BOSE audio]
108	W	-	-	108	- [Without BOSE audio]
109	Y	-	-	109	- [Without BOSE audio]
110	Y	-	-	110	- [Without BOSE audio]
111	SB	-	-	111	- [Without BOSE audio]
112	BR	-	-	112	- [Without BOSE audio]
113	O	-	-	113	- [Without BOSE audio]
114	O	-	-	114	- [Without BOSE audio]
115	L	-	-	115	- [Without BOSE audio]
116	R	-	-	116	- [Without BOSE audio]
117	SB	-	-	117	- [Without BOSE audio]
118	V	-	-	118	- [Without BOSE audio]
119	V	-	-	119	- [Without BOSE audio]
120	O	-	-	120	- [Without BOSE audio]
121	L	-	-	121	- [Without BOSE audio]
122	W	-	-	122	- [Without BOSE audio]
123	P	-	-	123	- [Without BOSE audio]
124	BR	-	-	124	- [Without BOSE audio]
125	Y	-	-	125	- [Without BOSE audio]
126	V	-	-	126	- [Without BOSE audio]
127	G	-	-	127	- [Without BOSE audio]
128	G	-	-	128	- [Without BOSE audio]
129	L	-	-	129	- [Without BOSE audio]
130	R	-	-	130	- [Without BOSE audio]
131	SB	-	-	131	- [Without BOSE audio]
132	V	-	-	132	- [Without BOSE audio]
133	B	-	-	133	- [Without BOSE audio]
134	W	-	-	134	- [Without BOSE audio]
135	R	-	-	135	- [Without BOSE audio]
136	SHIELD	-	-	136	- [Without BOSE audio]
137	V	-	-	137	- [Without BOSE audio]
138	O	-	-	138	- [Without BOSE audio]
139	BR	-	-	139	- [Without BOSE audio]
141	W	-	-	141	- [Without BOSE audio]
142	O	-	-	142	- [Without BOSE audio]
143	O	-	-	143	- [Without BOSE audio]
145	W	-	-	145	- [Without BOSE audio]
146	Y	-	-	146	- [Without BOSE audio]
147	Y	-	-	147	- [Without BOSE audio]
148	SB	-	-	148	- [Without BOSE audio]
149	BR	-	-	149	- [Without BOSE audio]
150	V	-	-	150	- [Without BOSE audio]
151	W	-	-	151	- [Without BOSE audio]
152	Y	-	-	152	- [Without BOSE audio]
153	Y	-	-	153	- [Without BOSE audio]
154	SB	-	-	154	- [Without BOSE audio]
155	BR	-	-	155	- [Without BOSE audio]
156	V	-	-	156	- [Without BOSE audio]
157	W	-	-	157	- [Without BOSE audio]
158	Y	-	-	158	- [Without BOSE audio]
159	Y	-	-	159	- [Without BOSE audio]
160	SB	-	-	160	- [Without BOSE audio]
161	BR	-	-	161	- [Without BOSE audio]
162	V	-	-	162	- [Without BOSE audio]
163	W	-	-	163	- [Without BOSE audio]
164	Y	-	-	164	- [Without BOSE audio]
165	Y	-	-	165	- [Without BOSE audio]
166	SB	-	-	166	- [Without BOSE audio]
167	BR	-	-	167	- [Without BOSE audio]
168	V	-	-	168	- [Without BOSE audio]
169	W	-	-	169	- [Without BOSE audio]
170	Y	-	-	170	- [Without BOSE audio]
171	Y	-	-	171	- [Without BOSE audio]
172	SB	-	-	172	- [Without BOSE audio]
173	BR	-	-	173	- [Without BOSE audio]
174	V	-	-	174	- [Without BOSE audio]
175	W	-	-	175	- [Without BOSE audio]
176	Y	-	-	176	- [Without BOSE audio]
177	Y	-	-	177	- [Without BOSE audio]
178	SB	-	-	178	- [Without BOSE audio]
179	BR	-	-	179	- [Without BOSE audio]
180	V	-	-	180	- [Without BOSE audio]
181	W	-	-	181	- [Without BOSE audio]
182	Y	-	-	182	- [Without BOSE audio]
183	Y	-	-	183	- [Without BOSE audio]
184	SB	-	-	184	- [Without BOSE audio]
185	BR	-	-	185	- [Without BOSE audio]
186	V	-	-	186	- [Without BOSE audio]
187	W	-	-	187	- [Without BOSE audio]
188	Y	-	-	188	- [Without BOSE audio]
189	Y	-	-	189	- [Without BOSE audio]
190	SB	-	-	190	- [Without BOSE audio]
191	BR	-	-	191	- [Without BOSE audio]
192	V	-	-	192	- [Without BOSE audio]
193	W	-	-	193	- [Without BOSE audio]
194	Y	-	-	194	- [Without BOSE audio]
195	Y	-	-	195	- [Without BOSE audio]
196	SB	-	-	196	- [Without BOSE audio]
197	BR	-	-	197	- [Without BOSE audio]
198	V	-	-	198	- [Without BOSE audio]
199	W	-	-	199	- [Without BOSE audio]
200	Y	-	-	200	- [Without BOSE audio]
201	Y	-	-	201	- [Without BOSE audio]
202	SB	-	-	202	- [Without BOSE audio]
203	BR	-	-	203	- [Without BOSE audio]
204	V	-	-	204	- [Without BOSE audio]
205	W	-	-	205	- [Without BOSE audio]
206	Y	-	-	206	- [Without BOSE audio]
207	Y	-	-	207	- [Without BOSE audio]
208	SB	-	-	208	- [Without BOSE audio]
209	BR	-	-	209	- [Without BOSE audio]
210	V	-	-	210	- [Without BOSE audio]
211	W	-	-	211	- [Without BOSE audio]
212	Y	-	-	212	- [Without BOSE audio]
213	Y	-	-	213	- [Without BOSE audio]
214	SB	-	-	214	- [Without BOSE audio]
215	BR	-	-	215	- [Without BOSE audio]
216	V	-	-	216	- [Without BOSE audio]
217	W	-	-	217	- [Without BOSE audio]
218	Y	-	-	218	- [Without BOSE audio]
219	Y	-	-	219	- [Without BOSE audio]
220	SB	-	-	220	- [Without BOSE audio]
221	BR	-	-	221	- [Without BOSE audio]
222	V	-	-	222	- [Without BOSE audio]
223	W	-	-	223	- [Without BOSE audio]
224	Y	-	-	224	- [Without BOSE audio]
225	Y	-	-	225	- [Without BOSE audio]
226	SB	-	-	226	- [Without BOSE audio]
227	BR	-	-	227	- [Without BOSE audio]
228	V	-	-	228	- [Without BOSE audio]
229	W	-	-	229	- [Without BOSE audio]
230	Y	-	-	230	- [Without BOSE audio]
231	Y	-	-	231	- [Without BOSE audio]
232	SB	-	-	232	- [Without BOSE audio]
233	BR	-	-	233	- [Without BOSE audio]
234	V	-	-	234	- [Without BOSE audio]
235	W	-	-	235	- [Without BOSE audio]
236	Y	-	-	236	- [Without BOSE audio]
237	Y	-	-	237	- [Without BOSE audio]
238	SB	-	-	238	- [Without BOSE audio]
239	BR	-	-	239	- [Without BOSE audio]
240	V	-	-	240	- [Without BOSE audio]
241	W	-	-	241	- [Without BOSE audio]
242	Y	-	-	242	- [Without BOSE audio]
243	Y	-	-	243	- [Without BOSE audio]
244	SB	-	-	244	- [Without BOSE audio]
245	BR	-	-	245	- [Without BOSE audio]
246	V	-	-	246	- [Without BOSE audio]
247	W	-	-	247	- [Without BOSE audio]
248	Y	-	-	248	- [Without BOSE audio]
249	Y	-	-	249	- [Without BOSE audio]
250	SB	-	-	250	- [Without BO

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


ECU DIAGNOSIS INFORMATION

REAR SEAT BACK POWER RETURN CONTROL UNIT

Reference Value

INFOID:000000005172783

TERMINAL LAYOUT




A. B227

B. B226

JMKIA1682ZZ



PHYSICAL VALUES

Rear seat back power return control unit

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)
(+)	(-)	Signal name	Input/ Output		
1 (V)	Ground	Ground (Motor sensor RH)	—	—	0
2 (Y)	Ground	Motor sensor (RH) input signal	Input	When the power return motor (RH) is operated	 JMKA0070GB
				When the pinch occurs	
3 (G)	Ground	Motor sensor (RH) Power supply	Input	When the power return motor is operated	Battery voltage
5 (GR)	Ground	Power return motor (LH) back- ward signal	Output	When the power return motor (LH) performs reverse operation	Battery voltage
				Other than the above	0
6 (L)	Ground	Power return motor (LH) for- ward signal	Output	When the power return motor (LH) performs return operation	Battery voltage
				Other than the above	0
7 (SB)	Ground	Power return motor (RH) back- ward signal	Output	When the power return motor (RH) performs reverse operation	Battery voltage
				Other than the above	0
8 (R)	Ground	Power return motor (RH) for- ward signal	Output	When the power return motor (RH) performs return operation	Battery voltage
				Other than the above	0
9 (P)	Ground	Ground (Motor sensor LH)	—	—	0

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)
(+)	(-)	Signal name	Input/ Output		
10 (BR)	Ground	Motor sensor (LH) input signal	Input	When the power return motor (LH) is operated	 JMKA0070GB
				When the pinch occurs	
11 (LG)	Ground	Motor sensor (LH) Power supply	Input	When the power return motor is operated	Battery voltage
13 (B)	Ground	Ground (power)	—	—	0
16 (W)	Ground	Battery power supply (power)	Input	—	Battery voltage
17 (Y)	Ground	Battery power supply (system)	Input	—	Battery voltage
20 (P)	Ground	Power return switch (RH) or rear seatback switch (RH) in UP direction input signal	Input	When pressing the power return switch (RH) or rear seatback switch (RH) in UP direction	0
				Other than the above	
21 (W)	Ground	Primary position limit switch (LH) input signal	Input	When the sector gear (LH) is in the initial position (other than low power consumption mode)	Battery voltage
				Other than the above	
22 (BR)	Ground	Primary position limit switch (RH) input signal	Input	When the sector gear (RH) is in the initial position (other than low power consumption mode)	Battery voltage
				Other than the above	
23 (O)	Ground	Ground (limit switch RH)	—	—	0
24 (BR)	Ground	Vehicle speed signal (8-pulse)	Input	When vehicle speed is approx.40 km/h (25MPH)	NOTE: Maximum voltage may be 12 V due to specifications (connected units)  SKIA6649J
28 (LG)	Ground	Power return switch (LH) or rear seatback switch in UP direction input signal	Input	When pressing the power return switch (LH) or rear seatback switch in UP direction	0
				Other than the above	
29 (G)	Ground	Return complete limit switch (LH) input signal	Input	When the rear seatback (LH) is in the return completion position (other than low power consumption mode)	Battery voltage
				Other than the above	

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (V) (Approx.)
(+)	(-)	Signal name	Input/ Output		
30 (R)	Ground	Return complete limit switch (RH) input signal	Input	When the rear seatback (RH) is in the return completion position (other than low power consump- tion mode)	Battery voltage
				Other than the above	0
31 (L)	Ground	Ground (limit switch LH)	—	—	0
32 (B)	Ground	Ground (system)	—	—	0

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

REAR SEAT BACK POWER RETURN CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - REAR SEATBACK POWER RETURN SYSTEM -

INFOID:0000000005568540

REAR SEATBACK POWER RETURN SYSTEM

*: This connector is not shown in "Harness Layout".




JCJWA0762GE

2008/08/28

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

* This connector is not shown in "Harness Layout".



JCJWA0763GB

REAR SEAT BACK POWER RETURN CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

REAR SEATBACK POWER RETURN SYSTEM

Connector No. B201

Connector Name REAR SEATBACK SWITCH (LH)

Connector Type TH00FW-1M4



Connector No. B227

Connector Name REAR SEATBACK POWER RETURN CONTROL UNIT


Connector Type SEATBW



Connector No. B226

Connector Name REAR SEATBACK POWER RETURN CONTROL UNIT


Connector Type YAA16FW



Connector No. B228

Connector Name REAR SEATBACK POWER RETURN CONTROL UNIT


Connector Type YAA16FW



Connector No. B229

Connector Name REAR SEATBACK POWER RETURN CONTROL UNIT

Connector Type YAA16FW



Connector No. B230

Connector Name REAR SEATBACK POWER RETURN CONTROL UNIT

Connector Type YAA16FW



JCJWA1132GB

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

REAR SEATBACK POWER RETURN SYSTEM

Connector No.	Wire to Wire
BR340	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
3	BR	-
4	P	-
5	W	-
6	G	-
8	G	-
9	L	-
10	B	-
11	W	-
12	W	-
13	R	-
14	O	-
15	BR	-
17	G	-
18	Y	-
19	V	-
22	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	P	-
3	B	-
5	W	-
6	W	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
4	G/B	-
5	G/R	-
6	SB	-
8	O	-
9	V	-
10	B	-
11	V/W	-
12	W	-
13	L	-
14	L/B	-
15	L/W	-
17	GR	-
18	GR/B	-
19	GR/R	-
22	E	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
4	G/B	-
5	G/R	-
6	SB	-
8	O	-
9	V	-
10	B	-
11	V/W	-
12	W	-
13	L	-
14	L/B	-
15	L/W	-
17	GR	-
18	GR/B	-
19	GR/R	-
22	E	-

Connector No.	WIRE TO WIRE
BZ239	
Connector Name	REAR SEATBACK SWITCH (RH)

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ241	
Connector Name	REAR SEATBACK RELEASE RELAY (RH)

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ243	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ247	
Connector Name	REAR SEATBACK RELEASE RELAY (RH)

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ248	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ249	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ250	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ251	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ252	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ253	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ254	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ255	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ256	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE
BZ257	
Connector Name	WIRE TO WIRE

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	P	-
5	W	-

Connector No.	WIRE TO WIRE

<tbl_r cells="2" ix="2" maxcspan="1" maxrspan="1" usedcols="

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

REAR SEATBACK POWER RETURN SYSTEM

Connector No.	B603	Connector No.	B505
Connector Name	WIRE TO WIRE	Connector Name	PRIMARY POSITION LIMIT SWITCH (RH)
Connector Type	NS104FW-CS	Connector Type	TK02FW
			

Terminal No.	1	Color of Wire	18	Signal Name [Specification]	14
	2	R/W	9	-	15
	3	G	8	-	
	4	GR	7	-	
	5	SB	6	-	
	6	0	5	-	
	7	V	4	-	
	8	Y	3	-	
	9	B	2	-	
	10	W	1	-	
	11	V/W		-	

Connector No.	B604	Connector No.	B506
Connector Name	POWER RETURN MOTOR ASSEMBLY (RH)	Connector Name	REAR SEATBACK LOCK ASSEMBLY (RH)
Connector Type	60388-0245	Connector Type	NS04FW-CS

Terminal No.	1	Color of Wire	14	Signal Name [Specification]	12
	2	R/W	13	-	1
	3	G	14	-	2
	4	GR	15	-	3
	5	SB	16	-	4
	6	0	17	-	5
	7	V	18	-	
	8	B	19	-	
	9	W	20	-	
	10	V/W		-	
	11			-	

Connector No.	B513	Connector No.	B511
Connector Name	REAR SEATBACK LOCK ASSEMBLY (LH)	Connector Name	POWER RETURN MOTOR ASSEMBLY (LH)
Connector Type	NS04FW-CS	Connector Type	60388-0245
			

Terminal No.	1	Color of Wire	14	Signal Name [Specification]	1
	2	R/W	15	-	2
	3	G	16	-	3
	4	GR	17	-	4
	5	SB	18	-	5
	6	0	19	-	6
	7	V	20	-	7
	8	B		-	
	9	W		-	
	10	V/W		-	
	11			-	

Connector No.	B512	Connector No.	B510
Connector Name	PRIMARY POSITION LIMIT SWITCH (LH)	Connector Name	WIRE TO WIRE
Connector Type	TK02FW	Connector Type	NS104FW-CS

Terminal No.	1	Color of Wire	16	Signal Name [Specification]	1
	2	GR	17	MOTOR SENS BAT	2
	3	GR/B	18	MOTOR SENS SIGNAL	3
	4	GR/R	19	MOTOR SENS GND	4
	5	LG	20	-	5
	6	LG		-	
	7			-	
	8			-	
	9			-	
	10			-	
	11			-	

Terminal No.	8	Color of Wire	9	Signal Name [Specification]	6
	10	R/W	11	-	7
	11	G	12	-	8
	12	GR	13	-	9
	13	GR/B	14	-	10
	14	GR/R	15	-	11
	15	LG	16	-	12
	16	LG	17	-	13
	17		18	-	14
	18		19	-	15
	19		20	-	16
	20			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	9	Color of Wire	10	Signal Name [Specification]	6
	11	R/W	12	-	7
	12	G	13	-	8
	13	GR	14	-	9
	14	GR/B	15	-	10
	15	GR/R	16	-	11
	16	LG	17	-	12
	17	LG	18	-	13
	18		19	-	14
	19		20	-	15
	20			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	2
	3	G	15	-	3
	4	GR	16	-	4
	5	SB	17	-	5
	6	0	18	-	6
	7	V	19	-	7
	8	B	20	-	8
	9	W		-	
	10	V/W		-	
	11			-	

Terminal No.	1	Color of Wire	13	Signal Name [Specification]	1
	2	R/W	14	-	

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

SE

K

M

N

O

P

REAR SEATBACK POWER RETURN SYSTEM		Signal Name [Specification]		Signal Name [Specification]	
Terminal No.	Color of Wire	Signal Name	Specification	Terminal No.	Color of Wire
1	R	-	-	64	B
2	W	-	-	65	G
3	B	-	-	66	R
4	GR	-	-	67	SHEILD
5	GR	-	-	68	LG
8	Y	-	-	69	LG
9	BR	-	-	70	W
10	O	-	-	71	R
11	SB	-	-	72	Y
12	O	-	-	73	Y
13	L	-	-	74	BR
14	R	-	-	74	L
15	P	-	-	75	G
16	Y	-	-	75	W
17	SB	-	-	76	W
18	Y	-	-	76	Y
20	O	-	-	77	R
21	L	-	-	77	P
22	Y	-	-	78	L
23	G	-	-	78	BR
24	P	-	-	79	Y
25	Y	-	-	79	L
26	V	-	-	80	SB
27	W	-	-	81	R
28	G	-	-	82	SB
31	O	-	-	83	O
32	W	-	-	84	G
33	B	-	-	85	L
34	R	-	-	86	P
35	G	-	-	87	V
36	SHEILD	-	-	89	GR
37	V	-	-	90	SHEILD
38	BR	-	-	91	W
39	O	-	-	92	Y
41	W	-	-	93	V
42	G	-	-	94	LG
43	BR	-	-	95	O
45	W	-	-	96	P
		-	-	97	R

JCJWA1135GB

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

REAR SEATBACK POWER RETURN SYSTEM

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-	64	B	-
2	R	-	65	W	-
3	B	-	66	R	-
4	SHEED	-	67	SHEED	-
5	G	-	68	GR	-
8	Y	-	69	GR	-
9	BR	-	70	LG	-
10	R	-	71	LG	-
11	BR	-	72	Y	-
12	O	-	73	SB	-
13	L	-	74	BR	-
14	R	-	74	BR	-
15	P	-	75	G	-
16	V	-	76	W	-
17	SB	-	76	GR	-
18	V	-	77	R	-
20	O	-	77	P	-
21	L	-	78	L	-
22	W	-	78	R	-
23	P	-	79	Y	-
24	BR	-	79	W	-
25	Y	-	80	SB	-
26	V	-	81	SB	-
27	G	-	82	SB	-
28	G	-	83	V	-
31	L	-	84	G	-
32	G	-	85	L	-
33	B	-	86	P	-
34	W	-	87	W	-
35	R	-	89	GR	-
36	SHEED	-	90	SHEED	-
37	V	-	91	W	-
38	O	-	92	Y	-
39	BR	-	93	BR	-
41	W	-	94	P	-
42	O	-	95	GR	-
43	O	-	96	W	-
45	W	-	97	L	-
			98	SHEED	-

JCJWA1136GB

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

REAR SEATBACK POWER RETURN SYSTEM		
Connector No.	Signal Name [Specification]	Terminal No.
M117	WIRE TO WIRE	82 V
Connector Name	WIRE TO WIRE	83 P
Connector Type	TH8BMW-CS16-TM4	84 R
		85 L
		86 O
		87 L
		88 P
		91 V
		92 G
		94 G
		95 W
		96 G
		97 Y
		98 BR
		99 V
		100 P
		101 SB
		102 L
		103 G
		104 CR
		105 SB
		106 W
		107 Y
		108 SB
		109 BR
		110 V
		111 P
		112 L
		113 G
		114 CR
		115 SB
		116 V
		117 BR
		118 V
		119 P
		120 L
		121 G
		122 CR
		123 SB
		124 L
		125 G
		126 CR
		127 SB
		128 V
		129 P
		130 L
		131 G
		132 CR
		133 SB
		134 V
		135 P
		136 L
		137 G
		138 CR
		139 SB
		140 V
		141 P
		142 L
		143 G
		144 CR
		145 SB
		146 V
		147 P
		148 L
		149 G
		150 CR
		151 SB
		152 V
		153 P
		154 L
		155 G
		156 CR
		157 SB
		158 V
		159 P
		160 L
		161 G
		162 CR
		163 SB
		164 V
		165 P
		166 L
		167 G
		168 SB
		169 V
		170 P
		171 SB
		172 V
		173 P
		174 L
		175 G
		176 CR
		177 SB
		178 V
		179 P
		180 L
		181 SB

REAR SEATBACK POWER RETURN SYSTEM		
Connector No.	Signal Name [Specification]	Terminal No.
M175	POWER RETURN SWITCH (RH)	157 V
Connector Name	POWER RETURN SWITCH (RH)	158 P
Connector Type	TK04W-B	159 L
		160 G
		161 CR
		162 SB
		163 V
		164 P
		165 L
		166 G
		167 CR
		168 SB
		169 V
		170 P
		171 SB
		172 V
		173 P
		174 L
		175 G
		176 CR
		177 SB
		178 V
		179 P
		180 L
		181 SB

REAR SEATBACK POWER RETURN SYSTEM		
Connector No.	Signal Name [Specification]	Terminal No.
M170	WIRE TO WIRE	121 V
Connector Name	WIRE TO WIRE	122 P
Connector Type	TH24FW-NH	123 L
		124 G
		125 CR
		126 SB
		127 V
		128 P
		129 L
		130 G
		131 CR
		132 SB
		133 V
		134 P
		135 L
		136 G
		137 CR
		138 SB
		139 V
		140 P
		141 L
		142 G
		143 CR
		144 SB
		145 V
		146 P
		147 L
		148 G
		149 CR
		150 SB
		151 V
		152 P
		153 L
		154 G
		155 CR
		156 SB
		157 V
		158 P
		159 L
		160 G
		161 CR
		162 SB
		163 V
		164 P
		165 L
		166 G
		167 CR
		168 SB
		169 V
		170 P
		171 SB
		172 V
		173 P
		174 L
		175 G
		176 CR
		177 SB
		178 V
		179 P
		180 L
		181 SB

REAR SEATBACK POWER RETURN SYSTEM		
Connector No.	Signal Name [Specification]	Terminal No.
M174	POWER-RETURN SWITCH (LH)	121 V
Connector Name	POWER-RETURN SWITCH (LH)	122 P
Connector Type	TK04WY	123 L
		124 G
		125 CR
		126 SB
		127 V
		128 P
		129 L
		130 G
		131 CR
		132 SB
		133 V
		134 P
		135 L
		136 G
		137 CR
		138 SB
		139 V
		140 P
		141 L
		142 G
		143 CR
		144 SB
		145 V
		146 P
		147 L
		148 G
		149 CR
		150 SB
		151 V
		152 P
		153 L
		154 G
		155 CR
		156 SB
		157 V
		158 P
		159 L
		160 G
		161 CR
		162 SB
		163 V
		164 P
		165 L
		166 G
		167 CR
		168 SB
		169 V
		170 P
		171 SB
		172 V
		173 P
		174 L
		175 G
		176 CR
		177 SB
		178 V
		179 P
		180 L
		181 SB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
SE
K
L
M
N
O
P

JCJWA1137GB

INFOID:0000000005172785

Fail-safe

Even if the automatic return control is inactivated, the fold-down and manual return operations can be performed

REAR SEAT BACK POWER RETURN CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Possible location of malfunction	Diagnosis mode	Corrective action
Return complete limit switch "ON" malfunction	The return completion position cannot be detected	Detect the lock with the rear seatback power return control unit, and then reverse the power return motor
Return complete limit switch "OFF" malfunction	The automatic return cannot be performed because the return completion position is misrecognized	The manual return operation can be performed
Primary position limit switch "ON" malfunction	The initial position of the sector gear cannot be detected	Detect the lock with the rear seatback power return control unit, and then stop the power return motor * If the above condition is repeated for 4 times, stop the subsequent automatic return operation. However, the manual return operation can be performed
Primary position limit switch "OFF" malfunction	The initial position of the sector gear is misrecognized (The sector gear reverse operation cannot be performed)	<ul style="list-style-type: none"> • Return the sector gear to the initial position if the primary position limit switch is not turned to ON after starting the return (Lock detection) • The manual return operation can be performed
Sensor malfunction (fixed to High or Low)	The motor lock is misrecognized because the pulse does not change	<ul style="list-style-type: none"> • If the pulse does not change completely after starting the motor operation, return the sector gear to the initial position • The manual return operation can be performed

HEATED SEAT CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

HEATED SEAT CONTROL UNIT

Reference Value

INFOID:0000000005532052

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Voltage (V) (Approx.)
(+)	(-)	Signal name	Input/ Output			
59 (Y)	Ground	Ground	–	–		0
60 (Y/R)	Ground	IGN power supply	Input	Ignition switch	OFF or ACC	0
					ON	Battery voltage
66 (B)	Ground	Heated seat operation signal	Input	Heated seat	Operate	Battery voltage
					Other than the above	0
67 (L)	Ground	Heated seat switch signal	Input	Heated seat switch	OFF	0
					1 (Min. temperature)	12.24
					2	12.33
					3	12.49
					4	12.63
					5	12.76
					6 (Max. temperature)	12.90
68 (R/W)	Ground	Seat cushion heater power supply	Output	Heated seat	Operate	0 – Battery voltage*
					Other than the above	0
69 (R)	Ground	Heat sensor signal	Input	Heated seat switch	OFF	0
					1 (Min. temperature)	10.87 – 11.02*
					2	10.93 – 11.07*
					3	11.04 – 11.17*
					4	11.13 – 11.26*
					5	11.22 – 11.34*
					6 (Max. temperature)	11.31 – 11.43*

*: Voltage is repeated within the value shown as per the following list depending on heater unit temperature.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O


P

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - HEATED SEAT SYSTEM -

INFOID:0000000005568541



*: This connector is not shown in "Harness Layout".

2009/07/16

JCJWA1124GB



HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I

SE
K
L
M
Z
O
P

◇PM : With automatic drive positioner
◇OP : Without automatic drive positioner



* : This connector is not shown in "Harness Layout".

JCJWA1125GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT					
Connector No.	Bl	Bl	Bl		
Connector Name	WIRE TO WIRE	WIRE TO WIRE	WIRE TO WIRE		
Connector Type	TH80FW-CS16-TM4	TH80FW-CS16-TM4	TH80FW-CS16-TM4		
					
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.		
3	R	-	78	P	
5	G	-	79	GR	
6	SB	-	83	O	
7	V	-	85	Y	
8	B	-	86	LG	
12	L	-	87	Y	
13	P	-	88	R	
14	GR	-	89	B	
15	LG	-	90	O	
17	W	-	91	G	
18	L	-	92	BR	
19	P	-	93	G	
20	BR	-	94	SB	
21	SHIELD	-	95	G	
22	Y	-	96	Y	
24	P	-	98	W	
28	R	-	99	GR	
30	SHIELD	-			
31	SHIELD	-			
32	W	-			
33	SB	-			
34	L	-			
35	P	-			
36	L	-			
37	P	-			
38	BR	-			
39	Y	-			
44	Y	-			
45	GR	-			
46	G	-			
47	B	-			
49	G	-			
50	V	-			
60	P	-			
61	L	-			
62	SHIELD	-			
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.		
59	66	1	59	66	1
60	67	2	60	67	2
Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.		
1	R	-	1	W	
2	B	-	2	R	
3	GR	-	3	GR	
4	O	-	4	LG	
7	LG	-	7	LG	
10	W	-	10	W	
15	SB	-	15	SB	
16	V	-	16	V	
67	Y	-	17	BR	

JCJWA1126GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



HEATED SEAT			
Connector No.	B403	Connector No.	B410
Connector Name	WIRE TO WIRE	Connector Name	SEAT CUSHION HEATER
Connector Type	MD61W-LC	Connector Type	SD4-TW
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	SB	59	Y
2	B	60	Y/R
59	B	61	Y
60	G	62	Y/R
66	O	63	B
67	GR	64	B
		65	Y
		66	Y/R
		67	L
Signal Name [Specification]			
1	R	59	-
2	B	60	-
59	-	61	-
60	-	62	-
66	-	63	-
67	-	64	-
		65	-
		66	-
		67	-
Signal Name [Specification]			
1	R	59	-
2	B	60	-
59	-	61	-
60	-	62	-
66	-	63	-
67	-	64	-
		65	-
		66	-
		67	-
HEATED SEAT CONTROL UNIT (DRIVER SIDE)			
Connector No.	B410	Connector No.	B411
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	NSQ5MW	Connector Type	MD2FW-LC
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	SB	59	Y
2	B	60	Y/R
59	Y	61	Y
60	Y/R	62	Y/R
66	B	63	B
67	L	64	B
		65	Y
		66	Y/R
		67	L
Signal Name [Specification]			
1	R	59	-
2	B	60	-
59	-	61	-
60	-	62	-
66	-	63	-
67	-	64	-
		65	-
		66	-
		67	-
Signal Name [Specification]			
1	R	59	-
2	B	60	-
59	-	61	-
60	-	62	-
66	-	63	-
67	-	64	-
		65	-
		66	-
		67	-
HEATED SEAT CONTROL UNIT (PASSENGER SIDE)			
Connector No.	B411	Connector No.	B412
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	MD2FW-LC	Connector Type	MD2FW-LC
			
Terminal No.	Color of Wire	Terminal No.	Color of Wire
1	SB	59	Y
2	B	60	Y/R
59	Y	61	IGN power supply
60	Y/R	62	Heated seat operation signal
66	B	63	Heated seat switch signal
67	L	64	Heated unit power supply
		65	Heated unit power supply
		66	Heat sensor signal
		67	Heat sensor signal
Signal Name [Specification]			
1	R	59	-
2	B	60	-
59	-	61	-
60	-	62	-
66	-	63	-
67	-	64	-
		65	-
		66	-
		67	-
Signal Name [Specification]			
1	R	59	-
2	B	60	-
59	-	61	-
60	-	62	-
66	-	63	-
67	-	64	-
		65	-
		66	-
		67	-

JCJWA1127GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT		
Connector No.	B462	
Connector Name	HEATED SEAT CONTROL UNIT (PASSENGER SIDE)	
Connector Type	174923-1	
		
Terminal No.	Color of Wire	Signal Name [Specification]
59	Y	Ground
60	Y.R	IGN power supply
66	B	Heated seat operation signal
67	L	Heated seat switch signal
68	R/W	Heater unit power supply
69	R	Heater sensor signal
Connector No.	B463	
Connector Name	SEAT CUSHION HEATER	
Connector Type	S044W	
		
Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-
Connector No.	E106	
Connector Name	WIRE TO WIRE	
Connector Type	HD07W-CSE-F-M2	
		
Terminal No.	Color of Wire	Signal Name [Specification]
59	Y	-
66	B	-
68	R/W	-
69	R	-
Connector No.	B464	
Connector Name	WIRE TO WIRE	
Connector Type	M02FY-LC	
		
Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	GR	-
5	GR	-
8	Y	-
9	BR	-
10	O	-
11	SB	-
12	O	-
13	L	-
14	R	-
15	P	-
16	Y	-
17	SB	-
18	Y	-
20	O	-
21	L	-
22	Y	-
23	G	-
24	P	-
25	Y	-
26	V	-
27	W	-
28	G	-
31	O	-
33	B	-
34	R	-
35	G	-
36	SHIELD	-
37	V	-
38	BR	-
39	O	-
41	W	-
42	G	-
43	BR	-
45	W	-
49	L	-
50	P	-
51	L	-
52	L	-
53	P	-
54	O	-
56	BR	-
57	BR	-
59	W	-
60	LG	-
61	G	-
62	SB	-
63	W	-
64	B	-
65	G	-
66	R	-

JCJWA1128GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P


HEATED SEAT

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS05FWY-042



Terminal No.	Color of Wire	Signal Name [Specification]
1A	GR	-
2A	G	-
3A	L	-
4A	P	-
5A	V	-
6A	Y	-
7A	R	-
8A	L	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	THGMMH-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	B	-
4	SHIELD	-
5	G	-
6	Y	-
7	R	-
8	BR	-
9	R	-
10	R	-
11	BR	-
12	O	-
13	L	-
14	R	-
15	P	-
16	V	-

JCJWA1129GB

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

HEATED SEAT

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Signal Name [Specification]
3	SB - (With automatic drive positioner)
3	W - [Without automatic drive positioner]
5	G
6	O
7	W
8	B
12	G
13	B
14	Y
15	G
17	W
18	L
19	P
20	BR
21	SHIELD
22	Y
24	V
27	B
28	W
29	R
30	SHIELD
31	L
32	P
33	SB
34	L
35	P
36	L
37	P
38	BR
39	Y
44	L
45	GR
46	B
47	G
49	V
50	R
60	P
61	L

Terminal No.	Signal Name [Specification]
7	SB - (With automatic drive positioner)
7	W - [Without automatic drive positioner]
9	G
10	O
11	W
12	R
13	Y
14	G
15	W
16	L
17	P
18	BR
19	Y
20	Y
21	R
22	Y
23	W
24	W
25	R
26	W
27	Y
28	Y
29	Y
30	Y
31	Y
32	Y
33	Y
34	Y
35	Y
36	Y
37	Y
38	Y
39	Y
40	Y
41	Y
42	Y
43	Y
44	Y
45	Y
46	Y
47	Y
48	Y
49	Y
50	Y
51	Y
52	Y
53	Y
54	Y
55	Y
56	Y
57	Y
58	Y
59	Y
60	Y
61	Y
62	Y
63	Y
64	Y
65	Y
66	Y
67	Y
68	Y
69	Y
70	Y
71	Y
72	Y
73	Y
74	Y
75	Y
76	Y
77	Y
78	Y
79	Y
80	Y
81	Y

Terminal No.	Signal Name [Specification]
1	SB - (With BOSE audio)
2	BR - [Without BOSE audio]
3	SB - (With BOSE audio)
4	BR - [Without BOSE audio]



Terminal No.	Signal Name [Specification]
1	SB - (With BOSE audio)
2	BR - [Without BOSE audio]
3	SB - (With BOSE audio)
4	BR - [Without BOSE audio]

Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	V
90	G
91	G
92	G
93	G
94	G
95	W
96	G
97	Y
98	BR
99	V
100	SB
101	L

Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	V
90	G
91	G
92	G
93	G
94	G
95	W
96	G
97	Y
98	BR
99	V
100	SB
101	L



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	R



Terminal No.	Signal Name [Specification]
82	V
83	P
84	R
85	L
86	O
87	L
88	P
89	BR
90	Y
91	G
92	Y
93	BR
94	Y
95	G
96	Y
97	Y
98	W
99	

HEATED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O


P

HEATED SEAT			
Connector No.	M71	Connector No.	M78
Connector Name	WIRE TO WIRE	Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)
Connector Type	NS05FBR-CS	Connector Type	TK08FBR



Terminal No.	Color of Wire	Signal Name [Specification]	
		Signal Name	[Specification]
1	SB	-	-
2	W	-	-
3	GR	-	-
4	GR	-	-
5	B	-	-
6	B	-	-
7	W	-	-
8	L	-	-

HEATED SEAT			
Connector No.	M77	Connector No.	M77
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE)	Connector Name	HEATED SEAT SWITCH (DRIVER SIDE)
Connector Type	TK08FWR	Connector Type	TK08FWR



Terminal No.	Color of Wire	Signal Name [Specification]	
		Signal Name	[Specification]
1	GR	-	-
2	L	-	-
3	R	-	-
4	W	-	-
5	W	-	-
6	B	-	-

JCJWA1131GB

REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE
BOTH SIDES

BOTH SIDES : Diagnosis Procedure

INFOID:00000000512786

1. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit.

Refer to [SE-16, "REAR SEATBACK POWER RETURN CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK VEHICLE SPEED SIGNAL CIRCUIT

Check vehicle speed signal circuit.

Refer to [SE-45, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident"](#).

NO >> GO TO 1.

LH

LH : Diagnosis Procedure

INFOID:00000000512787

1. PERFORM POWER RETURN SWITCH AND REAR SEATBACK SWITCH

Perform power return switch and rear seatback switch.

From which power return switch (or rear seatback switch) does the seat return operation occur?

POWER RETURN SWITCH>>GO TO 2.

REAR SEATBACK SWITCH>>GO TO 3.

BOTH SIDES>>GO TO 4.

2. CHECK POWER RETURN SWITCH (LH)

Check power return switch (LH).

Refer to [SE-21, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

3. CHECK REAR SEATBACK SWITCH (LH)

Check rear seatback switch (LH).

Refer to [SE-25, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK POWER RETURN MOTOR (LH)

Check power return motor (LH).

Refer to [SE-42, "LH : Component Function Check"](#).

Is the inspection result normal?

REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK RETURN COMPLETE LIMIT SWITCH (LH)

Check return complete limit switch (LH).

Refer to [SE-33, "LH : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> GO TO 1.

RH

RH : Diagnosis Procedure

INFOID:000000005172788

1. PERFORM POWER RETURN SWITCH AND REAR SEATBACK SWITCH

Perform power return switch and rear seatback switch.

From which power return switch (or rear seatback switch) does the seat return operation occur?

POWER RETURN SWITCH>>GO TO 2.

REAR SEATBACK SWITCH>>GO TO 3.

BOTH SIDES>>GO TO 4.

2. CHECK POWER RETURN SWITCH (RH)

Check power return switch (RH).

Refer to [SE-22, "RH : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

3. CHECK REAR SEATBACK SWITCH (RH)

Check rear seatback switch (RH).

Refer to [SE-26, "RH : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK POWER RETURN MOTOR (RH)

Check power return motor (RH).

Refer to [SE-43, "RH : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK RETURN COMPLETE LIMIT SWITCH (RH)

Check return complete limit switch (RH).

Refer to [SE-34, "RH : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

REAR SEATBACK POWER RETURN SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident"](#).

NO >> GO TO 1.

MALFUNCTION DETECTION BUZZER SOUNDS DURING POWER RETURN MOTOR INVERSE ROTATION

< SYMPTOM DIAGNOSIS >

MALFUNCTION DETECTION BUZZER SOUNDS DURING POWER RETURN MOTOR INVERSE ROTATION

LH

LH : Diagnosis Procedure

INFOID:000000005172789

1. CHECK RETURN COMPLETE LIMIT SWITCH (LH)

Check return complete limit switch (LH).

Refer to [SE-33, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK PRIMARY POSITION LIMIT SWITCH (LH)

Check primary position limit switch (LH).

Refer to [SE-29, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK POWER RETURN MOTOR (LH)

Check power return motor (LH).

Refer to [SE-42, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident"](#).

NO >> GO TO 1.

RH

RH : Diagnosis Procedure

INFOID:000000005172790

1. CHECK RETURN COMPLETE LIMIT SWITCH (RH)

Check return complete limit switch (RH).

Refer to [SE-34, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK PRIMARY POSITION LIMIT SWITCH (RH)

Check primary position limit switch (RH).

Refer to [SE-30, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK POWER RETURN MOTOR (RH)

Check power return motor (RH).

Refer to [SE-43, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

MALFUNCTION DETECTION BUZZER SOUNDS DURING POWER RETURN MOTOR INVERSE ROTATION

< SYMPTOM DIAGNOSIS >

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37. "Intermittent Incident"](#).

NO >> GO TO 1.

DOES NOT RETURN BUT MALFUNCTION DETECTION BUZZER SOUNDS

< SYMPTOM DIAGNOSIS >

DOES NOT RETURN BUT MALFUNCTION DETECTION BUZZER SOUNDS

LH

LH : Diagnosis Procedure

INFOID:000000005172791

1. CHECK PRIMARY POSITION LIMIT SWITCH (LH)

Check primary position limit switch (LH).

Refer to [SE-29, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MOTOR SENSOR (LH)

Check motor sensor (LH).

Refer to [SE-37, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident"](#).

NO >> GO TO 1.

RH

RH : Diagnosis Procedure

INFOID:000000005172792

1. CHECK PRIMARY POSITION LIMIT SWITCH (RH)

Check primary position limit switch (RH).

Refer to [SE-29, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MOTOR SENSOR (RH)

Check motor sensor (RH).

Refer to [SE-39, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident"](#).

NO >> GO TO 1.

ANTI-PINCH FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

ANTI-PINCH FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000005172793

1. CHECK MOTOR SENSOR (LH)

Check motor sensor (LH).

Refer to [SE-37, "LH : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MOTOR SENSOR (RH)

Check motor sensor (RH).

Refer to [SE-39, "RH : Component Function Check".](#)

Is the inspection result normal?

YES >> Replace rear seatback power return control unit. Refer to [SE-147, "Removal and Installation".](#)

NO >> Repair or replace the malfunctioning parts.

HEATED SEAT DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

HEATED SEAT DOES NOT OPERATE BOTH SIDES

BOTH SIDES : Diagnosis Procedure

INFOID:000000005532055

1. CHECK HEATED SEAT SWITCH POWER SUPPLY

Check heated seat switch power supply.

Refer to [SE-18, "HEATED SEAT SWITCH : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK HEATED SEAT RELAY

Check heated seat relay.

Refer to [SE-51, "Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check heated seat switch power supply and ground circuit.

Refer to [SE-16, "HEATED SEAT CONTROL UNIT : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> GO TO 1.

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005532056

1. CHECK HEATED SEAT SWITCH POWER SUPPLY

Check heated seat switch power supply.

Refer to [SE-18, "HEATED SEAT SWITCH : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check heated seat switch power supply and ground circuit.

Refer to [SE-16, "HEATED SEAT CONTROL UNIT : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-47, "DRIVER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

HEATED SEAT DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

4. CHECK SEAT CUSHION HEATER

Check seat cushion heater.

Refer to [SE-58, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000005532057

1. CHECK HEATED SEAT SWITCH POWER SUPPLY

Check heated seat switch power supply.

Refer to [SE-18, "HEATED SEAT SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK HEATED SEAT CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check heated seat switch power supply and ground circuit.

Refer to [SE-16, "HEATED SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-48, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK SEAT CUSHION HEATER

Check seat cushion heater.

Refer to [SE-59, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident"](#).

NO >> GO TO 1.

SEATBACK HEATER ONLY DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SEATBACK HEATER ONLY DOES NOT OPERATE DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005532058

1. CHECK SEATBACK HEATER

Check seatback heater.

Refer to [SE-62, "DRIVER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005532059

1. CHECK SEATBACK HEATER

Check seatback heater.

Refer to [SE-62, "PASSENGER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

CANNOT ADJUST HEATED SEAT TEMPERATURE

< SYMPTOM DIAGNOSIS >

CANNOT ADJUST HEATED SEAT TEMPERATURE DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005532060

1. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-47, "DRIVER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK HEAT SENSOR

Check heat sensor.

Refer to [SE-53, "DRIVER SIDE : Description".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> Replace heated seat control unit. Refer to [SE-148, "Removal and Installation".](#)

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005532061

1. CHECK HEATED SEAT SWITCH

Check heated seat switch.

Refer to [SE-48, "PASSENGER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK HEAT SENSOR

Check heat sensor.

Refer to [SE-55, "PASSENGER SIDE : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> Replace heated seat control unit. Refer to [SE-148, "Removal and Installation".](#)

HEATED SEAT SWITCH INDICATOR DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

HEATED SEAT SWITCH INDICATOR DOES NOT TURN ON DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005532062

1. CHECK HEATED SEAT SWITCH INDICATOR

Check heated seat switch indicator.

Refer to [SE-64, "DRIVER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005532063

1. CHECK HEATED SEAT SWITCH INDICATOR

Check heated seat switch indicator.

Refer to [SE-65, "PASSENGER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-37, "Intermittent Incident".](#)

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P


SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000005172794



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [SE-124, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
- 2) Tap or push/pull around the area where the noise appears to be coming from.
- 3) Rev the engine.
- 4) Use a floor jack to recreate vehicle "twist".
- 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
- 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.

- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
- If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - Placing a piece of paper between components that you suspect are causing the noise.
 - Looking for loose components and contact marks.
Refer to [SE-122, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - Separate components by repositioning or loosening and retightening the component, if possible.
 - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000005172795

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted under hood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:000000005172796







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

<input type="checkbox"/> anytime	<input type="checkbox"/> after sitting out in the rain
<input type="checkbox"/> 1st time in the morning	<input type="checkbox"/> when it is raining or wet
<input type="checkbox"/> only when it is cold outside	<input type="checkbox"/> dry or dusty conditions
<input type="checkbox"/> only when it is hot outside	<input type="checkbox"/> other:

A

B

C

D

E

III. WHEN DRIVING:

<input type="checkbox"/> through driveways	<input type="checkbox"/> squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> over rough roads	<input type="checkbox"/> creak (like walking on an old wooden floor)
<input type="checkbox"/> over speed bumps	<input type="checkbox"/> rattle (like shaking a baby rattle)
<input type="checkbox"/> only about _____ mph	<input type="checkbox"/> knock (like a knock at the door)
<input type="checkbox"/> on acceleration	<input type="checkbox"/> tick (like a clock second hand)
<input type="checkbox"/> coming to a stop	<input type="checkbox"/> thump (heavy, muffled knock noise)
<input type="checkbox"/> on turns: left, right or either (circle)	<input type="checkbox"/> buzz (like a bumble bee)
<input type="checkbox"/> with passengers or cargo	
<input type="checkbox"/> other: _____	
<input type="checkbox"/> after driving _____ miles or _____ minutes	

IV. WHAT TYPE OF NOISE

<input type="checkbox"/> squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> creak (like walking on an old wooden floor)
<input type="checkbox"/> rattle (like shaking a baby rattle)
<input type="checkbox"/> knock (like a knock at the door)
<input type="checkbox"/> tick (like a clock second hand)
<input type="checkbox"/> thump (heavy, muffled knock noise)
<input type="checkbox"/> buzz (like a bumble bee)

F

G

H

I

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

SE

YES	NO	Initials of person performing
-----	----	-------------------------------

L

Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

M

N

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

O

This form must be attached to Work Order

PIIB8742E

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005172797

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000005172798

NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.
(At this time, the steering lock will be released.)

3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.

4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

A

Service Notice

INFOID:000000005172799

B

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

C

Precaution for Work

INFOID:000000005172800

D

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
 - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
 - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

E

F

G

H

I

SE

K

L

M

N

O

P

PREPARATION

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool



INFOID:000000005172801

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J39570) Chassis ear	 SIIA0993E
(J43980) NISSAN Squeak and Rattle Kit	 SIIA0994E

Commercial Service Tool

INFOID:000000005172802

Tool name	Description
Engine ear	 SIIA0995E
Remover tool	 JMKIA3050ZZ

FRONT SEAT

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

FRONT SEAT

Exploded View

INFOID:0000000005172803

DRIVER'S SEAT



1. Headrest	2. Headrest holder (locked)	3. Headrest holder (free)
4. Seatback trim	5. Seatback pad	6. Seat cushion trim
7. Seat cushion pad	8. Seat cushion inner finisher outside	9. Seat cushion inner finisher inside (front)

FRONT SEAT

< REMOVAL AND INSTALLATION >

10. Seat cushion inner finisher inside (rear)	11. Seat cushion inner lower finisher	12. Seat belt buckle
13. Seat cushion front finisher	14. Front outer slide cover	15. Front inner slide cover
16. Seat harness	17. Driver seat control unit	18. Seat slide & lifter switch knob
19. Seat reclining switch knob	20. Seat cushion outer finisher outside	21. Seat cushion outer lower finisher (outside)
22. Seat cushion outer lower finisher (inside)	23. Seat cushion outer finisher inside (rear)	24. Seat cushion outer finisher inside (front)
25. Seat control switch	26. Lumbar support switch	27. Seat control harness
28. Rear outer slide cover	29. Rear inner slide cover	30. Seat cushion frame
31. Side air bag module	32. Seatback frame	33. Seatback board
34. Seatback board clip	35. Seatback silencer	

Refer to [GI-4, "Components"](#) for symbols in the figure.


PASSENGER'S SEAT

CAUTION:

Never disassembly the component parts of only front passenger seat in the dotted lines shown in the figure below. (With occupant classification system control unit model)

FRONT SEAT

< REMOVAL AND INSTALLATION >



1. Headrest	2. Headrest holder (locked)	3. Headrest holder (free)
4. Seatback trim	5. Seatback pad	6. Seatback silencer
7. Seatback frame	8. Seatback board	9. Seatback board clip
10. Side air bag module	11. Seat slide & lifter switch knob	12. Seat reclining switch knob
13. Seat cushion outer finisher outside	14. Seat cushion outer finisher inside (front)	15. Seat cushion outer finisher inside (rear)
16. Seat control switch	17. Seat control harness	18. Seat cushion outer lower finisher (outside)
19. Seat cushion outer lower finisher (inside)	20. Rear outer slide cover	21. Rear inner slide cover
22. Seat harness	23. Front outer slide cover	24. Front inner slide cover

A
B
C
D
E
F
G
H
I
SE
K
L
M
N

O
P

FRONT SEAT

< REMOVAL AND INSTALLATION >

25. Seat cushion front finisher	26. Seat cushion frame	27. Seat belt buckle
28. Seat cushion inner finisher outside	29. Seat cushion inner finisher inside (front)	30. Seat cushion inner finisher inside (rear)
31. Seat cushion inner finisher lower	32. Seat cushion trim	33. Seat cushion pad
34. Seat cushion assembly		

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000005172804


REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.


1. Remove the headrest.
2. Remove the front slide cover.
 - a. Front outer slide cover
 - Slide the seat to the rear-most position.
 - Pull up the front edge of the front slide cover to release the pawls.
 - Slide the front slide cover forward to release the pawls.

 : Pawl



- b. Front inner slide cover
 - Slide the seat to the rear-most position.
 - Pull up the front edge of the front slide cover to release the pawls.
 - Slide the front slide cover forward to release the pawls.

 : Pawl




3. Remove the mounting bolts on the front side of the front seat.

4. Remove the rear slide cover.

- a. Rear outer slide cover
 - Slide the seat to the front-most position.
 - Pull up the rear edge of the rear outer slide cover to release the pawls.
 - Open the front end of the rear outer slide cover to release the pawls.

 : Pawl




FRONT SEAT

< REMOVAL AND INSTALLATION >

b. Rear inner slide cover

- Slide the seat to the front-most position.
- Pull up the rear edge of the rear inner slide cover to release the pawls.
- Slide the rear inner slide cover rearward to release the pawls.

 : Pawl



5. Remove the mounting bolts on the rear side of the front seat.

6. Set seatback in a standing position.

7. Disconnect harness connector under the seat and remove harness securing clips.

CAUTION:

Before removal, turn ignition switch OFF, disconnect battery negative terminal, and then wait for at least 3 minutes.

8. Remove seat from the vehicle.

CAUTION:

- When removing and installing, use shop cloths to protect parts from damage.
- When removing and installing, 2 workers are required so as to prevent it from dropping.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Before installation, turn ignition switch OFF, disconnect both battery cables, and then wait for at least 3 minutes.

- Clamp the harness in position.

NOTE:

After installing the front seat, perform additional service when removing battery negative terminal.(Automatic drive positioner model only) Refer to [ADP-8, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

SE

Disassembly and Assembly

INFOID:0000000005172805

SEATBACK


Disassembly

1. Remove the seatback board.

- Remove the clips and pawls, and then pull out seatback board.
- Pull down the seatback board to release the upper pawls.

 : Clip

 : Pawl




2. Remove the seatback trim retainer and seatback trim band from seat cushion frame.

3. Disconnect the harness connectors and remove the harness clamps.


FRONT SEAT

< REMOVAL AND INSTALLATION >


- Disconnect the reclining motor harness connector (A) and lumbar support harness connector (Driver's seat only) (B).



- Disconnect the seatback heater harness (C).




- Remove the harness clamps, and then side air bag module harness (D).



4. Remove the metal clips and pawls, and then pull out seat cushion front finisher.

[] : Metal clip

△ : Pawl



5. Remove the seat cushion outer finisher.

FRONT SEAT


< REMOVAL AND INSTALLATION >

- Remove the seat slide and lifter (With lifter seat), reclining switch knob.
- Remove the clips, metal clips and pawls, and then pull out seat cushion outer finisher outside.
- Disconnect the slide & lifter, reclining and lumbar support switch (Driver's seat only) harness connectors.

○ : Clip


[] : Metal clip

△ : Pawl



A
B
C
D
E
F
G
H
I

6. Remove the seat cushion outer finisher inside front (1) and rear (2).




J
K
L
M
N
O
P

7. Remove the metal clip and pawls, and then pull out seat cushion inner finisher outside.


[] : Metal clip

△ : Pawl



SE
K
L
M
N
O
P

8. Remove the seat cushion inner finisher inside front (1) and rear (2).



9. Remove the seatback trim and seatback pad.


FRONT SEAT

< REMOVAL AND INSTALLATION >

- Remove the headrest holder.

CAUTION:
Before installing headrest holder check its orientation. (front/rear and right/left)

- Remove the air bag module.
- Remove the seatback trim and seatback pad from the seatback frame.
- Remove the hog rings, and separate the seatback trim and seatback pad.




PIIB8351J

10. Remove the seatback silencer.

11. Remove the seatback frame.

Remove the seatback frame mounting bolts (A) and then remove the seatback frame.



JMJA1494ZZ

Assembly

Assemble in the reverse order of disassembly.

CAUTION:

Install the hog rings of seatback trim in position, and then securely connect the trim or trim cord with the pad side wire.

SEAT CUSHION

Disassembly

CAUTION:

Never disassemble front passenger seat cushion assembly.


Always replace as an assembly.

For front passenger seat service parts, refer to the service part catalogue.

1. Remove the seatback board.
 - Remove the clips and pawls, and then pull out seatback board.
 - Pull down the seatback board to release the upper pawls.

○ : Clip

△ : Pawl




JMJA1485ZZ

2. Remove the seatback trim retainer and seatback trim band from seat cushion frame.
3. Disconnect the harness connectors and remove the harness clamps.

FRONT SEAT

< REMOVAL AND INSTALLATION >

- Disconnect the reclining motor harness connector (A) and lumbar support harness connector (B) (Driver's seat only).



A

B

C

D

E

F

G

H

I

SE

K

L


M

N

O

P

- Disconnect the seatback heater harness connector (C).




E

F

G

H

- Remove the side air bag module harness (D).




SE

4. Remove the metal clips and pawls, and then pull out seat cushion front finisher.

[] : Metal clip

△ : Pawl



K

L

M

N

5. Remove the seat cushion outer finisher.

FRONT SEAT


< REMOVAL AND INSTALLATION >

- Remove the seat slide and lifter (With lifter seat), reclining switch knob.
- Remove the clip, metal clips and pawls, and then pull out seat cushion outer finisher outside.
- Disconnect the slide & lifter, reclining and lumbar support switch (Driver's seat only) harness connectors.


○ : Clip

[] : Metal clip

△ : Pawl




6. Remove the seat cushion outer finisher inside front (1) and rear (2).




7. Remove the metal clip and pawls, and then pull out seat cushion inner finisher outside.

[] : Metal clip

△ : Pawl




8. Remove the seat cushion inner finisher inside front (1) and rear (2).



9. Remove the seatback assembly.

Remove the seatback assembly mounting bolts (A).




FRONT SEAT

< REMOVAL AND INSTALLATION >


10. Remove the metal clips, and then pull out seat cushion outer lower finisher outside (1) and inside (2).

[] : Metal clip




11. Remove the seat cushion inner lower finisher.

[] : Metal clip



12. Remove the seat cushion trim and seat cushion pad. (Without occupant classification system control unit model)

- Disconnect the seat cushion heater unit harness connector (A).
- Remove the seat cushion trim retainer.
- Remove the hog rings, and separate the seat cushion trim and seat cushion pad.



13. Remove the seat belt buckle. [SB-8, "SEAT BELT BUCKLE : Exploded View"](#)

14. Remove the driver seat control unit. (Driver's power seat only) [ADP-216, "Exploded View"](#)

Assembly

Assemble in the reverse order of disassembly.

CAUTION:

Install the hog rings of seat cushion trim in position, and then securely connect the trim or trim cord with the pad side wire.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT

< REMOVAL AND INSTALLATION >


REAR SEAT

Exploded View

INFOID:0000000005172806

REAR SEAT

SEC. 880



JMJIA1584GB

REAR SEAT

< REMOVAL AND INSTALLATION >

1. Rear center seat belt	2. Center seat belt retractor cover	3. Seat belt guide (upper)	A
4. Seat belt guide (lower)	5. Rear seatback lock cover (RH)	6. Rear seatback lock knob (RH)	
7. Rear seatback lock knob finisher (RH)	8. Headrest holder (free)	9. Headrest holder (locked)	
10. Seat belt finisher	11. Rear seatback trim (RH)	12. Rear seatback pad (RH)	B
13. Rear seatback board (RH)	14. Rear seatback board clip (RH)	15. Armrest trim	
16. Armrest pad	17. Armrest frame	18. Cup holder	C
19. Armrest bracket cover (RH)	20. Armrest bracket (RH)	21. Armrest bracket (LH)	
22. Armrest bracket cover (LH)	23. Rear seatback lock assembly (RH)	24. Rear seatback frame (RH)	D
25. Rear seat belt hook (RH)	26. Rear seatback hinge outer cover (RH)	27. Rear seatback hinge (RH)	
28. Rear seatback hinge bracket (RH)	29. Rear seatback hinge bush (RH)	30. Reclining device outer cover (RH)	E
31. Reclining device assembly (RH)	32. Reclining device inner cover (RH)	33. Rear seat harness (RH)	
34. Rear seat cushion trim	35. Rear seat cushion pad	36. Rear seat cushion hook	
37. Reclining device outer cover (LH)	38. Reclining device assembly (LH)	39. Reclining device inner cover (LH)	F
40. Reclining device bush	41. Rear seat harness (LH)	42. Rear seatback hinge outer cover (LH)	
43. Rear seatback hinge (LH)	44. Rear seat belt hook (LH)	45. Rear seatback lock assembly (LH)	G
46. Rear seatback frame (LH)	47. Rear seatback hinge bracket (LH)	48. Rear seatback hinge bush (LH)	
49. Rear seatback lock cover (LH)	50. Rear seatback pad (LH)	51. Rear seatback trim (LH)	
52. Rear seatback lock knob (LH)	53. Rear seatback lock knob finisher (LH)	54. Headrest holder (locked)	
55. Headrest holder (free)	56. Rear seatback board (LH)	57. Rear seatback board clip (LH)	H

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:0000000005172807


SE

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion.
 - Pull the lock lever (1) at the front bottom of the seat cushion forward (1 for each side), and pull the seat cushion upward to release the wire (2) from the seat cushion hook. Then pull the seat cushion forward the remove
 - Remove the seat cushion from vehicle.




JMJA0251ZZ

2. Remove the seatback.
 - Remove the luggage floor finisher front LH and RH. Refer to [INT-34, "Exploded View"](#).
 - Disconnect the rear seat harness connectors.
 - With power return seat model
 - LH seatback

REAR SEAT


< REMOVAL AND INSTALLATION >

Disconnect the rear seat harness connectors (A).



RH seatback


Disconnect the rear seat harness connector (A).



- Without power return seat model


LH seatback

Disconnect the rear seat harness connectors (A).



RH seatback


Disconnect the rear seat harness connector (A).



REAR SEAT


< REMOVAL AND INSTALLATION >

- Push the seatback lock pin (A).
- Remove the seatback mounting nuts (B), (C) and bolt (D).
- Remove the center seat belt anchor bolt. (RH seatback only)
Refer to [SB-11, "SEAT BELT RETRACTOR : Exploded View"](#).
- Remove the seatback from vehicle.



INSTALLATION

1. Install the rear seatback mounting nuts (1), (2), (3).
2. Lock the seatback striker (4).
3. Install the rear seatback mounting bolt (5).
4. Pull the rear seatback lock pin (6).



CAUTION:

- When removing and installing, use shop cloths to protect parts from damage.
- When removing and installing, 2 workers are required so as to prevent it from dropping.

Disassembly and Assembly


INFOID:000000005172808

SEATBACK


Disassembly

1. Remove the clips, and then pull out seatback board.

○ : Clip




2. Remove the armrest.
 - Remove the armrest hinge covers (1).



REAR SEAT

< REMOVAL AND INSTALLATION >

- Remove the arm rest mounting bolts (A), nuts (B) and hog rings (C), and then remove the armrest.




3. Remove the seatback device assembly.

- Remove the seatback trim fixing hog rings.
- Disconnect the seatback lock harness connector.


LH seatback

Disconnect the seatback lock harness connector (A).




RH seatback

Disconnect the seatback lock harness connector (B).



- Remove the seatback device.


Remove the seatback device mounting bolts (C).



REAR SEAT

< REMOVAL AND INSTALLATION >

4. Remove the hinge bracket mounting bolt (A), and then remove the hinge bracket (1).




A
B
C
D

5. Remove the seatback trim and pad.


- Remove the metal clips and pawls, and then pull out seatback lock cover.

[] : Metal clip
△ : Pawl




E
F
G
H
I

- Remove the seatback hinge outer cover.



SE
K

- Remove the seatback hinge.
Remove the seatback hinge mounting bolt (A).




L
M
N
O
P

- Turn seatback lock knob counterclockwise to remove.

REAR SEAT

< REMOVAL AND INSTALLATION >


- Push the seatback lock knob finisher pawl upward through the seatback pad and the seatback frame to remove it.



- Remove the headrest holder.

CAUTION:


Before installing headrest holder check its orientation.
(front/rear and right/left)



- Remove the seatback trim and pad.
- Remove the hog rings to separate the seatback trim and seatback pad.

6. Remove the seatback lock assembly.

Remove the seatback lock assembly mounting bolts.



7. Remove the rear center seat belt. Refer to [SB-11, "SEAT BELT RETRACTOR : Exploded View"](#)

Assembly

Assemble in the reverse order of disassembly.

CAUTION:

Install the hog rings of seatback trim in position, and then securely connect the trim or trim cord with the seatback frame.

SEAT CUSHION

Disassembly

Remove the hog rings to separate the trim and pad.

Assembly

Assemble in the reverse order of disassembly.

CAUTION:

Install the hog rings of seat cushion trim in position, and then securely connect the trim or trim cord with the seat cushion pad wire.


REAR SEAT BACK POWER RETURN CONTROL UNIT

< REMOVAL AND INSTALLATION >

REAR SEAT BACK POWER RETURN CONTROL UNIT

Exploded View

INFOID:000000005172809



1. Rear seatback power return control unit

Removal and Installation


INFOID:000000005172810

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the luggage floor finisher assembly (front). Refer to [INT-35, "Removal and Installation"](#).
2. Remove mounting nuts (A).
3. Remove rear seatback power return control unit (1).



INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to clamp the harness to the right place.

A
B
C
D
E

F
G
H
I

SE
K

L
M
N
O
P

HEATED SEAT CONTROL UNIT

< REMOVAL AND INSTALLATION >

HEATED SEAT CONTROL UNIT

Exploded View

INFOID:0000000005532104

Refer to [SE-129, "Exploded View"](#).

Removal and Installation

INFOID:0000000005532105

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the front seat.
2. Disconnect heated seat control unit connector.
3. Remove the heated seat control unit from the heated seat control unit stay. Refer to [SE-129, "Exploded View"](#).

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Always clamp the harness to the right place.

POWER SEAT SWITCH

< REMOVAL AND INSTALLATION >

POWER SEAT SWITCH

Exploded View

INFOID:000000005172811

Refer to [SE-129, "Exploded View"](#).

Removal and Installation


INFOID:000000005172812

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion outer finisher (1). Refer to [SE-132, "Removal and Installation"](#).
2. Remove the screws (A).
3. Remove the power seat switch (2) from the seat cushion outer finisher.



INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to clamp the harness to the right place.

A

B

C

D

E

F

G

H

SE

K

L

M

N

O

P

LUMBAR SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

LUMBAR SUPPORT SWITCH

Exploded View

INFOID:000000005172813

Refer to [SE-129, "Exploded View"](#).

Removal and Installation

INFOID:000000005172814


REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat cushion outer finisher (1). Refer to [SE-132, "Removal and Installation"](#).
2. Remove the lumbar support switch (2) from the seat cushion outer finisher. With flat bladed screw driver (A).

△ : Pawl



INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to clamp the harness to the right place.

HEATED SEAT SWITCH

< REMOVAL AND INSTALLATION >

HEATED SEAT SWITCH

Exploded View

INFOID:000000005172815

Refer to [IP-22, "Exploded View"](#).

Removal and Installation

INFOID:000000005172816

REMOVAL

CAUTION:


When removing and installing, use shop cloths to protect from damage.

1. Remove the console body assembly. Refer to [IP-22, "Removal and Installation"](#)
2. Remove heated seat switch (1) from switch bracket with flat bladed screw driver (A).

 : Pawl

NOTE:

The same procedure is also performed for passenger side.



INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

SE

K

L

M

N

O

P

POWER RETURN SWITCH

< REMOVAL AND INSTALLATION >

POWER RETURN SWITCH

Exploded View

INFOID:000000005172817

Refer to [IP-22, "Exploded View"](#).

Removal and Installation

INFOID:000000005172818


REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the console body assembly. Refer to [IP-22, "Removal and Installation"](#)
2. Remove power return switch (1) from switch bracket. With flat bladed screw driver (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.


REAR SEATBACK SWITCH

< REMOVAL AND INSTALLATION >

REAR SEATBACK SWITCH

Exploded View

INFOID:000000005172819



1. Rear seatback switch
2. Luggage side finisher lower escutcheon

Removal and Installation

INFOID:000000005172820


REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the luggage side finisher lower escutcheon. Refer to [INT-35, "Removal and Installation"](#).
2. Remove rear power return switch (1) from luggage side finisher lower escutcheon. With flat bladed screw driver (A).

△ : Pawl



INSTALLATION

Install in the reverse order of removal.


REAR SEATBACK RELEASE SWITCH

< REMOVAL AND INSTALLATION >

REAR SEATBACK RELEASE SWITCH

Exploded View

INFOID:000000005172821



1. Rear seatback release switch
2. Luggage side finisher lower escutcheon

Removal and Installation

INFOID:000000005172822


REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove the luggage side finisher lower escutcheon. Refer to [INT-35, "Removal and Installation"](#).
2. Remove rear power return switch (1) from luggage side finisher lower escutcheon. With flat bladed screw driver (A).

△ : Pawl



INSTALLATION

Install in the reverse order of removal.