



Electrical Circuit: 46 01 19: Navigation system (LHD) All markets other than Japan

No	Description
C0098	Driver's information panel
C0685	Navigation monitor
C0686	GPS antenna
C0697	Navigation monitor up/down motor
C0704	Navigation monitor up/down switch
C0758	Navigation monitor control module
C1047	Navigation unit
C1049	Integration module
C1051	Remote eye
C1101	Fuse F1, 5 amp - luggage compartment fusebox
C1103	Fuse F3, 10 amp - luggage compartment fusebox
C1104	Fuse F4, 5 amp - luggage compartment fusebox
C1105	Fuse F5, 5 amp - luggage compartment fusebox
C1111	Luggage compartment fusebox
G0171	Ground point connector
G0172	Ground point connector
G0311	Ground point connector
G0314	Ground point connector
S1294	Splice - Brown/slate - rear main loom
S1301	Splice - Black - rear main loom
S1323	Splice - Red/yellow - rear main loom
S1325	Splice - Red/orange - rear main loom
S1348	Splice - Black - rear main loom
S1361	Splice - Red - rear main loom
S1452	Splice - Red/yellow - left-hand drive facia loom
S2349	Splice - Brown/slate - rear main loom
S2353	Splice - Black - rear main loom
S2373	Splice - Red/yellow - rear main loom
S2375	Splice - Red/orange - rear main loom
S2399	Splice - Black - rear main loom
S2412	Splice - Red - rear main loom
X3719	Navigation unit connector
X3720	Navigation monitor connector
X3753	Rear main loom to left-hand drive facia loom plug and socket 18-way
X3763	Front roof console connector 20-way
X3814	Navigation monitor control module connector 8-way
X3817	Navigation unit connector 8-way - grey
X3819	Rear main loom to left-hand drive facia loom plug and socket 14-way
X3831	Integration module connector 20-way
X3833	Navigation unit connector 8-way - brown
X3849	Luggage compartment fusebox connector 2-way
X3852	Luggage compartment fusebox connector 2-way
X3853	Luggage compartment fusebox connector 2-way
X3854	Luggage compartment fusebox connector 2-way
X4003	Driver's information panel connector 12-way
X4019	Remote eye plug and socket
X4020	Remote eye connector
X4024	Navigation monitor connector 3-way
X4288	Header connector 20-way
X4290	GPS antenna connector

X4291	GPS antenna connector - navigation unit
X5681	Front roof console connector 20-way
X5724	Navigation monitor control module connector 8-way
X5727	Navigation unit connector 8-way - grey
X5735	Integration module connector 20-way
X5737	Navigation unit connector 8-way - brown
X5770	Luggage compartment fusebox connector 2-way
X5773	Luggage compartment fusebox connector 2-way
X5774	Luggage compartment fusebox connector 2-way
X5775	Luggage compartment fusebox connector 2-way
X5785	Header connector 20-way
X5799	GPS antenna connector 2-way
X5800	GPS antenna connector - navigation unit - 2-way

Circuit Links

Description	Circuit	Additional Information
J	050104	12 V+ from the battery
C		12 V+ from the accessories relay
E		Reverse signal input
D		12 V+ when the side lamps are switched on
I		Panel lamps (PWM) input from the DIP