



Electrical Circuit: 45 01 13: Heated elements (LHD)

No	Description
C0001	Primary fusebox
C0002	Secondary fusebox
C0003	Luggage compartment fusebox
C0026	Heated windscreen washer jet 2
C0027	Heated windscreen washer jet 1
C0090	Ignition switch
C0116	Left-hand front wheel speed sensor
C0191	Heated rear windscreen relay
C0408	HVAC control module
C0444	Fuse F13, 10 amp - primary fusebox
C0462	Ignition relay - primary fusebox
C0487	Fuse F16, 10 amp - secondary fusebox
C0489	Fuse F18, 5 amp - secondary fusebox
C0495	Fuse F1, 30 amp - luggage compartment fusebox
C0500	Fuse F6, 10 amp - luggage compartment fusebox
C0532	Heated rear windscreen
C0548	Left-hand heated door mirror
C0549	Right-hand heated door mirror
C0979	Fuse FL7, 40 amp - primary fusebox
G0150	Ground point connector
G0164	Ground point header connector 6-way
G0169	Ground point connector
G0170	Ground point connector
G0181	Ground point header connector 6-way
G0301	Ground point connector
G0304	Ground point connector
G0307	Ground point connector
S1293	Splice - Black - rear main loom
S1334	Splice - Blue/slate - rear main loom
S1535	Splice - Black - right-hand door loom
S1579	Splice - Brown/pink - front main loom
S1861	Splice - Black - right-hand door loom
S2348	Splice - Black - rear main loom
S2388	Splice - Blue/slate - rear main loom
X2740	Front main loom to left-hand drive facia loom plug and socket 23-way
X3750	Hood control module connector 10-way
X3780	Secondary fusebox connector 9-way
X3789	Luggage compartment fusebox connector 21-way
X3790	Luggage compartment fusebox connector 4-way
X3791	Luggage compartment fusebox connector 2-way
X3792	Luggage compartment fusebox connector
X3793	Luggage compartment fusebox connector 13-way
X3797	Rear main loom to left-hand drive console loom plug and socket 18-way
X3863	Heated rear windscreen relay connector
X3868	Rear main loom to hood loom plug and socket 6-way
X3894	Rear main loom to right-hand door loom plug and socket 10-way
X3895	Rear main loom to right-hand door loom plug and socket 10-way
X3898	Rear main loom to left-hand door loom plug and socket 10-way
X3899	Rear main loom to left-hand door loom plug and socket 10-way
X3932	HVAC control module connector 26-way
X3987	Header connector 20-way

X4212	Left-hand door mirror plug and socket 8-way
X4227	Right-hand door mirror plug and socket 8-way
X4261	Rear windscreen heater connector
X4262	Hood lamp connector
X4285	Header connector 20-way
X4351	Heated windscreen washer jet connector 2-way
X4358	Heated windscreen washer jet connector 2-way
X4360	Header connector 20-way
X4362	Header connector 20-way
X4367	Primary fusebox connector 12-way
X4368	Secondary fusebox connector 4-way
X4369	Secondary fusebox connector 21-way
X4371	Primary fusebox connector 3-way
X4374	Primary fusebox connector 18-way
X4380	Primary fusebox connector 2-way
X4831	Switchbox connector 12-way
X5670	Hood control module connector 10-way
X5694	Secondary fusebox connector 9-way
X5703	Luggage compartment fusebox connector 4-way
X5704	Luggage compartment fusebox connector 2-way
X5705	Luggage compartment fusebox connector 1-way
X5706	Luggage compartment fusebox connector 13-way
X5707	Luggage compartment fusebox connector 13-way
X5782	Header connector 20-way
X5790	Heated rear windscreen relay connector 9-way

Circuit Links

Description	Circuit	Additional Information
F	050106	12 V+ from the battery
D	050106	12 V+ from the battery