



Electrical Circuit: 45 01 15: Heated elements (LHD)

No	Description
C0001	Primary fusebox
C0002	Secondary fusebox
C0003	Luggage compartment fusebox
C0026	Heated windscreen washer jet 2
C0027	Heated windscreen washer jet 1
C0090	Ignition switch
C0191	Heated rear windscreen relay
C0408	HVAC control module
C0444	Fuse F13, 10 amp - primary fusebox
C0462	Ignition relay - primary fusebox
C0487	Fuse F16, 10 amp - secondary fusebox
C0489	Fuse F18, 5 amp - secondary fusebox
C0500	Fuse F6, 10 amp - luggage compartment fusebox
C0532	Heated rear windscreen
C0548	Left-hand heated door mirror
C0549	Right-hand heated door mirror
C0979	Fuse FL7, 40 amp - primary fusebox
C1106	Fuse F6, 40 amp - luggage compartment fusebox
G0164	Ground point header connector 6-way
G0181	Ground point header connector 6-way
G0213	Ground point connector
G0217	Ground point connector
G0220	Ground point connector
G0263	Ground point connector
G0267	Ground point connector
G0270	Ground point connector
G0280	Ground point connector
S1535	Splice - Black - right-hand door loom
S1579	Splice - Brown/pink - front main loom
S1861	Splice - Black - right-hand door loom
S1929	Splice - Blue/slate - rear main loom
S1940	Splice - Black - rear main loom
S2201	Splice - Blue/slate - rear main loom
S2208	Splice - Black - rear main loom
X2740	Front main loom to left-hand drive facia loom plug and socket 23-way
X3797	Rear main loom to left-hand drive console loom plug and socket 18-way
X3894	Rear main loom to right-hand door loom plug and socket 10-way
X3895	Rear main loom to right-hand door loom plug and socket 10-way
X3898	Rear main loom to left-hand door loom plug and socket 10-way
X3899	Rear main loom to left-hand door loom plug and socket 10-way
X3932	HVAC control module connector 26-way
X3987	Header connector 20-way
X4212	Left-hand door mirror plug and socket 8-way
X4227	Right-hand door mirror plug and socket 8-way
X4351	Heated windscreen washer jet connector 2-way
X4358	Heated windscreen washer jet connector 2-way
X4360	Header connector 20-way
X4362	Header connector 20-way
X4367	Primary fusebox connector 12-way
X4368	Secondary fusebox connector 4-way
X4369	Secondary fusebox connector 21-way

X4371	Primary fusebox connector 3-way
X4374	Primary fusebox connector 18-way
X4380	Primary fusebox connector 2-way
X4831	Switchbox connector 12-way
X4893	Heated rear windscreen positive connector 1-way
X4904	Secondary fusebox connector 9-way
X4912	Heated rear windscreen negative connector 1-way
X4923	Luggage compartment fusebox connector 21-way
X4924	Luggage compartment fusebox connector 4-way
X4925	Luggage compartment fusebox connector 2-way
X4926	Luggage compartment fusebox connector 13-way
X4992	Luggage compartment fusebox connector 2-way
X4997	Header connector 20-way
X5005	Heated rear windscreen relay connector 9-way
X5373	Heated rear windscreen positive connector 1-way
X5383	Secondary fusebox connector 9-way
X5391	Heated rear windscreen negative connector 1-way
X5402	Luggage compartment fusebox connector 21-way
X5403	Luggage compartment fusebox connector 4-way
X5404	Luggage compartment fusebox connector 13-way
X5405	Luggage compartment fusebox connector 13-way
X5484	Luggage compartment fusebox connector 2-way
X5489	Header connector 20-way
X5499	Heated rear windscreen relay connector 9-way
X5526	Header connector 20-way
X5540	Switchbox connector 12-way

Circuit Links

Description	Circuit	Additional Information
K	050107	12 V+ from the battery
D	050107	12 V+ from the battery