



## Electrical Circuit: 12 01 15: Stop lamps (LHD)

| No    | Description  |
|-------|--|
| C0001 | Primary fusebox  |
| C0090 | Ignition switch  |
| C0098 | Driver's information panel   |
| C0118 | Stop lamps switch  |
| C0202 | High mounted stop lamp   |
| C0437 | Fuse F6, 10 amp - primary fusebox                                    |
| C0444 | Fuse F13, 10 amp - primary fusebox                                   |
| C0463 | Engine ignition relay - primary fusebox                              |
| C0467 | Stop lamps relay - primary fusebox                                   |
| C0530 | Left-hand stop lamp  |
| C0531 | Right-hand stop lamp   |
| G0164 | Ground point header connector 6-way                                  |
| G0184 | Ground point header connector 10-way                                 |
| G0210 | Ground point connector   |
| G0219 | Ground point connector   |
| G0260 | Ground point connector   |
| G0269 | Ground point connector   |
| G0280 | Ground point connector   |
| S1183 | Splice - Black - brake switch loom                                   |
| S1608 | Splice - Pink/slate - front main loom                                |
| S1870 | Splice - Brown/yellow - rear main loom                               |
| S1901 | Splice - Brown/orange - rear main loom                               |
| S1910 | Splice - Black - rear main loom                                      |
| S1948 | Splice - Black - rear main loom                                      |
| S1950 | Splice - Black - rear main loom                                      |
| S2145 | Splice - Black - rear main loom                                      |
| S2172 | Splice - Brown/orange - rear main loom                               |
| S2180 | Splice - Black - rear main loom                                      |
| S2216 | Splice - Black - rear main loom                                      |
| S2218 | Splice - Black - rear main loom                                      |
| X2748 | Front main loom to left-hand drive facia loom plug and socket 22-way |
| X2789 | Front main loom to brake switch link loom plug and socket 8-way      |
| X2825 | Front main loom to rear main loom plug and socket 22-way             |
| X3532 | Stop lamps switch connector 4-way                                    |
| X3772 | Rear main loom to left-hand drive facia loom plug and socket 20-way  |
| X3967 | Right-hand drive facia loom to console loom plug and socket 20-way   |
| X4008 | Driver's information panel connector 12-way                          |
| X4363 | Header connector 20-way  |
| X4367 | Primary fusebox connector 12-way                                     |
| X4374 | Primary fusebox connector 18-way                                     |
| X4380 | Primary fusebox connector 2-way                                      |
| X4392 | Primary fusebox connector 6-way                                      |
| X4831 | Switchbox connector 12-way   |
| X5022 | High mounted stop lamp connector 2-way                               |
| X5023 | Right-hand rear lamp assembly connector 10-way                       |
| X5024 | Left-hand rear lamp assembly connector 10-way                        |
| X5514 | High mounted stop lamp connector 2-way                               |
| X5515 | Right-hand rear lamp assembly connector 10-way                       |
| X5516 | Left-hand rear lamp assembly connector 10-way                        |
| X5540 | Switchbox connector 12-way   |
| X5546 | Driver's information panel connector 12-way                          |

#### Circuit Links

| Description | Circuit                | Additional Information |
|-------------|------------------------|------------------------|
| D           | <a href="#">050107</a> | 12 V+ from the battery |