



128、IPB (一)

IPB


接插件信息




IPB
① 零件: 1 928 405782 (BOSCH) (请见零件数字序号)
端子:
端子: 1928 405 783
端子:
1928 498 806 (2.5mm²L, 镀锡)
1928 498 629 (4.8mm²L, 镀锡)
1928 498 259 (1.2mm²L, 镀锡)




B01B 接左后轮速传感器
① 零件: 1-967644-1
端子:
密封堵:




D01A 接左后轮速传感器
① 零件: 1-967644-1
端子:
密封堵:




X08A 接左后轮速传感器和EPB电机
① 零件: 936257-2
端子:
密封堵:
附件:



X08B 接右后轮速传感器和EPB电机
① 零件: 936257-2
端子:
密封堵:
附件:



K75 锁止机构
① 零件: 1-967640-1 (TYCO)
端子: 965906-1 (镀锡)
密封堵: 967067-1



B17 接制动踏板开关
① 零件: 1-967644-1
端子: 962885-1
密封堵: 967067-1