

整车控制系统

整车控制系统.....	7-1
系统描述	7-1
系统图	7-4
规定力矩	7-7
故障码表	7-8
P057662.....	7-20
P062F44.....	7-21
P064216.....	7-22
P064317.....	7-23
P065216.....	7-24
P065317.....	7-25
P069111.....	7-26
P069212.....	7-27
P069111.....	7-28
P069412.....	7-29
P069816.....	7-30
P069917.....	7-31
P0A0A13	7-32
P0A0B96	7-33
P0A0C11	7-34
P0A0D12.....	7-35
P0C4713	7-36
P0C4811	7-37
P0C4912	7-38
P0CE913	7-39
P0CEB11.....	7-40
P0CEC12.....	7-41
P140096.....	7-42
P140496.....	7-43
P140596.....	7-44
P140796.....	7-45
P140896.....	7-46
P140B29	7-47
P140C96	7-48
P140D96	7-49
P140E29	7-50
P140F96.....	7-51
P141029.....	7-52
P141429.....	7-53
P141529.....	7-54
P141629.....	7-55

P141796.....	7-56
P141896.....	7-57
P141996.....	7-58
P142196.....	7-59
P142396.....	7-60
P142696.....	7-61
P142729.....	7-62
P143296.....	7-63
P143396.....	7-64
P143796.....	7-65
P146029.....	7-66
P146296.....	7-67
P146396.....	7-68
P146596.....	7-69
P146C29.....	7-70
P146D29.....	7-71
P147C29.....	7-72
P14A129.....	7-73
P14A229.....	7-74
P14A329.....	7-75
P14A429.....	7-76
P14A529.....	7-77
P14A629.....	7-78
P14A729.....	7-79
P14A829.....	7-80
P14A929.....	7-81
P14AA29.....	7-82
P14E096.....	7-83
P14E129.....	7-84
P14E229.....	7-85
P14FB62.....	7-86
P14FC96.....	7-87
P14FD96.....	7-88
P14FE96.....	7-89
P14FF96.....	7-90
P150029.....	7-91
P150167.....	7-92
P150229.....	7-93
P150596.....	7-94
P150696.....	7-95
P150796.....	7-96
P150896.....	7-97
P150996.....	7-98
P150C29.....	7-99
P151011.....	7-100

P151112.....	7-101
P151213.....	7-102
P151511.....	7-103
P151612.....	7-104
P151713.....	7-105
P151A96	7-106
P151B96	7-107
P151C96	7-108
P151D96	7-109
P151E11	7-110
P151F12.....	7-111
P152013.....	7-112
P152196.....	7-113
P152296.....	7-114
P152396.....	7-115
P152496.....	7-116
P152513.....	7-117
P152673.....	7-118
P152772.....	7-119
P152813.....	7-120
P152973.....	7-121
P152A72	7-122
P152B12	7-123
P152C11	7-124
P152D13	7-125
P152E12	7-126
P152F11.....	7-127
P153013.....	7-128
P153173.....	7-129
P153272.....	7-130
P153396.....	7-131
P153416.....	7-132
P153517.....	7-133
P153696.....	7-134
P153796.....	7-135
P153896.....	7-136
P153996.....	7-137
P153A96	7-138
P153B96	7-139
P153C96	7-140
P153D96	7-141
P153E17	7-142
P153F16.....	7-143
P154017.....	7-144
P154116.....	7-145

P154296.....	7-146
P154396.....	7-147
P154796.....	7-148
P154896.....	7-149
P154996.....	7-150
P155162.....	7-151
P156096.....	7-152
P156196.....	7-153
P156296.....	7-154
P156396.....	7-155
P156496.....	7-156
P156596.....	7-157
P156696.....	7-158
P156796.....	7-159
P156896.....	7-160
P156996.....	7-161
P156A96	7-162
P156B96	7-163
P156C96	7-164
P156D96	7-165
P158400.....	7-166
P158596.....	7-167
P158696.....	7-168
P158796.....	7-169
P158896.....	7-170
P158996.....	7-171
P158B96	7-172
P158D96	7-173
P159496.....	7-174
P159D00	7-175
P159E00	7-176
P159F00.....	7-177
P15A01C	7-178
P15A11C	7-179
P15A200	7-180
P15A262	7-181
P15A362	7-182
P15A496	7-183
P15A596	7-184
P15A696	7-185
P15A796	7-186
P15A896	7-187
P15A996	7-188
P15AA96	7-189
P15AB96.....	7-190

P15AC96	7-191
P15AE96	7-192
P15B096	7-193
P15B196	7-194
P15B296	7-195
P15B396	7-196
P15B496	7-197
P15B596	7-198
P15B696	7-199
P15B796	7-200
P15B896	7-201
P15BA96	7-202
P15BB96	7-203
P15BC96	7-204
P15BD96	7-205
P15BE96	7-206
P15C096	7-207
P15C196	7-208
P15C296	7-209
P15C396	7-210
P15C496	7-211
P15C696	7-212
P15C996	7-213
P15CA96	7-214
P15CB96	7-215
P15CC96	7-216
P15CD96	7-217
P15CE96	7-218
P15CF62	7-219
P15D296	7-220
P15D329	7-221
P15D496	7-222
P15D596	7-223
P15D729	7-224
P15D800	7-225
P15D900	7-226
P15DB00	7-227
P15DC96	7-228
P15DD96	7-229
P15DE96	7-230
P15DF96	7-231
P15E096	7-232
P15E196	7-233
P15E296	7-234
P15E396	7-235

P15E496	7-236
P15E596	7-237
P15E696	7-238
P15E796	7-239
P15E896	7-240
P15E996	7-241
P15EA96	7-242
P15EB96	7-243
P15EC96	7-244
P15ED00	7-245
P15EE00	7-246
P15EF00	7-247
P15F000	7-248
P15F100	7-249
P15F200	7-250
P15F400	7-251
P15F600	7-252
P15F800	7-253
P15FB00	7-254
P15FC00	7-255
P15FF00	7-256
P212216	7-257
P212317	7-258
P212716	7-259
P212817	7-260
P213862	7-261
U007508	7-262
U007588	7-263
U010387	7-264
U011087	7-265
U011187	7-266
U012287	7-267
U014382	7-268
U014383	7-269
U014387	7-270
U014487	7-271
U014687	7-272
U015587	7-273
U016487	7-274
U019887	7-275
U01BB87	7-276
U024387	7-277
U040482	7-278
U040483	7-279
U041182	7-280

U041183	7-281
U041282	7-282
U041283	7-283
U041382	7-284
U041383	7-285
U041682	7-286
U041683	7-287
U050282	7-288
U050283	7-289
U054482	7-290
U054483	7-291
U100082	7-292
U100083	7-293
U100087	7-294
U100287	7-295
U110116	7-296
U110200	7-297
U110400	7-298
U110487	7-299
U110500	7-300
U110600	7-301
U110687	7-302
U110017	7-303
U140100	7-304
U140400	7-305
U140500	7-306
U140B00	7-307
U141100	7-308
U141200	7-309
U141300	7-310
U141987	7-311
U141A87	7-312
U141E87	7-313
U141F87	7-314
U142087	7-315
U142100	7-316
U142287	7-317
U143100	7-318
U143400	7-319
U143B87	7-320
U143C87	7-321
U146100	7-322
U146200	7-323
U146400	7-324
U146500	7-325

U146700	7-326
U146800	7-327
U147187	7-328
U147287	7-329
U14A087	7-330
U14A187	7-331
U14A600	7-332
U14A787	7-333
U14A800	7-334
U14A900	7-335
U14AB00	7-336
U14E000	7-337
U14E100	7-338
U14E887	7-339
U14E987	7-340
U14EA87	7-341
U14EC87	7-342
U14ED87	7-343
U14EE87	7-344
U14F387	7-345
U14F587	7-346
U14F687	7-347
U14F787	7-348
U14F887	7-349
U14FB00	7-350
U14FE00	7-351
U150187	7-352
U150287	7-353
U150500	7-354
U150687	7-355
U150A87	7-356
U150B87	7-357
U150C00	7-358
U150D00	7-359
U151000	7-360
U151100	7-361
U151200	7-362
U151300	7-363
U151400	7-364
U15A000	7-365
U15A100	7-366
U15A300	7-367
U15A400	7-368
U15A500	7-369
U15A600	7-370

U15A700	7-371
U15A800	7-372
U15A900	7-373
U15AA00	7-374
U15AB00	7-375
U15AC00	7-376
U15AD00	7-377
U15D000	7-378
U15D100	7-379
U15D600	7-380
U15F300	7-381
U15F500	7-382
U15F700	7-383
U15F900	7-384
U15FA00	7-385
U15FD00	7-386
U15FE00	7-387
整车控制器	7-388
位置图	7-388
拆卸/安装	7-389
油门踏板	7-390
位置图	7-390
检查	7-391
拆卸/安装	7-391
换挡器	7-393
结构图	7-393
故障代码表	7-394
故障代码排除方法	7-395
拆卸/安装	7-401
驾驶模式切换开关	7-403
位置图	7-403
拆卸/安装	7-404

www.qxkjz.com