


灯光组合开关



档位图

端子		1	2	3	4	5	6	7	8	9	10	11	12	13	14
档位															
左转向 左变道		○	○												
零位															
右转向 右变道		○		○											
0															
蜂												○			○
蜂									○			○			○
0	上抬 I				○	○									
	上抬 II				○	○	○								
☀	上抬 I				○	○						○	○		
	上抬 II				○	○	○					○	○		
☀/☀	上抬 I				○	○						○	○		○
	上抬 II				○	○	○					○	○		○

