





8W-43 OCCUPANT RESTRAINT SYSTEM

Component	Page	Component	Page
Airbag-Driver Squib 1	8W-43-3	Module-Integrated Power	8W-43-2, 4
Airbag-Driver Squib 2	8W-43-3	Module-Occupant Restraint	
Airbag-Passenger Squib	8W-43-3	Controller	8W-43-2, 3, 4
Airbag-Side Curtain-Left	8W-43-4	PTC No. 2	8W-43-4
Airbag-Side Curtain-Right	8W-43-4	Seat Belt Tensioner-Driver	8W-43-3
Clockspring	8W-43-3	Seat Belt-Tension Reducer-Driver	8W-43-4
Cluster	8W-43-4	Seat Belt-Tensioner-Passenger	8W-43-3
Data Link Connector	8W-43-2	Sensor-Side Impact-Left 1	8W-43-4
Fuse 52	8W-43-2	Sensor-Side Impact-Right 1	8W-43-4
Fuse 53	8W-43-2	Switch-Passenger Airbag On/Off	8W-43-2
G204	8W-43-2		










SIDE AIRBAGS






SENSOR-SIDE IMPACT-LEFT 1



AIRBAG-SIDE CURTAIN-LEFT



SENSOR-SIDE IMPACT-RIGHT 1



AIRBAG-SIDE CURTAIN-RIGHT

MODULE-OCCUPANT RESTRAINT CONTROLLER