

8W-41 HORN/CIGAR LIGHTER/POWER OUTLET

Component	Page	Component	Page
Accessory Relay	8W-41-3, 4	G200	8W-41-2, 3, 4
Body Control Module	8W-41-3	G302	8W-41-3, 4
Clockspring	8W-41-2	High Note Horn	8W-41-2
Floor Console Lamp	8W-41-4	Horn Relay	8W-41-2
Floor Console Power Outlet	8W-41-4	Horn Switch	8W-41-2
Front Cigar Lighter	8W-41-3	Integrated Power Module	8W-41-2, 3, 4
Front Control Module	8W-41-2, 3, 4	Low Note Horn	8W-41-2
Fuse 5	8W-41-3	Power Outlet	8W-41-4
Fuse 6	8W-41-3, 4	PTC 7	8W-41-4
Fuse 8	8W-41-2	Radio	8W-41-3
G102	8W-41-2	Rear Power Outlet	8W-41-3





