

8W-39 VEHICLE THEFT SECURITY SYSTEM

Component	Page
Body Control Module	8W-39-2, 3, 6, 7, 8, 9, 10, 11, 12, 13
Clockspring	8W-39-5
Driver Door Lock Switch	8W-39-11, 12
Front Control Module	8W-39-2, 3, 5
Front Intrusion Sensor	8W-39-4
Fuse 8	8W-39-5
Fuse 14	8W-39-2
G102	8W-39-5
G200	8W-39-2, 3, 5
G300	8W-39-6, 7, 8, 10, 11, 12, 13
G301	8W-39-6, 7, 8, 10, 11, 12
G302	8W-39-13
G303	8W-39-13
High Note Horn	8W-39-5
Hood Ajar Switch	8W-39-13
Horn Relay	8W-39-5
Horn Switch	8W-39-5
Ignition Switch	8W-39-2, 3
Integrated Power Module	8W-39-2, 3, 5
Left Cylinder Lock Switch	8W-39-11, 12
Left Front Door Ajar Switch	8W-39-6
Left Front Door Lock Motor/Ajar Switch	8W-39-6, 7

Component	Page
Left Sliding Door Control Module	8W-39-8, 9
Left Sliding Door Latch Sensing Switch	8W-39-8
Left Sliding Door Lock Motor	8W-39-9
Left Sliding Door Lock Motor/Ajar Switch	8W-39-10
Liftgate Ajar Switch	8W-39-13
Liftgate Cinch/Release Motor	8W-39-13
Passenger Door Lock Switch	8W-39-11, 12
Power Liftgate Module	8W-39-13
Rear Intrusion Sensor	8W-39-4
Right Cylinder Lock Switch	8W-39-11, 12
Right Front Door Ajar Switch	8W-39-6
Right Front Door Lock Motor/Ajar Switch	8W-39-6, 7
Right Sliding Door Control Module	8W-39-8, 9
Right Sliding Door Latch Sensing Switch	8W-39-8
Right Sliding Door Lock Motor	8W-39-9
Right Sliding Door Lock Motor/Ajar Switch	8W-39-10
Sentry Key Remote Entry Module	8W-39-2
Siren	8W-39-3
Thatcham Alarm Indicator	8W-39-4
Thatcham Alarm Module	8W-39-3, 4

























