


FUEL INJECTOR

COMPONENTS





N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part

*1: Do not allow oil to contact these bolts

FU

FU



N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part