


# Heater



○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A8	36	B3	36	B5	36
A11	36	B4	36	J7	37

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IM	24	
3A	28	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		

▽ : Ground Points

Code	See Page	Ground Points Location
IG	44	Right Kick Panel