



Front Wiper and Washer





Front Wiper and Washer

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A23	A	41 (LHD)	A38	41 (LHD)	D15
	B	55 (RHD)		55 (RHD)	
A28	41 (LHD)	D14	B	44 (LHD)	D45
	55 (RHD)			58 (RHD)	
				44 (LHD)	45 (LHD)
				58 (RHD)	59 (RHD)

○ : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	30	Engine Room Main Wire and Instrument Panel J/B Assembly (Left Instrument Panel Reinforcement)
1I	31	Instrument Panel Wire and Instrument Panel J/B Assembly (Left Instrument Panel Reinforcement)


□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
AD3	70 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Cowl Side Panel LH)
	76 (RHD)	

▽ : Ground Points

Code	See Page	Ground Points Location
A2	68 (LHD)	Front Fender Apron LH
	74 (RHD)	
D3	70 (LHD)	Instrument Panel Reinforcement
	76 (RHD)	





 : Parts Location

Code		See Page	Code		See Page	Code		See Page
A30		41 (LHD)	D42		45 (LHD)	T14		51 (LHD)
		55 (RHD)			59 (RHD)			65 (RHD)
D14	B	44 (LHD)	D45		45 (LHD)	T15		51 (LHD)
		58 (RHD)			59 (RHD)			65 (RHD)
D15	A	44 (LHD)	T1		51 (LHD)			
		58 (RHD)			65 (RHD)			

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	30	Engine Room Main Wire and Instrument Panel J/B Assembly (Left Instrument Panel Reinforcement)
1P	30	Floor No.2 Wire and Instrument Panel J/B Assembly (Left Instrument Panel Reinforcement)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
AD3	70 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Cowl Side Panel LH)
	76 (RHD)	
DO3	70 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Cowl Side Panel LH)
	76 (RHD)	
DO4	70 (LHD)	
	76 (RHD)	
OD1	71 (LHD)	Floor No.2 Wire and Instrument Panel Wire (Instrument Panel Brace LH)
	77 (RHD)	
XO1	72 (LHD)	Back Door No.3 Wire and Floor No.2 Wire (Roof Panel)
	78 (RHD)	
XT2	72 (LHD)	Back Door No.3 Wire and Back Door No.1 Wire (Back Window Upper Frame)
	78 (RHD)	

 : Ground Points

Code	See Page	Ground Points Location
D3	70 (LHD)	Instrument Panel Reinforcement
	76 (RHD)	
T1	72 (LHD)	Back Door Panel
	78 (RHD)	