






A28	离合器起动开关总成
A52	刹车灯开关总成
A58	2 号离合器起动开关总成
A63	9 号接线连接器
A64	10 号接线连接器
A67	发动机启停 ECU
A68	发动机启停 ECU
A69	发动机启停 ECU
B63	ECM
B64	ECM
B65	ECM
D1	仪表板乘客空气囊总成
z1	喇叭按钮总成、螺旋电缆分总成
z3	驾驶员侧点火管电路 (喇叭按钮总成)、螺旋电缆分总成
z4	动力转向 ECU 总成、动力转向电动机总成
z5	动力转向 ECU 总成、动力转向扭矩传感器
z6	方向盘装饰盖开关总成、螺旋电缆分总成
z7	螺旋电缆分总成、巡航控制主开关




90980-10825




90980-12954




90980-10825




90980-12372




90980-12372




90980-11362




90980-12566




82824-12510




90980-12527




90980-12528




90980-12526




90980-12576




90980-12361




90980-12224




90980-12918



90980-12899



90980-12361



90980-12360