



门锁控制






门锁控制




门锁控制




*13 :带防夹
*14 :不带防夹

门锁控制


E20 (A)
主车身 ECU



门锁控制




A39
黑色




90980-12372

A42
灰色




90980-12828

E20
白色




90980-12909

E57
灰色




90980-12372

E58
黑色




90980-12372

G8
白色




90980-12226

H6
白色




90980-12122

H9
白色




90980-12226

J3
白色



90980-12226

K3
白色



90980-12226

L1
黑色




90980-10871

L2
黑色




90980-10871

L15
白色



90980-12366

L29
黑色



90980-10908

L39
黑色




90980-10871

L40
黑色




90980-10871

L53
黑色




90980-12372

L54
黑色




90980-12372

3A
白色




90980-12A15

3C
白色




90980-12890

3D
白色



90980-12887


3E
白色




90980-12884

AE3

白色




90980-12743




90980-12742

EL2

黑色




90980-12741




90980-12740

EL6

白色




90980-12737




90980-12736

GE1

白色




90980-12A22




90980-12638

GE3

白色




90980-12A21




90980-12546

HE1
白色




90980-12A22




90980-12638

HE3
白色




90980-12A21




90980-12546

JL1
白色




90980-12A01




90980-12A00

门锁控制

KL1
白色



90980-12A01



90980-12A00