







SYNC I





SYNC I




SYNC I








带活动噪音控制





模块通信网络

14-14
14-16
14-14
14-16

VDB06 GY

VDB07 VT

C2402A
17
18

MS CAN +

MS CAN -

蓄电池电压

接地

1
GD216
BK-GY
G202
10-12

26 C2402A

10 C2280H

SBP12
GN-RD

S297

SBP12
GN-RD

常电源

F12
7.5A
13-46

车身控制
模块 (BCM)
11-5

前部控制
接口模块
(FCIM)
151-25 151-27

畅易汽车维修平台

