




灯光总开关	OFF																
	AUTO																
变光开关	HL																
	HU																
	HF																
转向开关	R																
	R'																
	TN																
	L'																
	L																
雾灯开关	OFF																
功能	管脚	1	2	3	4	5	6	7	8	9	10	11	12				