





四、电池管理系统




整车电器原理图



HC18R-S32


RMS政治管理系統

TE:1473407-1
TE:1674742-1
接车身主数据LD10



12

TYCO:1-1703639-1
AMP:1241380-1



10