




十九、天窗系统



AMP:368544-1
AMP:173630-1
AMP:173631-1
AMP:85098-1


前车顶窗-ECU E05



ZHC:7081-2.3-21
ZHC:DJ621-G2.3*0.6

前车顶窗电机 E03

HL:NTL10BSL05N
HL:617003
后遮阳窗开关(后座用) E38





HL:RB2BSL02N
HL:604503

遮阳窗电机(前左侧) E14



HL:RB2BSL02N
HL:604503

遮阳窗电机 E07




HL:RB2BSL02N
HL:604503


遮阳窗电机(后左侧) E42




HL:RB2BSL02N
HL:604503
遮阳窗电机(后右侧) E31A




ZHC:32080014
ZHC:DJ621-G2.3*0.6
遮阳窗继电器(前右侧) E32



ZHC:32080014
ZHC:DJ621-G2.3*0.6
遮阳窗继电器(后右侧) E34



ZHC:32080014
ZHC:DJ621-G2.3*0.6
遮阳窗继电器(后左侧) E35



ZHC:32080014
ZHC:DJ621-G2.3*0.6
遮阳窗继电器(前左侧) E33