




二十五、档位控制器



二十六、高压互锁




整车电器原理图



护套 HC18B-S32


BMS电池管理系统



TYCO:1-1563759-1

TYCO:1241380-1

BMS从电池包 CH01




TYCO:1743062-2

TE:964269-2

TE:964300-1/964302-1


接低压控制电缆束总成 FB-HC1



TE:1318774-1

TE:1674298-1

接底盘线束3 IP52



KET:MG652400

KET:ST730770-3

ST730675-3

ST730676-3

ST730644-3

ST730645-3

ST730646-3

接车身主电缆束 FB26