





## 1.12 整车专用工具列表



### 1.12.1 专用工具和设备

#### 1.12.1.1 底盘与车身专用工具

1

| 序号 | 图示  | 工具号       | 名称          |
|----|---|-----------|-------------|
| 1  | <br>FE0142-128ZZ   | GL401-001 | 前桥轮毂轴承拆卸    |
| 2  | <br>FE0142-129ZZ   | GL401-002 | 驱动轴内球笼拆卸器   |
| 3  | <br>FE0142-130ZZ | GL401-003 | 后桥胶套拆装工具    |
| 4  | <br>FE0142-131ZZ | GL401-004 | 车轮螺母罩拆卸工具   |
| 5  | <br>FE0142-132ZZ | GL501-001 | 减速器壳体油封拆装工具 |

1

| 序号 | 图示  | 工具号       | 名称          |
|----|---|-----------|-------------|
| 6  | <br>FE0142-133ZZ | GL501-002 | 减速器壳体油封拆装工具 |
| 7  | <br>FE0142-134ZZ | GL501-003 | 减速器壳体油封拆装工具 |