

























专用工具

	<p>5058A - 压缩机, 弹簧</p> <p>Originally Shipped In Kit Number(s) 8853.</p>
	<p>6311 - 规杆</p> <p>Originally Shipped In Kit Number(s) 6692, 9202, 9202A-CAN, 9202CC, 9299, 9299CC, 9299CC, 9300A-CAN.</p>
	<p>7794-A - 除去器, 密封件</p> <p>Originally Shipped In Kit Number(s) 6645.</p>
	<p>8513A - 嵌件, 曲轴</p> <p>Originally Shipped In Kit Number(s) 8283, 8527, 8575, 8999, 8999CC.</p>
	<p>8888 - 插头, 差速器轴承</p> <p>Originally Shipped In Kit Number(s) 8887, 8887CC.</p>
	<p>8900A - 多次使用弹簧压缩机</p> <p>Originally Shipped In Kit Number(s) 9202, 9202CC, 9299, 9299CC, 9299CC, 9300A-CAN, 9329-SUP, 9516-SUP, 9518-SUP, 9540-SUP, 9785-SUP.</p>
	<p>9336A - 量油尺</p> <p>Originally Shipped In Kit Number(s) 9336A, 9541.</p>
	<p>9613 - 适配器, 拉紧器</p> <p>Originally Shipped In Kit Number(s) 9690, 9720-SUP.</p>
	<p>9664 - 除去器, 轴承外座圈</p>

	<p>Originally Shipped In Kit Number(s) 9675, 9685, 9695.</p>
	<p>9667 - 除去器, 密封件 Originally Shipped In Kit Number(s) 9691.</p>
	<p>9668 - 除去器/安装器, 轴承外圈 Originally Shipped In Kit Number(s) 9691.</p>
	<p>9858 - 安装器, 密封件 Originally Shipped In Kit Number(s) 9870, 9971.</p>
	<p>9871 - 安装器, 密封件 Originally Shipped In Kit Number(s) 9870, 9971.</p>
	<p>9874 - 压缩机, 皮带轮 Originally Shipped In Kit Number(s) 9870-SUP, 9971.</p>
	<p>9875 - 压缩机 Originally Shipped In Kit Number(s) 9870, 9971.</p>
	<p>9876 - 调整工具 Originally Shipped In Kit Number(s) 9870, 9971.</p>
	<p>9877 - 安装器, 密封件 Originally Shipped In Kit Number(s) 9870, 9971.</p>

	
	<p>9878 - 变速器维修台</p> <p>Originally Shipped In Kit Number(s) 9870-SUP, 9971.</p>
	<p>C-293-40 - 垫块组, 拉紧器</p> <p>Originally Shipped In Kit Number(s) 9695, 9870, 9971.</p>
	<p>C-293-PA - 拉紧器, 压机</p> <p>Originally Shipped In Kit Number(s) 8418, 8837, C-293-M.</p>
	<p>C-3752 - 滑动锤</p> <p>Originally Shipped In Kit Number(s) 9202, 9202A-CAN, 9202-CAN, 9202CC.</p>
	<p>C-4171 - 通用驱动器手柄</p> <p>Originally Shipped In Kit Number(s) 9202, 9202A-CAN, 9202CC, 9299, 9299CC, 9299CC, 9300A-CAN.</p>
	<p>C-4628 - 安装器, 外座圈</p>
	<p>C-4996 - 适配器, 插头</p> <p>Originally Shipped In Kit Number(s) 6672.</p>
	<p>C-637 - 滑动锤, 通用</p> <p>Originally Shipped In Kit Number(s) 9202.</p>

	
	<p>D-129 - 安装器, 轴承外座圈</p> <p>Originally Shipped In Kit Number(s) 6947, 6949, 8667.</p>