

8W-35 ANTILOCK BRAKES

Component	Page	Component	Page
Antilock Brake Relay	8W-35-2	Fuse Block	8W-35-2, 3
Brake Lamp Switch	8W-35-3	G-Switch	8W-35-3
Brake Transmission Shift Interlock Solenoid	8W-35-2	G100	8W-35-2
Center High Mounted Stop Lamp	8W-35-3	G101	8W-35-2
Controller Antilock Brake	8W-35-2, 3, 4	Instrument Cluster	8W-35-2
Data Link Connector	8W-35-3	Multi-Function Switch	8W-35-3
Fuse 2 (FB)	8W-35-3	Left Front Wheel Speed Sensor	8W-35-4
Fuse 7 (FB)	8W-35-2	Left Rear Wheel Speed Sensor	8W-35-4
Fuse 8 (PDC)	8W-35-2	Power Distribution Center	8W-35-2
Fuse 10 (FB)	8W-35-2	Powertrain Control Module	8W-35-3
Fuse 12 (PDC)	8W-35-2	Right Front Wheel Speed Sensor	8W-35-4
		Right Rear Wheel Speed Sensor	8W-35-4





