

## X250 (LHD) CONNECTOR QUICK REFERENCE GUIDE


**Document Objective:** To provide basic connector location information only, including in-lines and grounds.

A RHD version of this document will not be produced. For detailed connector information (including RHD) refer to the Electrical Reference Library (ERL) at the EDS web site:

<http://esr.gaydon.landrover.ford.com/eds/jlrcircuits>


**Note:** For improved clarity some harnesses have been omitted completely e.g. engines, seats, steering, climate control and some link leads.

All paper copies are uncontrolled.




## AREA 'B'


### INSTRUMENT PANEL



**AREA 'C'**  
**CENTRE CONSOLE**



AREA 'E'  
REAR RIGHT QUARTER



# X250 SPORTBRAKE (LHD) CONNECTOR QUICK REFERENCE GUIDE


**Document Objective:** To provide basic connector location information only, including in-lines and grounds.

**Use in conjunction with X250 Saloon Connector Quick Reference Guide.**

A RHD version of this document will not be produced. For detailed connector information (including RHD), refer to the Electrical Reference Library (ERL) at the EDS web site: <http://esr.gaydon.landrover.ford.com/eds/jlrcircuits>

**Note:** For improved clarity some harnesses have been omitted completely e.g. engines, seats, steering, climate control and some link leads.


All paper copies are uncontrolled.





# X250 SPORTBRAKE (LHD) CONNECTOR QUICK REFERENCE GUIDE

All paper copies are uncontrolled.


AREA 'C' - REAR ROOF



AREA 'D' - LEFT REAR QUARTER



TAILGATE - INTERIOR VIEW



AREA 'E' - RIGHT REAR QUARTER