



## 主线束


### 主线束(1)




M01




M07 M08



M02 M03 M04 M05



M10 M11




M06




M12

## 主线束 (2)




M13




M17 M18



M14



M20




M15 M16 M19




M21 M22

## 主线束 (3)



M23



M27



M24



M28



M25 M26



M29

## 主线束 (4)



**M30 M31**



**M34**




**M32**



**M35**




**M33**




**ME01 ME02 ME03**

## 主线束 (5)



MF01 MF03




MF02 MA01 MA02



MA03

## ABS 线束




A01 A03



A05




A02



A06




A04




MA01 MA02

## 空调线束




A10 MA03




A14 A15



A11 A13



A16 A17



A12 AA01

## 发动机仓线束

### 发动机仓线束(1)



E01



E05




E02



E06



E04



E07


## 发动机仓线束 (2)




E09




E14



E10 E11



E15



E12 E13



E16

## 发动机仓线束 (3)




E17



E21



E18



ME01 ME02 ME03 EF01 EF02




E19



CE01 CE02


## 电源线束




EE01 E22 E24



E25 E26



E23




E27 E28

## 控制线束

### 控制线束(1)




C20 C21 C22 C23



C01



C24 C25



C02 C03




C26 C27




C05


## 控制线束 (2)



**C04 C06 CC01**



**E12 E13**



**C11 C12 C10**




**CE01 CE02**



## 车架线束

### 车架线束(1)




F01 F02 F03




F06 F19




F04



F07




F05



F08 F09


## 车架线束 (2)



**F10 F12**




**F15**



**F11**



**F16**



**F13 F14 FR01 FR02**




**F17 F18**

## 车架线束 (3)




F19



MF01 MF03 EF01 EF02



F20 F21



FD01



F27




FD03


## 车架线束 (4)



FD04



MF02 FR03



FD05




FR04


## 车门线束 左前门线束



D01 D02




D04 D05



D06 D07 D08



D09



FD01


## 右前门线束



D10 D11



D12



D13 D14 D15




D16



FD03

## 后门线束



D17 D19 D21



D18



D20




D22




FD04

## 尾门线束&传感器线束




R05 R06 R07 R08



G10 R18 FR04




FR01



R17 G11



R01 R02 R03 R04




FR02

## 顶棚线束


### 顶棚线束(1)




R10



R13 R14




R11 R12 R15 R16



FR03

## 搭铁线束

### 搭铁线束(1)



G01




G05



G02



G06 G07




G03 G04



G08


## 搭铁线束 (2)




G09



G12 G13 G14




G10



G15 G16 G17



G11



G30