

8W-60 POWER WINDOWS

Component	Page
Circuit Breaker No. 2 (FB)	8W-60-2, 4
Front Power Window Switch	8W-60-2, 3, 4, 5, 6
Fuse Block	8W-60-2, 4
G203	8W-60-2
G300	8W-60-5
G301	8W-60-6
Instrument Cluster	8W-60-2, 4

Component	Page
Left Front Power Window Motor	8W-60-3
Left Rear Power Window Motor	8W-60-5
Left Rear Power Window Switch	8W-60-4, 5
Right Front Power Window Motor	8W-60-3
Right Rear Power Window Motor	8W-60-6
Right Rear Power Window Switch . . .	8W-60-4, 5, 6









