



© Automobili Lamborghini S.p.A.

The information and procedures published below are strictly confidential and exclusively for the Lamborghini Dealer Network and Authorized Service Points. All copyrights are property of Automobili Lamborghini S.p.A based on copyright law. All of the PDF chapters in the WEB workshop manuals described below are based on information available at the time of publication. The company reserves the right to make updates and modifications. The following are prohibited: reprinting, reproduction, forwarding to unauthorized people and/or third parties, and translation, including partial, without written authorization from Automobili Lamborghini S.p.A.



Catalytic converter temperature check

The temperature of the catalytic converters is estimated through calibration with the Misfiring system; there are NO more sensors that measure their temperature.

Proper temperature operation with respect to all the other engine parameters is read with the engine running normally; depending on one or more misfirings, how much the temperature varies is CALCULATED.

In this way, the temperature of the catalytic converter is determined depending on the problem.



It must in any case be remembered that this temperature is not the real one, but only the estimated one.
This value can be seen by means of LaRa-AS (109000).