



® Automobili Lamborghini S.p.A.

The information and procedures published below are strictly confidential and exclusively for the Lamborghini Dealer Network and Authorized Service Points. All copyrights are property of Automobili Lamborghini S.p.A based on copyright law. All of the PDF chapters in the WEB workshop manuals described below are based on information available at the time of publication. The company reserves the right to make updates and modifications. The following are prohibited: reprinting, reproduction, forwarding to unauthorized people and/or third parties, and translation, including partial, without written authorization from Automobili Lamborghini S.p.A.

The present section contains the following assembly sequences:

A) Fuel anti-evaporation valve

B) Canister



#### A) Fuel anti-evaporation valve

1. Assemble the fuel anti-evaporation valve (A-Fig.1) on the tank using the six socket head screws.

- Assemble the air filter guard (013305).
- Assemble the right side carbon bulkhead (081305).
- Assemble the silencer safety grid (025105).
- Position the right hood support piston (012705).



Fig.1

#### B) Canister

1. Place the canister (B-Fig.2) in its special housing inside the left side of the vehicle.

2. Reconnect the three pipes (C-Fig.2) of the canister.

- Assemble the air filter (013305).
- Assemble the air filter guard (013305).
- Assemble the left side carbon bulkhead (081305).
- Assemble the silencer safety grid (025105).
- Position the left hood support piston (012705).



Fig.2