



© Automobili Lamborghini S.p.A.

The information and procedures published below are strictly confidential and exclusively for the Lamborghini Dealer Network and Authorized Service Points. All copyrights are property of Automobili Lamborghini S.p.A based on copyright law. All of the PDF chapters in the WEB workshop manuals described below are based on information available at the time of publication. The company reserves the right to make updates and modifications. The following are prohibited: reprinting, reproduction, forwarding to unauthorized people and/or third parties, and translation, including partial, without written authorization from Automobili Lamborghini S.p.A.



### Front combination lights adjustment

Front combination lights have three adjustment devices each (two to adjust low beam headlights and one to adjust the fog lights) fitted in the lower part of the cluster. Can be accessed from the luggage compartment inner sides and from the wheel arch shutters.

Each cluster has one lamp for both high beam and low beam headlights: the light different inclination is obtained by means of the power reflecting baffle plate inside the cluster.

LH front combination lights adjustment devices (Fig.1)		
Ref.	Description	Adjustment
A.	Low beam and high beam headlight horizontal light adjustment	Turning the light inside clockwise
B.	Low beam and high beam headlight vertical light adjustment	Turning the light downwards clockwise
C.	Fog light adjustment	Turning the light upwards clockwise




Fig.1

www.car60.com



® Automobili Lamborghini S.p.A.

The information and procedures published below are strictly confidential and exclusively for the Lamborghini Dealer Network and Authorized Service Points. All copyrights are property of Automobili Lamborghini S.p.A based on copyright law. All of the PDF chapters in the WEB workshop manuals described below are based on information available at the time of publication. The company reserves the right to make updates and modifications. The following are prohibited: reprinting, reproduction, forwarding to unauthorized people and/or third parties, and translation, including partial, without written authorization from Automobili Lamborghini S.p.A.

- Remove the luggage compartment inner sides and the wheel arch shutters.
- Adjust the low/high beam headlight vertical inclination by means of device **(A-Fig.2)**.
- Adjust the low/high beam headlight horizontal inclination by means of device **(B-Fig.2)**.
- Adjust the fog light vertical inclination by means of device **(C-Fig.2)**.




Fig.2