

Power Source -Matrix Chart-

 Capacity
  Name

Engine Room R/B and Engine Room J/B		
Fuse		System
20A	ABS MAIN NO.1	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u>
7.5A	ABS MAIN NO.2	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u>
		<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u>

30A	ABS MTR 1	<u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u>
30A	ABS MTR 2	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u>
7.5A	AM2	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u>

		<u>(RHD)</u> <u>Parking Assist (Rear View Monitor)</u> <u>Power Seat (LHD)</u> <u>Power Seat (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Starting (w/o Entry Function)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u>
30A	AMP NO.1	<u>Audio System (w/ LEXUS Navigation System)</u> <u>Audio System (w/o LEXUS Navigation System w/ Stereo Component Amplifier)</u> <u>LEXUS Navigation System</u> <u>Parking Assist (Back Guide Monitor)</u>
30A	AMP NO.2	<u>Audio System (w/ LEXUS Navigation System)</u> <u>Audio System (w/o LEXUS Navigation System w/ Stereo Component Amplifier)</u> <u>LEXUS Navigation System</u> <u>Parking Assist (Back Guide Monitor)</u>
10A	BATT FAN	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
30A	CDS	<u>Cooling Fan</u>
125A	DC/DC	<u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Front Fog Light</u> <u>Headlight Beam Level Control (Manual)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Illumination</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u>

		<u>Rear Fog Light</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Taillight</u>
5A	DC/DC-S	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
10A	DOVE	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Interior Light</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
25A	DOOR NO.2	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Door Lock Control (LHD)</u> <u>Door Lock Control (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u>

		<u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
7.5A	DRL	<u>Headlight</u>
7.5A	ECU-B	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Air Conditioner</u> <u>Audio System (w/ LEXUS Navigation System)</u> <u>Audio System (w/o LEXUS Navigation System w/ Stereo Component Amplifier)</u> <u>Audio System (w/o LEXUS Navigation System w/o Stereo Component Amplifier)</u> <u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Combination Meter</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Door Lock Control (LHD)</u> <u>Door Lock Control (RHD)</u> <u>Double Locking</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>EPS</u> <u>Front Fog Light</u> <u>Front Wiper and Washer (w/ Auto Wiper System)</u> <u>Garage Door Opener</u> <u>Headlight</u> <u>Headlight Beam Level Control (Automatic)</u> <u>Headlight Beam Level Control (Manual)</u> <u>Headlight Cleaner</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Illumination</u> <u>Interior Light</u>

		<u>LEXUS Navigation System</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u> <u>Mirror Heater</u> <u>Parking Assist (Back Guide Monitor)</u> <u>Parking Assist (LEXUS Parking Assist-Sensor)</u> <u>Power Seat (LHD)</u> <u>Power Seat (RHD)</u> <u>Power Window (LHD)</u> <u>Power Window (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Rear Fog Light</u> <u>Rear Window Defogger</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Seat Belt Warning</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Sliding Roof</u> <u>SRS</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Starting (w/o Entry Function)</u> <u>Taillight</u> <u>Theft Deterrent</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
7.5A	ECU-B2	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Starting (w/o Entry Function)</u> <u>Theft Deterrent</u>

		<u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
10A	ECU-B3	<u>Air Conditioner</u> <u>Front Window Deicer</u> <u>Mirror Heater</u> <u>Rear Window Defogger</u>
20A	EFI MAIN	<u>Cooling Fan</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
10A	EFI NO.2	<u>Cooling Fan</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
30A	ENG W/P	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
60A	EPS	<u>EPS</u>
10A	ETCS	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u>

		<u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
30A	H-LP CLN	<u>Headlight Cleaner</u>
20A	H-LP HI MAIN	<u>Headlight</u>
10A	H-LP LH HI	<u>Headlight</u>
10A	H-LP RH HI	<u>Headlight</u>
50A	HTR	<u>Air Conditioner</u>
20A	IG2	<u>Combination Meter</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Ignition</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
30A	IGCT	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Starting (w/o Entry Function)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u>
		<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u>

10A	IGCT NO.2	<u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Starting (w/o Entry Function)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u>
10A	IGCT NO.3	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
10A	MAYDAY	<u>G-BOOK</u>
10A	M-HTR	<u>Mirror Heater</u> <u>Rear Window Defogger</u>
7.5A	P CON MAIN	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Shift Control System (LHD)</u>

		<u>Shift Control System (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u>
30A	P CON MTR	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u>
40A	P/I 2	<u>Air Conditioner</u> <u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Back-Up Light</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Front Window Deicer</u> <u>Headlight</u> <u>Headlight Beam Level Control (Automatic)</u> <u>Headlight Cleaner</u> <u>Horn</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u> <u>Mirror Heater</u> <u>Parking Assist (Rear View Monitor)</u>

		<u>Rear Window Defogger</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Theft Deterrent</u>
10A	PCU	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>
15A	RAD NO.1	<u>Audio System (w/ LEXUS Navigation System)</u> <u>Audio System (w/o LEXUS Navigation System w/ Stereo Component Amplifier)</u> <u>Audio System (w/o LEXUS Navigation System w/o Stereo Component Amplifier)</u> <u>LEXUS Navigation System</u> <u>Parking Assist (Back Guide Monitor)</u>
30A	RDI	<u>Cooling Fan</u>
10A	TURN & HAZ	<u>Turn Signal and Hazard Warning Light</u>

Instrument Panel J/B Assembly		
Fuse		System
10A	A/C	<u>Air Conditioner</u> <u>Front Window Deicer</u> <u>Mirror Heater</u> <u>Rear Window Defogger</u>
25A	D FR DOOR	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Door Lock Control (LHD)</u> <u>Door Lock Control (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Interior Light</u> <u>Mirror Heater</u>

		<u>Power Seat (LHD)</u> <u>Power Seat (RHD)</u> <u>Power Window (LHD)</u> <u>Power Window (RHD)</u> <u>Rear Window Defogger</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Theft Deterrent</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
25A	DBL LOCK	<u>Double Locking</u>
25A	DOOR NO.1	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Air Conditioner</u> <u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Combination Meter</u> <u>Door Lock Control (LHD)</u> <u>Door Lock Control (RHD)</u> <u>Double Locking</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Front Fog Light</u> <u>Headlight</u> <u>Headlight Beam Level Control (Automatic)</u> <u>Headlight Beam Level Control (Manual)</u> <u>Headlight Cleaner</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Illumination</u> <u>Interior Light</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u> <u>Power Seat (LHD)</u> <u>Power Seat (RHD)</u>

		<u>Power Window (LHD)</u> <u>Power Window (RHD)</u> <u>Rear Fog Light</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Sliding Roof</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Taillight</u> <u>Theft Deterrent</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
25A	DOOR RL	<u>Power Window (LHD)</u> <u>Power Window (RHD)</u>
25A	DOOR RR	<u>Power Window (LHD)</u> <u>Power Window (RHD)</u>
10A	ECU-ACC	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Air Conditioner</u> <u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Combination Meter</u> <u>Door Lock Control (LHD)</u> <u>Door Lock Control (RHD)</u> <u>Double Locking</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Front Fog Light</u> <u>Headlight</u> <u>Headlight Beam Level Control (Automatic)</u> <u>Headlight Beam Level Control (Manual)</u> <u>Headlight Cleaner</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Illumination</u>

		<u>Interior Light</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u> <u>Mirror Heater</u> <u>Power Seat (LHD)</u> <u>Power Seat (RHD)</u> <u>Power Window (LHD)</u> <u>Power Window (RHD)</u> <u>Rear Fog Light</u> <u>Rear Window Defogger</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Remote Control Mirror (w/o Seat Position Memory)</u> <u>Sliding Roof</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Taillight</u> <u>Theft Deterrent</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
10A		<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Audio System (w/ LEXUS Navigation System)</u> <u>Automatic Glare-Resistant EC Mirror</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Electric Tension Reducer</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>EPS</u> <u>Front Wiper and Washer (w/ Auto Wiper System)</u> <u>Headlight Cleaner</u> <u>Heated Steering Wheel System</u>

	ECU-IG NO.2	<u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Illumination</u> <u>Interior Light</u> <u>LEXUS Navigation System</u> <u>Mirror Heater</u> <u>Parking Assist (Back Guide Monitor)</u> <u>Parking Assist (LEXUS Parking Assist-Sensor)</u> <u>Parking Assist (Rear View Monitor)</u> <u>Power Seat (LHD)</u> <u>Power Seat (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Rear Window Defogger</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Seat Heater</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Sliding Roof</u> <u>SRS</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Taillight</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>Turn Signal and Hazard Warning Light</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
		<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Air Conditioner</u> <u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Combination Meter</u> <u>Door Lock Control (LHD)</u> <u>Door Lock Control (RHD)</u> <u>Double Locking</u>

10A	ECU-IG1 NO.1	<u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Front Fog Light</u> <u>Headlight</u> <u>Headlight Beam Level Control (Automatic)</u> <u>Headlight Beam Level Control (Manual)</u> <u>Headlight Cleaner</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Illumination</u> <u>Interior Light</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u> <u>Power Seat (LHD)</u> <u>Power Seat (RHD)</u> <u>Power Window (LHD)</u> <u>Power Window (RHD)</u> <u>Rear Fog Light</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Sliding Roof</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Taillight</u> <u>Theft Deterrent</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
15A	FR FOG	<u>Front Fog Light</u>
7.5A	FUEL OPEN	<u>Fuel Lid Opener</u>
		<u>Air Conditioner</u> <u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Back-Up Light</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u>

10A	GAUGE	<u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Front Window Deicer</u> <u>Headlight</u> <u>Headlight Beam Level Control (Automatic)</u> <u>Headlight Cleaner</u> <u>Horn</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u> <u>Mirror Heater</u> <u>Parking Assist (Rear View Monitor)</u> <u>Rear Window Defogger</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Theft Deterrent</u>
10A	IGN	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>G-BOOK</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>SRS</u>

		<u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Starting (w/o Entry Function)</u> <u>Theft Deterrent</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
7.5A	MET	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Air Conditioner</u> <u>Audio System (w/ LEXUS Navigation System)</u> <u>Audio System (w/o LEXUS Navigation System w/ Stereo Component Amplifier)</u> <u>Audio System (w/o LEXUS Navigation System w/o Stereo Component Amplifier)</u> <u>Automatic Light Control (LHD)</u> <u>Automatic Light Control (RHD)</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Combination Meter</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>EPS</u> <u>Front Fog Light</u> <u>Front Wiper and Washer (w/ Auto Wiper System)</u> <u>Headlight</u> <u>Headlight Beam Level Control (Automatic)</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Illumination</u>

		<u>LEXUS Navigation System</u> <u>Light Auto Turn Off System (LHD)</u> <u>Light Auto Turn Off System (RHD)</u> <u>Light Reminder (LHD)</u> <u>Light Reminder (RHD)</u> <u>Parking Assist (Back Guide Monitor)</u> <u>Parking Assist (LEXUS Parking Assist-Sensor)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Rear Fog Light</u> <u>Seat Belt Warning</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Sliding Roof</u> <u>SRS</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Starting (w/o Entry Function)</u> <u>Taillight</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
7.5A	OBD	<u>DLC3</u>
25A	P FR DOOR	<u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Back Door Opener (w/o Entry Function) (LHD)</u> <u>Back Door Opener (w/o Entry Function) (RHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (LHD)</u> <u>Engine Immobiliser System (w/o Entry Function) (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Interior Light</u> <u>Mirror Heater</u> <u>Power Window (LHD)</u> <u>Power Window (RHD)</u> <u>Rear Window Defogger</u> <u>Remote Control Mirror (w/ Seat Position Memory)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u>

		<u>Wireless Door Lock Control (w/o Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/o Entry Function) (RHD)</u>
10A	PANEL	<u>Illumination</u> <u>Taillight</u>
30A	PSB	<u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u>
15A	PWR OUTLET	<u>Power Outlet</u>
15A	PWR OUTLET2	<u>Power Outlet</u>
30A	PWR SEAT FL	<u>Power Seat (LHD)</u>
30A	PWR SEAT FR	<u>Power Seat (RHD)</u>
7.5A	RAD NO.2	<u>Audio System (w/ LEXUS Navigation System)</u> <u>Audio System (w/o LEXUS Navigation System w/ Stereo Component Amplifier)</u> <u>Audio System (w/o LEXUS Navigation System w/o Stereo Component Amplifier)</u> <u>G-BOOK</u> <u>Illumination</u> <u>LEXUS Navigation System</u> <u>Parking Assist (Back Guide Monitor)</u> <u>Taillight</u>
7.5A	RR FOG	<u>Rear Fog Light</u>
20A	RR WIP	<u>Rear Wiper and Washer</u>
30A	S/ROOF	<u>Sliding Roof</u>
10A	SEAT HTR FL	<u>Seat Heater</u>
10A	SEAT HTR FR	<u>Seat Heater</u>
10A	STOP	<u>ABS (LHD)</u> <u>ABS (RHD)</u> <u>Back Door Opener (w/ Entry Function) (LHD)</u> <u>Back Door Opener (w/ Entry Function) (RHD)</u> <u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Entry & Start System (LHD)</u> <u>Entry & Start System (RHD)</u> <u>Hill-Start Assist Control (LHD)</u> <u>Hill-Start Assist Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (LHD)</u>

		<u>Hybrid Vehicle Immobiliser System (w/ Entry Function) (RHD)</u> <u>Pre-Crash Safety System (LHD)</u> <u>Pre-Crash Safety System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u> <u>Starting (w/ Entry Function) (LHD)</u> <u>Starting (w/ Entry Function) (RHD)</u> <u>Stop Light</u> <u>TRC (LHD)</u> <u>TRC (RHD)</u> <u>VSC (LHD)</u> <u>VSC (RHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (LHD)</u> <u>Wireless Door Lock Control (w/ Entry Function) (RHD)</u>
10A	STRG HTR	<u>Heated Steering Wheel System</u>
10A	TAIL	<u>Front Fog Light</u> <u>Headlight Beam Level Control (Manual)</u> <u>Illumination</u> <u>Rear Fog Light</u> <u>Taillight</u>
15A	WASHER	<u>Front Wiper and Washer (w/ Auto Wiper System)</u> <u>Front Wiper and Washer (w/o Auto Wiper System)</u>
30A	WIP	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Front Wiper and Washer (w/ Auto Wiper System)</u> <u>Front Wiper and Washer (w/o Auto Wiper System)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u> <u>Shift Control System (RHD)</u>

Fuse Block		
Fuse		System
10A	WIP NO.3	<u>Cruise Control (LHD)</u> <u>Cruise Control (RHD)</u> <u>Dynamic Radar Cruise Control (LHD)</u> <u>Dynamic Radar Cruise Control (RHD)</u> <u>Engine Control (LHD)</u> <u>Engine Control (RHD)</u> <u>Hybrid System (LHD)</u> <u>Hybrid System (RHD)</u> <u>Shift Control System (LHD)</u>

	Shift Control System (RHD)	
--	-----------------------------------	--