




M	2	Clearance Warning ECU
M	3	Curtain Shield Airbag Squib (RH)
M	4	Diode (Door Courtesy Rear RH)
M	5	Door Control Receiver
M	6	Door Courtesy SW (Front RH)
M	7	Door Courtesy SW (Rear RH)
M	8	Electrical Key Antenna
M	9	Front Seat Outer Belt (RH)
M	10	Front Seat Outer Belt Motor (RH)
M	11	Junction Connector
M	12	Junction Connector
M	15	Junction Connector
M	16	Junction Connector
M	17	Junction Connector
M	19	Pretensioner (Front RH)
M	20	Pretensioner (Rear RH)
M	22	Side Airbag Sensor (Front RH)
M	23	Side Airbag Sensor (Rear RH)
M	25	Side Airbag Squib (Rear RH)
M	26	Speaker (Package Tray LH)
M	27	Speaker (Package Tray RH)
M	28	Speaker (Woofer)
M	28	Speaker (Woofer)
M	29	Stereo Component Amplifier
M	30	Stereo Component Amplifier
M	32	Stereo Component Amplifier
M	35	Stereo Component Amplifier
M	36	Stereo Component Amplifier
M	37	Seat Belt Control ECU
M	38	Seat Belt Control ECU

Position of Parts in Body <From Aug. 2009 Production>

