


Position of Parts in Seat <Rear Seat>



- h 1 Cooler Control Switch Assembly
- h 2 Cooler Control Switch Assembly

- i 1 Seat Heater Control Sub-Assembly LH
- i 2 Seat Heater Control Sub-Assembly RH
- i 3 Junction Connector

- z 14 Rear Seat Airbag Assembly LH
- z 15 Rear Seat Airbag Assembly RH

Position of Parts in Seat <Rear Seat>

