


* 1:Before Sep. 2007 Production
* 2:From Sep. 2007 Production



- F 1 Starter
- F 1 Starter
- F 2 Starter
- F 3 Knock Control Sensor (Bank 1)
- F 4 Knock Control Sensor (Bank 2)

- G 1 Alternator

- m 1 Speed Sensor (Front LH)

- n 1 Speed Sensor (Front RH)

- z 10 Front Stabilizer Control ECU , Front Stabilizer Control Actuator Assembly
- z 13 Front Stabilizer Control ECU , Front Stabilizer Control Actuator Assembly
- z 14 Front Stabilizer Control ECU , Front Stabilizer Control Actuator Assembly

