



















A 1 Airbag Sensor (Front LH)
A 2 Windshield Washer Motor
A 3 Headlamp Cleaner Motor
A 4 Water Level Warning SW
A 5 Headlamp Cleaner Control Relay
A 6 Engine ECU
A 7 Engine ECU
A 8 Junction Connector
A 9 Junction Connector
A 10 Junction Connector
A 11 Junction Connector
A 17 Junction Connector
A 18 Wireless Door Lock Buzzer
A 19 Turn Signal Lamp (Front Side LH)
A 20 Windshield Wiper Motor
A 21 Height Control Sensor (Front)
A 23 Brake Fluid Level Warning SW
A 24 Power Steering ECU
A 25 Fuel Pump Resistor
A 26 Airbag Sensor (Front RH)
A 28 Security Horn
A 29 Turn Signal Lamp (Front Side RH)
A 46 Battery Current Sensor
A 47 Battery Thermometer Sensor
A 48 Skid Control ECU with Actuator
A 51 A/C Pressure Sensor (Low)

B 1 Fog Lamp (Front RH)
B 2 Headlamp Assembly (RH)
B 3 Cooling Fan ECU
B 4 A/C Pressure Sensor
B 5 Ambient Temp. Sensor
B 6 Horn (Low)
B 7 Engine Hood Courtesy SW
B 8 Millimeter Wave Radar Sensor
B 9 Horn (High)
B 10 Smog Ventilation Sensor
B 11 Headlamp Assembly (LH)
B 12 Fog Lamp (Front LH)





Position of Parts in Engine Compartment <RHD 3GR-FSE Before Jul. 2006 Production>




(RHD)



(1UR-FSE, 3GR-FSE, 3GR-FE)




(Before Sep. 2007 Production)




(From Sep. 2007 Production)


A 47
Black




A 48
Black




A 51
Black




B 1
Brown



B 2
Black



B 3
Black



B 4
Black



B 5
Black



B 6
Black



B 7
Black



B 8
Black



B 9
Black



(Before Sep. 2008 Production)

B 9
Gray




(From Sep. 2008 Production)

B 10
Black



B 11
Black



B 12
Brown

