











- L 1 Junction Connector
- L 2 Junction Connector
- L 3 Junction Connector
- L 4 Junction Connector
- L 5 Junction Connector
- L 6 Junction Connector
- L 7 Junction Connector
- L 8 Junction Connector
- L 9 Junction Connector
- L 10 Register Illumination (Driver's Side)
- L 11 VSC Warning Buzzer
- L 12 Outer Mirror SW Assembly
- L 13 Distance Control ECU
- L 14 Airbag Squib (Driver's Side Knee Airbag)
- L 15 Tire Pressure Warning Reset SW
- L 16 DLC3
- L 17 Foot Lamp (LH)
- L 18 Tilt Motor
- L 19 Steering Sensor
- L 20 Spiral Cable
- L 21 Airbag Squib (Steering Wheel Pad)
- L 22 Windshield Wiper SW Assembly
- L 23 Tweeter (Front LH)
- L 24 Acceleration Sensor (Front)
- L 25 Turn Signal Flasher
- L 26 Steering Actuator
- L 27 Tilt and Telescopic ECU
- L 28 Steering Lock ECU
- L 29 Power SW
- L 30 Register Illumination (Center)
- L 31 Combination Meter
- L 32 Clearance Warning Buzzer
- L 33 A/C Room Temp. Sensor
- L 34 Heated Oxygen Sensor (Bank 1 Sensor 2)














Position of Parts in Instrument Panel <LHD Before Jul. 2006 Production>




(Before Sep. 2007 Production)




(From Sep. 2007 Production)




L 26  
White




L 27  
White



L 28  
Black




L 29  
Black




L 30  
White




L 31  
White



L 32  
Black



L 33  
Black



L 34  
Dark Gray

