

F RELAY LOCATIONS

 : Center J/B RH

LHD : Right Side of the Instrument Panel Reinforcement (See Page 21)

RHD : Left Side of the Instrument Panel Reinforcement (See Page 21)

