



Position of Parts in Engine Compartment <LHD>




- A 1 Airbag Sensor (Front LH)
- A 2 Windshield Washer Motor
- A 3 Headlamp Cleaner Motor
- A 4 Water Level Warning SW
- A 5 Headlamp Cleaner Control Relay
- A 8 Junction Connector
- A 9 Junction Connector
- A 10 Junction Connector
- A 11 Junction Connector
- A 12 Absorber Control Actuator (Front LH)
- A 13 Skid Control ECU
- A 14 Skid Control ECU
- A 15 Skid Control ECU
- A 16 Brake Actuator
- A 17 Junction Connector
- A 18 Wireless Door Lock Buzzer
- A 19 Turn Signal Lamp (Front Side LH)
- A 20 Windshield Wiper Motor
- A 20 Windshield Wiper Motor
- A 21 Height Control Sensor (Front)
- A 22 Brake Stroke Simulator Cylinder
- A 23 Brake Fluid Level Warning SW
- A 24 Power Steering ECU
- A 25 Fuel Pump Resistor
- A 26 Airbag Sensor (Front RH)
- A 27 Absorber Control Actuator (Front RH)
- A 28 Security Horn
- A 29 Turn Signal Lamp (Front Side RH)
- A 44 Short Connector (Brake Stroke Simulator Cylinder)
- A 45 Short Connector (Brake Stroke Simulator Cylinder)
- A 52 Water Pump Motor (Inverter)
- A 53 Junction Connector
- A 54 Engine ECU
- A 55 Hybrid Vehicle Control ECU
- A 56 Oil Pump Motor Controller
- A 57 Water Pump Motor (A/C)
- A 58 Front Stabilizer Control ECU
- A 59 Inverter
- A 60 Junction Connector
- A 64 Front Wiper Deicer

Position of Parts in Engine Compartment <LHD>




Position of Parts in Engine Compartment <LHD>


A 54
Black




A 55
Black




A 56
Black




A 57
Black



A 58
Black



A 59
Black



A 60
Black



A 64
Black

