








: There is no wire color information.

* 3 : w/ Bluetooth













* 3 : w/ Bluetooth
 * 5 : 13 Speaker












A 29
Blue




A 33
Blue



A 58
Black




J 10
Blue




J 24
Black




J 27
White




J 34
Black




J 54
White




J 76
White




J 80
Blue




J107
White




J108
White




J109
White




J110
White




J111
White



J113
White



J117
Black




J131
Brown



L 1
White




L 2
White



L 5
White



M 4
White



M 12
White




M 13
White



N 3
White



N 4
White



N 6
White




N 11
Blue



O 3
White




O 4
White




O 6
White




O 11
Blue




P 21
White




P 27
White




P 28
White




P 30
White




P 44
White




R 5
White




k 1
White




z 15
Black




LD
White




RA
White




RD
White




RJ
Gray




RK
Gray



AP1
White



JA3
White



JP1
White

