


Position of Parts in Engine Compartment <RHD 2GR-FSE>

* 1:Optitron Meter
* 2:Except Optitron Meter



- B 1 High Pitched Horn Assembly
- B 4 Low Pitched Horn Assembly
- B 5 A/C Pressure Sensor
- B 6 Cooler (Ambient Temperature Sensor) Thermistor
- B 8 Millimeter Wave Radar Sensor Assembly
- B 9 Hood Courtesy Switch (Hood Lock Assembly)

- C 1 Power Steering Link Assembly
- C 2 Power Steering Link Assembly
- C 3 Power Steering Link Assembly
- C 4 Power Steering ECU Assembly
- C 5 Power Steering ECU Assembly

- D 1 Front No. 1 Ultrasonic Sensor RH
- D 2 Front No. 2 Ultrasonic Sensor Center RH
- D 3 Front No. 2 Ultrasonic Sensor Center LH
- D 4 Front No. 1 Ultrasonic Sensor LH

- G 1 Battery
- G 2 Starter Assembly

Position of Parts in Engine Compartment <RHD 2GR-FSE>

