


① : Engine Room R/B Assembly No. 1
② : Engine Room J/B Assembly No. 1


Right Engine Compartment

(LHD)

- * 1:120A ENG-AM
- * 2:120A J/B LH-AM
- * 3:150A ALT
- * 4:100A P/I-B
- * 5:50A HTR
- * 6:30A ABS NO.1
- * 7:50A PTC HTR 1
- * 8:50A PTC HTR 2
- * 9:80A P/I-AM
- * 10:40A VGRS
- * 11:80A EPS
- * 12:80A J/B LH-B
- * 13:50A ABS NO.2
- * 14:30A ST
- * 15:50A ENG-B




Unit A



① : Engine Room R/B Assembly No. 1
○ : Engine Room J/B Assembly No. 1

Left Engine Compartment

(RHD)



Unit A

