



仪表板零件位置 (右驾驶车型)




* 1:有关零件的安装位置,请参考《服务快讯》。

- I27 车内 1 号电子钥匙天线总成
- I28 带风扇的鼓风机电动机分总成
- I29 挡风玻璃刮水器开关总成
- I30 挡风玻璃刮水器开关总成
- I31 前照灯变光开关总成
- I32 换档杆位置指示灯
- I33 组合开关总成
- I35 集成控制面板总成
- I36 防滑控制蜂鸣器总成
- I37 2 号组合开关总成
- I38 收音机总成
- I39 收音机总成
- I42 多功能显示屏总成
- I43 左侧 1 号车内照明灯总成
- I44 右侧 1 号车内照明灯总成
- I45 手套箱灯总成
- I46 收音机总成
- I47 主车身 ECU
- I48 主车身 ECU
- I49 主车身 ECU
- I50 空调放大器总成
- I51 认证 ECU
- I52 认证 ECU
- I53 认证 ECU

仪表板零件位置 (右驾驶车型)




90980-12795




90980-11667




90980-12358




90980-12359




90980-12460




90980-12361




90980-12412




82824-33470




90980-10860




90980-12372



90980-12964



90980-12553




90980-12554




90980-12128




90980-12128



90980-12128



90980-12552



90980-12908

仪表板零件位置 (右驾驶车型)

